Data Loggers

Data loggers are designed to measure static strain, a phenomenon where the subject strain does not change at all or slowly changes. As seen in load tests of large-scale structures, static strain is often measured in several hundred channels and under dozens of load conditions.

Data loggers are available in 2 types: stand-alone and PC-controlled. Both are oriented to automatic multi-channel measurement as intelligent, expansible systems.

A data logger can stably measure microvolt signals in strain/stress measurement indoors and outdoors. Besides that advantage, some data loggers have a processing capability incorporated into the portable package.


Advancements in electronic components, progress in multimedia in information-related fields and downsizing of equipment have generated the following demands:

- OSimultaneous measurement of various static variables including strain/stress, load, pressure, acceleration, displacement, torque, voltage and temperature
- Visual presentation of the progressive status of measurement and function that enables smooth progression of measurement while accepting the engineer's judgment.
- Unattended measurement
- More compact and lightweight design
- Capability to measure not only static phenomena but also events changing at a frequency of several Hz

To cope with these demands, Kyowa has been making every effort.


■Scanning methods and synchronous sampling of all channels

Data Loggers




Synchronous sampling of all channels

All channels are synchronously measured (No scanning)




→ All channels are synchronously sampled and the data is updated every constant interval. Therefore, a dynamic measurement is possible.










Data Logger Selection Chart

Scanning methods

Models	Max. channels	Scanning Speed	Measuring Interval	Measuring Targets	Interfaces	Power Supply	Pages
All-in-one Data Logger UCAM-60C M14 PC-controlled Data Logger UCAM-65C M14 Resolution as high as 0.1 ×10 ⁴ strain	1000	0.02 s, 0.05s, 0.28 s, 0.5 s, 1 s, 2 s, 5 s, and 10 s	1 min to 99 h 59 min in 1 min steps	Strain (Gage, transducer) Civil engineering transducers (Maybe with a thermal sensor) Potentiometer sensors Voltage Temperature (Thermocouples platinum-resistance temperature sensors)	LAN RS-232C USB memory	100 to 240 VAC or 10 to 16 VDC	3-35
Network Terminal Box NTB-100/200 Series Field measurement is digitized.	396	0.5 s, 1 s	1 min to 99 h 59 min in 1 min steps	Strain (Gage, transducer) Civil engineering transducers (Maybe with a thermal sensor) Voltage Thermocouples	USB (USB/CAN converter)	11 to 16 VDC AC adapter (Optional accessory)	3-45
Handy Data Logger SME-100A/101A Able to connect with the NTB-100/200 series.	33	0.5 s, 1 s	1 min to 99 h 59 min in 1 min steps	Strain (Gage, transducer) Civil engineering transducers (Maybe with a thermal sensor) Thermocouples (With thermocouple adapter SMET-1A)	SD card	AA size alkaline batteries SME-101A is compatible with AC adapter.	3-49
Handy Data Logger SME-30A/31A Easy to operate Portable data logger	1	0.5 s, 1 s	1 min to 99 h 59 min in 1 min steps	Strain (Gage, transducer) Civil engineering transducers (Maybe with a thermal sensor) Thermocouples (With thermocouple adapter SMET-1A)	SD card	AA size alkaline batteries SME-31A is compatible with AC adapter.	3-49
Digital Strain Recorder RMH-310A For long-term measurement in the absence of personnel	10		1 to 59 min (1 min/step) 1 to 99 hours (1 h/step)	Strain Civil engineering transducers (Maybe with a thermal sensor) Thermocouples	USB memory	Dedicated battery (Optional accessory)	3-51
Digital Strain Recorder RMH-301B For long-term measurement in the absence of personnel	1		1 to 59 min (1 min/step) 1 to 99 hours (1 h/step)	Strain Civil engineering transducers (Maybe with a thermal sensor)	USB memory USB	Dedicated battery (Optional accessory)	3-52

Synchronous sampling of all channels


Models Max.			ampling Speed (s)	Measuring Targets		Power	Pages
	channels	0.001	0.02	0.5	granges	Interfaces	Supply	9
Fast Data Logger UCAM-550A Synchronous sampling of 1000 channel at 50 Hz*	1000		Yes		Strain (Gage, transducer) Potentiometer sensors Voltage Thermocouples	LAN	100 to 240 VAC	3-40
Medium Speed Network Terminal Box NTB-500C Synchronous sampling and distributed deployment	64	Yes			Strain (Gage, transducer) Voltage Thermocouples	USB (USB/CAN converter)	11 to 16 VDC AC adapter (Optional accessory)	3-43





UCAM-60C M14/65C M14

Data Logger



Up to 20 k ×10⁻⁶ strain with a resolution as high as 0.1 ×10⁻⁶ strain measurement possible (With full bridge system)

Common to UCAM-60C M14 and UCAM-65C M14

- Saves long-term measured data in built-in memory than the conventional products. (Built-in memory: Approx. 1.8 GB)
- Measurement up to 20 k ×10⁻⁶ strain with a resolution of 0.1 ×10⁻⁶ strain (With full bridge system)
- Scanning at 50 ms/channel (With dedicated scanners)
- High-speed scanning at 20 ms/channel (With dedicated scanners)
- Up to 30 channels measurement with dedicated scanners
- Up to 1000 channels measurement with external scanners

UCAM-60C M14

- Easy to understand English presentation
- Fluorescent display tube ensuring easy viewing in the field
- Built-in thermal printer for smooth confirmation of measured results

UCAM-65C M14

- Setting measuring conditions from PC and saving measured results to PC
- Interval measurement possible with no PC connected

The UCAM-60C M14 is an all-in-one measuring instrument developed in full pursuit of easier field measurement. It has easy-to-operate keys, a bright readable display providing understandable presentation and a printer for immediate confirmation of measurement results. All these and more are incorporated in this compact unit to satisfy every need in field measurement.

The UCAM-65C M14 is a compact online data logger fully controlled from the PC.

System Content

Data Loggers				
Models	Power Supply	Control Software UCS-60B	Features	
UCAM-60C-AC M14	AC	Optional	Operation keys, display, printer	
UCAM-60C-DC M14	DC	Ориона	Operation keys, display, printer	
UCAM-65C-AC M14	AC	Standard	5 11 . 11 16 .1 56	
UCAM-65C-AC-0 M14	AC	Optional	Fully controlled from the PC Operation keys, display,	
UCAM-65C-DC M14	DC	Standard	printer none	
UCAM-65C-DC-0 M14	DC	Optional	printer mone	
Dedicated Scanners	JSS-61B	* (TEDS com	patible)	
(Optional)	(Optional) USS-62B* (With NDIS4102 (7 pins) connectors,			
TEDS compatible)(*1)				
USS-63B* (For civil engineering, with lightning				
arresters, TEDS compatible)				
,	*The dedicated scanner measures 10 channels/unit.			
-	The main unit accommodates up to 3 dedicated			
9	canners	5.		
External Scanners	The main unit is connected to the following scanners			
\	via the optional scanner interface.			
	USB-70B (Via scanner interface USI-67A)			
Scanner Interfaces	JSI-67A	for USB-70B		
External I/O Unit	UIO-60A			
Control Software	JCS-60B			

^{*1} TEDS compatible function is made effective by connecting TEDS installed sensor through NDIS4102 (7 pins) connector.

Specifications

■Data Logger UCAM-60C M14/65C M14

Measuring Targets

Strain gages, strain-gage transducers, DC voltage-output or DC current-output instruments, civil engineering transducers with a thermal sensor, potentiometer sensors, thermal sensors

(Thermocouples and platinum resistance thermometer bulbs)

Connectable Scanners

USS-61B, 62B, 63B (Dedicated scanners, mounted on top of the UCAM-60C M14)

The main unit is connected to the following scanners via the optional scanner interface.

USB-70B series (via USI-67A)

Measuring Targets and Connectable Scanners

Scanners				External Scanners	
					Civil engineering
Measurii	USS-62B USS-63B	USB-70B- 10/20	USB-70B 30		
	0	120 Ω	Yes	Yes	Yes
	Quarter bridge system	240 Ω	Yes	Yes	Yes
	System	350 Ω	Yes	Yes	Yes
Strain gages	Quarter bridge	120 Ω	Yes	Yes	Yes
and	(true-dummy system)	350 Ω	Yes	Yes	Yes
Strain-gage	11-16	Active dummy system	Yes	Yes	Yes
transducers (*3)	Half bridge 60 to 1000 O	Active active system	Yes	Yes	Yes
())	00 10 1000 12	Common dummy system		Yes	Yes
	Full bridge	Opposite-leg active system	Yes	Yes	Yes
	60 to 1000 Ω (*2)	Full bridge system	Yes	Yes	Yes
Civil	Full bridge 120 Ω	Constant-current excitation	Yes		
engineering	Full bridge	Constant-current excitation	Yes	Yes	Yes
transducers	350 Ω	Transducers with a thermal sensor	Yes		Yes
Voltage	DC voltage	e-output instruments	Yes	Yes	Yes
Current	DC curren	t-output instruments	Yes	Yes	Yes
		K (CA)	Yes	Yes	Yes
		T (CC)	Yes	Yes	Yes
_	Thermocouples	E (CRC)	Yes	Yes	Yes
Temperature		J (IC)	Yes	Yes	Yes
		R	Yes	Yes	Yes
	Platinum resistance	Pt100 (new JIS)	Yes		Yes
thermometer bulbs		JPt100(old JIS)	Yes		Yes
	Potentiome		Yes	Yes	Yes
	Built-in lighti	ng arresters	Yes (*1)		Yes

- (*1) With USS-63B mounted.
- (*2) 120 to 1000 $\boldsymbol{\Omega}$ in high-resolution mode.
- (*3) Cannot use remote sensing sensor directly.



Line Frequencies Scanners	50 Hz Zone	60 Hz Zone	
Dedicated scanner (Standard mode)	50 ms/channel		
Dedicated scanner (High-resolution mode)	0.28 s/channel		
Dedicated scanner (High-speed mode)	20 ms.	/channel	
USB-70B (Standard mode only)	60 ms/channel	58.4 ms/channel	

Notes: 1. Scanning speeds stated above are standard maximum speeds in respective modes. Besides these, the following speeds are set for each individual channel:0.28 s, 0.5 s, 1s, 2 s, 5 s, and 10 s.

2. High-resolution mode and high-speed mode are selectable for dedicated scanners only

3. High-resolution mode is individually switchable for desired channels.

High-speed mode is only collective switching for all channels of dedicated scanners

Repeat measurement interval time=(Number of Measuring channels * scanning speed)

+ data processing time (2~20 s)

Data processing time is indetenninate, changed by measurement setting and environment.

Scanning Speed Measuring Targets	Standard Mode (50 ms/CH)	High-resolution Mode (0.28 s/CH)	High-speed Mode (20 ms/CH)
Strain (Gage & transducer)	Yes	Yes	Yes
Voltage/current-output sensor	Yes		Yes
Civil engineering transducer	Yes		
Temperature sensor (TC, Pt)	Yes		
Potentiometer sensor	Yes		Yes

Notes: 1. High-resolution mode is available only with Full bridge system. 2. High-speed mode is available Full bridge system, Voltage, Current, and Potentiometer sensor.

Operating Modes	Real-time, monitor, and automatic

Measurement Functions

Initial (Initial values are measured and stored in internal memory.) Measure (Initial values are subtracted from original values.)

Original (Raw values are measured without subtraction of initial values.) Easy Measure (Auto zero balancing function is activated.)

* The selected function is applied to all channels.

Coefficient Calculation Function

Multiplication by calibration coefficient, calibration by TEDS conversion of measured values to physical quantities scaling and correction

Unit 59 units

Automatic Measurement Function

Interval Measurement Measurement is automatically performed at preset time intervals

Trigger Measurement A relative value (certain changing quantity) or an absolute value triggers measurement.

Trigger Interval Measurement Combination of trigger measurement and interval measurement

Storage Internal memory

Capacity: Approx. 1.8 GB Strain Measurement (Standard Mode)

Constant Voltage Excitation Approx. 2 or 5 VDC

Constant Current Excitation Approx. 5.7 mA (Bridge resistance 350 Ω) Approx. 16.7 mA (Bridge resistance 120 Ω) Scanning Speed 50 ms/channel **Gage Factor** 2.00 fixed (Coefficient calculation function enables correction with 2.00/Ks.)

Initial Value Memory Range Same as measuring range

Measuring Range, Resolution and Accuracy

Measuring Range	Resolution	Accuracy
0 to ±50 k ×10 ⁻⁶ strain	1×10 ⁻⁶ strain	$\pm (0.05\% \text{ of reading} + 1) \times 10^{-6} \text{ strain}$
±50 k to ±500 k ×10 ⁻⁶ strain	10 ×10 ⁻⁶ strain	$\pm (0.05\% \text{ of reading} + 10) \times 10^{-6} \text{ strain}$

Notes: Resolution and accuracy be automatically change by Autorange function

(Strain Measurement (High-resolution Mode)			
	Constant Voltage Excitation	Approx. 5 VDC		
	Constant Current Excitation	Approx. 16.7 mA		
		(Bridge resistance 350 Ω)		
	Scanning Speed	0.28 s/channel		
ĺ	Initial Value Memory Range	Same as measuring range.		
	Gage Factor	2.00 fixed (Coefficient calculation		
		function enables correction with 2.00/Ks.		

Measuring Range, Resolution and Accuracy

Measuring Range	Resolution	Accuracy
0 to ±20 k ×10 ⁻⁶ strain	0.1 ×10 ⁻⁶ strain	$\pm (0.05\% \text{ of reading} + 0.3) \times 10^{-6} \text{ strain}$
±20 k to ±200 k ×10-6 strain	1 ×10 ⁻⁶ strain	$\pm (0.05\% \text{ of reading} + 3) \times 10^{-6} \text{ strain}$

Notes: 1. Available only with full bridges system

2. Bridge resistance should be 120 to 1000 Ω for bridge

excitation with constant voltage. 3. Bridge resistance should be 350 Ω for bridge excitation with constant current.

Measuring range 0 to $15k \times 10^{-6}$ strain 0 to 150k x10⁻⁶ strain

4. Available only with dedicated scanners.

5. Resolution and accuracy be automatically change by Autorange function

Strain Measurement (High-speed Mode)			
Constant Voltage Excitation	Approx. 2 VDC		
Constant Current Excitation	Approx. 5.7 mA (Bridge resistance 350 Ω)		
	Approx. 16.7 mA (Bridge resistance 120 Ω)		
Scanning Speed	20 ms/channel		
Gage Factor	2.00 fixed (Coefficient calculation		
	function enables correction with 2.00/Ks.)		
Initial Value Memory Range	Same as measuring range.		

Measuring Range, Resolution and Accuracy

Measuring Range	Resolution	Accuracy
0 to ±50 k ×10 ⁻⁶ strain	1 ×10 ⁻⁶ strain	$\pm (0.08\% \text{ of reading} + 3) \times 10^{-6} \text{ strain}$
$\pm 50 \text{ k to } \pm 500 \text{ k} \times 10^{-6} \text{ strain}$	10 ×10 ⁻⁶ strain	$\pm (0.08\% \text{ of reading} + 30) \times 10^{-6} \text{ strain}$

Notes: 1. Available only with full bridges system (120 to 1000 Ω)

 A vailable only with dedicated scanners.
 Resolution and accuracy be automatically change by Autorange function

Voltage Measurement (Standard Mode)

Scanning Speed	50 ms/channel
1 '0' 137 1 NA D	

Initial Value Memory Range Same as measuring range Measuring Range, Resolution and Accuracy

Range Mode	Measuring Range	Resolution	Accuracy	Input Resistance
V/500 mV	0 to ±50.000 mV	1 μV	\pm (0.05% of reading + 0.003) mV	10 M Ω
V/300111V	± 50.00 to ± 500.00 mV	10 μV	±(0.05% of reading + 0.03) mV	or more
V/50 V	0 to ±5.0000 V	100 μV	±(0.05% of reading + 0.0002) V	1 Μ Ω
V/30 V	±5.000 to ±50.000 V	1 mV	±(0.05% of reading + 0.002) V	or more

Note: Resolution and accuracy be automatically changed by Autorange function.

●Voltage Measurement (High-speed Mode)

Scanning Speed 20 ms/channel

Initial Value Memory Range Same as measuring range

Measuring Range, Resolution and Accuracy

			-	
Range Mode	Measuring Range	Resolution	Accuracy	Input Resistance
V/500 mV	0 to ±50.000 mV	1 μV	±(0.08% of reading + 0.006) mV	10 Μ Ω
V/300 IIIV	±50.00 to ±500.00 mV	10 μV	±(0.08% of reading + 0.06) mV	or more
V/50 V	0 to ±5.0000 V	100 μV	±(0.08% of reading + 0.0006) V	1 Μ Ω
V/30 V	+5 000 to +50 000 V	1 m\/	+(0.08% of reading + 0.006) \/	or more

Notes: 1. Resolution and accuracy be automatically change by Autorange function

2. Available only with dedicated scanners

●Current Measurement (Standard Mode) Scanning Speed 50 ms/channel Initial Value Memory Range Same as measuring range

Measuring Range, Resolution and Accuracy

Channel Mode	Measuring Range	Resolution	Accuracy
I/50 mA	0 to ±50.00 mA	10 μΑ	\pm (0.05% of reading + 0.01) mA
Notes: 1. External shunt resistor (High-accuracy 250 Ω) is required.			

2. Accuracy does not include resistance error of external shunt resistor

●Current Measurement (High-speed Mode)

Scanning Speed 20 ms/channel Initial Value Memory Range Same as measuring range

Measuring Range, Resolution and Accuracy

Channel Mode	Measuring Range	Resolution	Accuracy
I/50 mA	0 to ±50.00 mA	10 μΑ	±(0.08% of reading + 0.01) mA

Notes: 1. Available only with dedicated scanners.

External shunt resistor (High-accuracy 250 Ω) is required. Accuracy does not include resistance error of external shunt resistor.





■Temperature Measurement wi	th Thermocouple (Standard Mode)
Scanning Speed	50 ms/channel

Measuring Range, Resolution and Accuracy

	<u> </u>				
Type	Measuring Range	Resolution	Accuracy	Internal Reference Junction Compensator Accuracy	
K	-200.0 to 1230.0 °C		±0.7°C	±0.5 °C	
Т	-200.0 to 400.0 °C		±0.7°C	(With input terminal	
Е	-200.0 to 660.0 °C	0.1°C	±0.5°C	temperature balanced in an ambient)	
J	-200.0 to 870.0 °C		±0.6°C	(Temp. range of	
R	0 to 1760.0 °C		±2.2°C	0 to 50 °C)	

Notes: 1. Accuracies do not include the internal reference junction

compensator accuracy.

2. The reference junction compensator is switchable between internal and external.

3. Thermocouple resistance should be 1 $k\Omega$ or less.

●Temperature Measurement with Civil Engineering Transducers with a Thermal Sensor (Standard Mode)

Scanning Speed 50 ms/channel

Measuring Range, Resolution and Accuracy

Measuring Range	Resolution	Accuracy
-50.0 to 200.0°C	0.1°C	±0.5°C

Notes: 1. Target physical quantity and temperature are measured

in a single channel.
2. Strain measuring range are the same as in strain measurement in standard mode.

■Temperature Measurement with Platinum Resistance

Thermometer Bulb (Standard Mode)

Scanning Speed 50 ms/channel

Measuring Range, Resolution and Accuracy

<u> </u>	J.,	,	
Type	Measuring Range	Resolution	Accuracy
Pt100	-200.0 to 660.0°C	0.1°C	+0.3°C
JPt100	-200.0 to 510.0°C	0.1 C	±0.5 C

Note: Connection is 3-wire system.

POT.

Measurement with Potentiometer sensor (Standard Mode)		
Scanning Speed	50 ms/channel	
Initial Value Memory Rang	ge Same as measuring range	Т
Sensor Power Supply	Approx. 2 VDC	
Potentiometer Resistance	1 to 10 kΩ	
Measuring Range, Resolution and Accuracy		
Channel Mode Measuring	Range Resolution Accuracy	

●Measurement with Potention	neter sensor (High-speed Mode)
Scanning Speed	20 ms/channel
Initial Value Memory Range	Same as measuring range
Sensor Power Supply	Approx. 2 VDC
Potentiometer Resistance	1 to 10 kΩ

0.01%

±0.1% FS

Ī	Measuring Range, Resolution and Accuracy				
	Channel Mode	Measuring Range	Resolution	Accuracy	
	POT.	0 to +50.00%	0.01%	+0.1% FS	

0 to ±50.00%

	0 10 _50.0070	0.0170	_0.17015
Note: Available	e only with dedica	ated scanners.	
Internal Timer	Real time clock is	s built-in. (Battery	backup)
Display Fluorescent display tube			
	128×64 dots (UC	CAM-60C M14)	
Printer	Printing	Thermal	
	Paper width	58 mm (24 charac	ters/line)
	Printing speed	60 mm/s (Max.) (l	JCAM-60C M14)
Interface	RS-232C		
	LAN (10BASE-T/	100BASE-TX)	
			by USB Flash Drive.
	Notes: 1. Measur	ement data canno	ot be saved directly
		memory.	
	Notes: 2. USB Fla	sh Drives	
	<u> </u>	y: 32 GB or less, Fi	
			ves: GH-UFI-XSD2G
		facturer: GREENH	
File Conversion			converted to CSV.
	(UCAM-60C M1	4)	
Self Diagnosis Fu			
		JCAM-60C M14),	
	printer (UCAM-6		
	bridge excitation	·	
	input/output re		
	insulation resista	ance, mode, etc.	
TEDS			
	451.4 Mixed Mod		
Applicable sensor: Should have information			en in accordance
	with IEEE tem	<u> </u>	
	Cable length	should be 30m or	less.

(With dedicated scanner USS-61B/62B/63B.)

20 to 85% (Non-condensing)

Operating Temperature 0 to 50°C

Operating Humidity

Setting Maintenance Function			
ACOM at measurement circuit is switchable			
between floating and GND connect.			
Power Supply	100 to 240 VAC (AC-operated version)		
	10 to 16 VDC (DC-operated version)		
	* DC operated version has power control function.		

Current Consumption

100 VAC: 0.5 A or less (With 3 dedicated scanners mounted) 12 VDC: 4.0 A or less (With 3 dedicated scanners mounted)

Dimensions

 $360~W \times 88~H \times 400~D~mm$ (Excluding protrusions) (UCAM-60C M14) 327 W \times 88 H \times 365 D mm (Excluding protrusions) (UCAM-65C M14)

Weight

Approx. 6.3 kg (Excluding scanner) (UCAM-60C M14)

Approx. 9.6 kg (With 3 dedicated scanners USS-62B mounted) (UCAM-60C M14) Approx. 5.0 kg (Excluding scanner) (UCAM-65C M14)

Approx. 8.3 kg (With 3 dedicated scanners USS-62B mounted) (UCAM-65C M14)

Standard Accessories

AC power cable P-18 (With 2-pin conversion plug CM-52) (ACoperated version), DC power cable P-76 (DC-operated version), recording paper UCAM-60A-RP (1 roll for UCAM-60C M14 only), screwdriver, spare fuse, CD-R (Instruction Manual), CD-R (Control software UCS-60B for UCAM-65C M14 only), ground wire P-72

Optional Accessories Recording paper UCAM-60A-RP (10 rolls/pack)

■Dedicated Scanner	USS-61B/62B/63B
Models	USS-61B (TEDS

Models	USS-61B (TEDS compatible)	
	USS-62B (With NDIS4102 (7 pins) connectors	
	TEDS compatible)	
	USS-63B (For civil engineering measurement,	
	TEDS compatible, with lightning	
	arresters)	
Channels	10/unit	
Switching Terminals	Semiconductor relays	
Input Terminals	Connect to lead wire by either soldering	
	or screwing.	
	NDIS4102 (7 pins) connectors (USS-62B)	
	One-touch terminal block (JT-1A) (Optional)	
Lightning Arresters	Built in USS-63B	
Operating Temperature	0 to 50°C	
Operating Humidity	20 to 80% (Non-condensing)	
Dimensions	$320 \mathrm{W} \times 28 \mathrm{H} \times 80 \mathrm{D} \mathrm{mm}$ (Excluding protrusions)	
Weight	USS-61B: Approx. 0.8 kg	
	USS-62B: Approx. 1.1 kg	
	USS-63B: Approx. 1.0 kg	
Standard Accessories		

Standard Accessories

NDIS4102 (7 pins) connector caps (Pre-attached to connectors, USS-62B only), terminal cover, channel label, short bar ML-1000-3H1

Scanner Interfaces USI-67A		
Connectable Scanners	USB-70B	
Number of Scanners	Max. 20	
Cable Length	Max. 1 km (When connecting the UPS-70B	
•	to the USB-70B.)	
Operating Temperature	0 to 50°C	
Operating Humidity	20 to 85% (Non-condensing)	
Dimensions	$99\mathrm{W}\times50\mathrm{H}\times163\mathrm{D}\mathrm{mm}$ (Excluding protrusions	
Weight	Approx. 170 g	

USI-67A

External I/O Unit UIO-60A		
Output	ALARM signal	4 channels (High/low limit checking)
	BUSY signal	1 channel
Input	START signal	1 channel
	STOP signal	1 channel
	RESET signal	1 channel
	RAINFALL signal	1 channel
Operatin	g Temperature	0 to 50°C
Operatin	g Humidity	20 to 85% (Non-condensing)
Dimensio	ons	90 W × 50 H × 180 D mm
		(Excluding protrusions)
Weight		Approx. 140 g
Standard	l Accessories	
Screw	driver	




Models	USB-70B-10 (For general measurement)
	USB-70B-20 (For general measurement, with
	NDIS4102 (7 pins) connectors)
	USB-70B-30 (For civil engineering)
Measuring	Targets
	Strain gages
	Strain-gage transducers
	DC voltage 0 to ±50 V
	DC current 0 to ±50 mA
	Thermocouples K, T, E, J, N, B, S, R
	Platinum resistance thermometer bulbs Pt100,
	JPt100 (USB-70B-30)
	Civil engineering transducers with a thermal sensor (USB-70B-30)
	Potentiometer sensors
Channels	50/unit
Connection	data loggers
UCAM-60	C M14, UCAM-65C M14
An option	nal Scanner Interface USI-67A is required.
Number of	Connection Up to 20
19 if there	e are 30 channels in the data logger
Input Termi	nals
Screw-sol	dering terminal blocks (M3 screw with washer)
NDIS4102	? (7 pins) connectors (USB-70B-20)
Receptacl	e PRC90-231BR10-7F
Applicabl	e plug ex. PRC03-12A10-7M10.5
Built-in lig	htning arresters (USB-70B-30)

Switching Elen	nents	Semiconductor relays
Measuring Mode		Every channel set by the data logger
Measuring Cha	annel N	lumber
The upper 2-	digit fro	om every 10 channels are set with digital switches
Power Supply	Suppli	ed from data logger.
	If the	cable is extended or if 4 or more scanners are
	conne	cted, an optional UPS-70B should be mounted
	into the scanners. 302 W ×107 H × 500 D mm	
Dimensions		
	(Exclud	ding protrusions)
Weight	USB-7	OB-10: Approx. 7.3 kg (Excluding UPS-70B)
	USB-7	OB-20: Approx. 8.5 kg (Excluding UPS-70B)
	USB-70B-30: Approx. 7.7 kg (Excluding UPS-70B)	
Option Built-in AC Power Unit UPS-70B 100 to 240 VAC (100 to 127 VAC or 220 to		n AC Power Unit UPS-70B
		240 VAC (100 to 127 VAC or 220 to 240 VAC
	automatic switchover)	


Standard Accessories Phillips precision screwdriver Connection cable N-24 (1 m)

■ Dimensions





■Control Software UCS-60B



Operating Environment				
OS Windov	vs® 8/8.1, Windows® 10			
English/	Japanese, 32/64 bits support			
CPU Core 2 D	Duo, 2 GHz or advanced			
Memory If 32-bit	OS, 2 GB or more			
If 64-bit	OS, 4 GB or more			
Display 1024 x 1	768 pixels or more			
External Connection	Serial port: RS-232C, standard serial port or			
	a port connectable to USB-serial			
	conversion adaptor			
	LAN port: For Ethernet communication			
	GP-IB			
Measuring Condition Setting Functions				
Controllable UCAMs	UCAM-60C/65C			

Measuring Condition S	Setting Fur	nctions
Controllable UCAMs	UCAM-60	C/65C
Measuring Channels	CH000 to	CH999
Measurement Functio	ns	EASY MEAS., MEAS., ORIG., INITIAL
Repeat Times		0 to 9999 (0: Infinite)
Calibration Coefficient	Calculation	ON/OFF selectable
Channel Conditions	Scanner ty	/pe, measuring channel mode,
	scanning s	speed, calibration coefficient,
	number o	f digits below decimal point, unit,
	offset, refe	erence temperature, initial value,
	channel n	ame (within 18 alphanumerics)
Interval Measurement	Conditions	Starting date/time, time interval
Trigger Measurement C	Conditions	Trigger channel (Up to 4 channels),
		AND/OR between trigger channels,
		trigger value, offset,
		repeat times 0 to 9999 (0: Infinite),
		number of steps up to 99
Trigger Interval Measuremen	nt Conditions	Trigger channel (Up to 4 channels),
		reference value of trigger channel,
		AND/OR between trigger channels,
		time interval, repeat times 0 to 9999
		(0: Infinite), number of steps up to 99
Measuring Condition		Reading/saving possible
Calculation Condition	Setting Fu	nctions
Calculation Condition	File	Reading/saving possible
Measurement Functio	ns	MEAS check, initial value measurement,
		monitor measurement (max. 40 channels),
		real-time measurement, automatic
		measurement (interval, trigger
		measurement, trigger interval),
		change stroke measurement
Numeric Display of Me		ıta
NI ' 187' I	111 611	and the second second second

List of the most recent data in real-time or

Data obtained in monitor measurement

Y-Time graph, Y-Cycle graph, X-Y graph,

List of all data, list of data by measurement point,

Max. 20 (max. 10 sets of channels in X-Y graph)
Zooming X and Y axes, auto scaling of X and

automatic measurement

initial values, check results

bar graph

Y axes, cursor



Numeric Window

Display Formats

Monitor Window

Types of Graph

Display Channels

Display Operations

Graphic Display of Measured Data

Data Available on Disp	play Depends on the number of	
	measuring channels as follows:	
	100 channels or less 10000 data	
	200 channels or less 5000 data	
	500 channels or less 2000 data	
	501 channels or more 1000 data	
Measured Data Saving	Formats KU1, UCAM-70A (ASCII), CSV,	
	XLS (MS-Excel format)	
TEDS Reads info	ormation from TEDS-installed sensors.	
Reproduce Program		
KU1 format files, UCAM-70	A format files (compatible with both ASCII and binary	
and UCAM-500A/B format	t files can be read/saved, displayed and cut/converted	
into CSV or XLS format files	5.	
Calculation Condition S	Setting Functions	
Calculation Condition File Reading/saving possible		
Numeric Display of Me	asured Data List of all data	
Graphic Display of Mea	asured Data	
Types of Graph	Y-Time graph, Y-Cycle graph,	
	X-Y graph, bar graph	
Display Channels	Max. 20 (max. 10 sets of channels	
	in X-Y graph)	
Display Operations	Zooming X and Y axes,	
	auto scaling of X and Y axes, cursor	
Display Condition File	Reading/saving possible	
Restrictions		
To save or convert measured data into an XLS format file, the number of		
and the number of data are	e limited to the following:	
Channels	Max. 250	
Data	Max. 10000	
Note that the UCS-60B is no	ot compatible with measuring/calculation/display	

condition files compiled with the UCS-25A.

UCAM-550A

Fast Data Logger



Synchronous sampling at 50 Hz of all channels

- Synchronous* sampling of all channels
- ●Synchronous measurement of 1000 channels at max. 50/s
- Synchronous measurement of up to 20 units possible using a LAN cable
- Control using Dynamic Data Acquisition Software DCS-100A
- •5 types of measuring units available
- * Except temperature measurement using USM-51B or USM-52B

To Ensure Safe Usage

DCS-100A, standard accessory, can measure up to 300 channels. Measurement up to 1000 channels requires an optional software DCS-106A. See chapter 4.

UCAM-550A is a fast data logger that repeatedly measures a maximum of 1000 channels at an interval of 0.02 s.

Because it is capable of high-speed synchronous measurement, this unit measures a wide range of phenomena, from static to dynamic phenomena. The following 5 types of measuring units are provided.

- Strain Unit USS-51B (Potentiometer sensor also supported)
- ●Voltage Unit USV-51B
- ●Thermocouple Unit UST-51B
- Strain/Voltage/Thermocouple Unit USM-51B, USM-52B

They support strain gages, strain-gage transducers, voltage output sensors, potentiometer sensors, and thermocouples, measure and collect strain and stress, load, pressure, and displacement, as well as voltage and temperature.

Input channels are for 1 unit a maximum of 50 channels, and with 20 units cascaded, a maximum of 1000 channels, and these are suited from small-scale to large-scale measurement.

Measuring Targets and Measuring Unit

Measuring units Measuring targets			USM-51B/52B*	USS-51B	USV-51B	UST-51B
	ing targets	120 Ω	Yes	Yes		
Strain gages	Quarter bridge					
		350 Ω	Yes	Yes		
Strain-gage	Half bridge	Active-dummy	Yes	Yes		
transducers	120 to 1 k Ω	Active-active	Yes	Yes		
	Full bridge	Active opposite-leg	Yes	Yes		
	120 to 1 k Ω	Full bridge	Yes	Yes		
Potention	neter sensors	1 to 10 kΩ	Yes	Yes		
Vo	ltage	±20 V	Yes		Yes	
		K	Yes			Yes
	Thermocouples	T	Yes			Yes
Temperature		E	Yes			Yes
Temperature		J	Yes			Yes
		R	Yes			Yes
		N	Yes			Yes*

^{*}Requires UCAM-550A firmware version 03.00 or higher.



Data Logger

Specifications

UCAM-55	50A				
Models	UCAM-550A With DCS-100A				
	UCAM-550A-0 Without DCS-100A				
Channels	5				
Maxim	um of 50 channels/unit (Possible up to 5 units of the				
measur	ring unit)				
(Each n	neasuring unit measures 10 channels.)				
Measur	rement is possible of up to 1000 channels at maximum by				
adding	an optional software DCS-106A.				
*The pu	ublic command corresponds up to 20 units (Max. 1000 channels).				
*DCS-1	00A corresponds to up to 6 units (Max. 300 channels).				
Sampling	Method Synchronous sampling of all channels				
Sampling	Frequencies 1, 2, 10, 20, and 50 Hz				
*Respo	nse frequency depends on the measuring unit.				
USM-5	USM-51B/52B*, USS-51B, USV-51B, UST-51B: DC to 7.8 Hz				
Deviation: 0.5 to -3.5 dB					
*For temperature measurement with USM-51B/52B using scanning					
mode, the updating rate is approx. 1 s.					
	Amplitude (dB)				
	0				
	_1				

Amplitud	e (dB)						
0 🔷	•	-				nc	COTT
-1						-	11111
-2			-242			 }-	1
-3						+ -	-14 4 4
-4			- 44 64 -				
-5			 - - - - - -				-14 + 1
-6 -	i	<u>i i i </u>	11111	<u> </u>		<u>i i </u>	11111
0.1	0.2	0.5	1	2		5	10
		Fre	quencie	es (Hz)			
unctions	s Original value measurement						
	Measure value measurement						
10 BASE-T, 100BASE-TX							

Measuring Fund	tions Original value measurement
	Measure value measurement
Interfaces	10 BASE-T, 100BASE-TX
	Between PC and UCAM
	LAN cable (Straight) Max. 100 m
	Between UCAM and UCAM
	STP straight cable (See notes) Max. 100 m
	Note: "STP" is the initials of Shield Twisted Pair,
	and an STP cable is a shielded LAN cable
Display	LCD (20 digits × 2 lines)
	Status display LED: POWER (When power ON, lit green)
	MASTER (When master, lit green, when slave, not lit)
	TRANSFER (When communications, flashing green)
Operation Keys	UP, Down, Left, Right
Data Storage	Measurement data is saved on a PC (No internal storage)
Operating Temp	perature 0 to 40°C
Operating Hum	idity 20 to 85% (Non-condensing)
Power Supply	100 to 240 VAC
	Approx. 50 VA (With 5 USS-51B strain units
	installed, and 120 Ω load on all channels connected)
Dimensions	$426\mathrm{W}\times132.5\mathrm{H}\times305\mathrm{D}$ mm (Excluding protrusions
Weight	Approx. 7 kg (With 5 USS-51B strain units installed

Standard Accessories AC power cable P-18 (With a 2-pin conversion plug CM-52), ground wire P-72, DVD (DCS-100A, instruction manual)

Dedicated Optional Accessories

Strain/Voltage/Thermocouple Unit USM-51B/USM-52B			
Input Terminals			
USM-51B: NDIS4102 (7 pins) connectors, and screw-soldering terminal blocks			
USM-52B: NDIS4102 (7 pin	DIS4102 (7 pins) connectors, and one-touch terminal blocks		
Channels	10		
Measuring Targets	Strain gages, strain-gage transducers,		
	potentiometer sensors,		
voltage, and thermocouples			
Bridge Excitation	2 VDC		
Power Supply to Sensors	rs 2 VDC, for potentiometer sensors		
Gage Factor	2.00 fixed		
Frequency Response	DC to 7.8 Hz, deviation: 0.5, -3.5dB		
	(Except temperature measurement)		
Burnout Check	Performing burnout when checking		
TEDS	Reads information from TEDS-installed sensors		
Strain Potentiometers	and Voltage		

Targets	Mode	Measuring Range	Resolution	Accuracy
Strain	L	0 to ±19 k ×10 ⁻⁶ strain	1 ×10 ⁻⁶ strain	±0.08%FS
Strain	Н	0 to ±300 k ×10 ⁻⁶ strain	10 ×10 ⁻⁶ strain	±0.06%F3
Potentiometers		-50% to 50%	0.01%	±0.1%FS
Volta	ige	-20 to 20 V	1 mV	±0.08%FS

Thermocouples

Types	Range	Accuracy* (Resolution: 0.1 °C)		
K	-200.0 to 1200.0 °C	-200.0 to below -100.0 °C	±(0.3% of reading + 0.8 °C)	
	-200.0 to 1200.0 °C	-100.0 to 1200.0 °C	±(0.2% of reading + 0.6 °C)	
Т	-200.0 to 350.0 °C	-200.0 to below -100.0 °C	±(0.3% of reading + 0.8 °C)	
'	-200.0 to 330.0 °C	-100.0 to 350.0 °C	±(0.2% of reading + 0.6 °C)	
F	-200.0 to 800.0 °C	-200.0 to below -100.0 °C	±(0.3% of reading + 0.8 °C)	
-	-200.0 to 800.0 -C	-100.0 to 800.0 °C	±(0.2% of reading + 0.6 °C)	
J	-200.0 to 750.0 °C	-200.0 to below -100.0 °C	±(0.3% of reading + 0.8 °C)	
]	-200.0 to 7 30.0 °C	-100.0 to 750.0 °C	±(0.2% of reading + 0.6 °C)	
R	0.0 to 1600.0 °C	0.0 to below 100.0 °C	±(0.6% of reading + 1.2 °C)	
11	0.0 to 1000.0 -C	100.0 to 1600.0 °C	±(0.5% of reading + 1.0 °C)	
N	-200.0 to 1250.0 °C	-200.0 to below -100.0 °C	±(0.3% of reading + 0.8 °C)	
IN	-200.0 to 1230.0 °C	-100.0 to 1250.0 °C	±(0.2% of reading + 0.6 °C)	

* Accuracy of the Internal Reference-junction Compensator Within ±1.0 °C (When temperature balanced at input terminals) (The ambient temperature is $25\pm10\,^{\circ}\text{C}$) Within $\pm2.0\,^{\circ}\text{C}$ (When temperature balanced at input terminals)

(The ambient temperature is other than mentioned above.)

Standard Accessories Terminal cover UM-51B

Strain Unit USS-51B	
Channels	10
Measuring Targets Strain gage, strain-gage transducers,	
	potentiometer sensors
Bridge Excitation	2 VDC constant voltage (Applied constantly)
Power Supply to Sensors	2 VDC constant voltage (Applied constantly)
Gage Factor	2.00 fixed
	(Correction is possible at 2.00/Ks with the
	engineering value conversion function)

Measuring Range, Resolution, Accuracy (In static (DC) Inputting)

Target	Mode	Measuring Range	Resolution	Accuracy
Strain	L	0 to ±19 k ×10 ⁻⁶ strain	1 ×10 ⁻⁶ strain	±0.05% FS
Strain	Н	0 to ±200 k ×10 ⁻⁶ strain	10 ×10 ⁻⁶ strain	±0.03 % F3
Poten [*]	tiometers	0 to ±50%	0.01%	±0.1% FS

Note: Measuring range is indicated when the initial measurement and the original value measurement are performed. In the case of a measure value measurement, the value of the initial measurement is subtracted in advance from the original measurement value.

Optional Accessories Terminal cover UT-50A

■Voltage Unit USV-51B

Channels 10

Measuring Targets DC voltage, voltage output type sensors

Measuring Range, Resolution, Accuracy (In static (DC) Inputting)

Measuring Range	Resolution	Accuracy	Signal Source Resistance
0 to ±20.000 V	1 mV	±0.05% FS	50 Ω or less

Standard Accessories Terminal cover UT-50A

■Thermocouple Unit UST-51B 10

Channels

Measuring Targets Temperature (Thermocouples)

Measuring Range, Resolution, Accuracy (In static (DC) Inputting)

Types	Measuring Range		Accuracy
V	L	-200.0 to 437.0°C	±0.8°C
K	Н	-200.0 to1200.0°C	±2.8°C
Т	_	-200.0 to 350.0°C	±0.7°C
F	L	-200.0 to 260.0°C	±0.5°C
E	Н	-200.0 to 800.0°C	±1.7°C
J	L	0 to 330.0°C	±0.6°C
J	Н	0 to 750.0°C	±2.0°C
R	_	0 to 1600.0°C	±2.2°C
		-200.0 to below -100.0 °C	±(0.4% of reading + 1.0 °C)
N		-100 to 530.0 °C	±(0.3% of reading + 0.8 °C)
IN	Н	-200.0 to below -100.0 °C	±(0.4% of reading + 1.2 °C)
	П	-100 to 1250.0 °C	±(0.3% of reading + 1.0 °C)

* When temperature balanced at input terminals, and the ambient temperature is 25 ±10 °C.

Type K, T, E, J, and R: Within ±0.5 °C

Type N: Within ±1.0 °C

Note: Accuracy does not include internal reference junction accuracy. Switching between internal and external standard connect compensators is possible. Thermocouple resistance 300 Ω or less (K type).

Standard Accessories Terminal cover UT-50A

Connection Cable U-17 to 20 (See chapter 8.)

■Isolation Transformer UPT-300B

This is used to obtain good measurement results under bad power supply conditions (Strong noise, etc.).

■One-touch Terminal Block JT-1A

A terminal block that supports one-touch connection of input lead wires, and is to be attached to input terminals. 1 for each lead wire (Sale units: 10).

■Dummy Panel UD-50A

Covers the slots of a UCAM-550A that do not have a measuring unit installed.


DCS-100A software, specification for control of UCAM-550A


*For details of DCS-100A, see chapter 4.

		<u>-</u>	
Units	Up to 6 u	ınits (up to 300 channels.) Standard Issue	
	Up to 20 units (up to 1000 channels.) With the optional		
	DCS-106	A.	
Interface	LAN		
Saving Format	Saves the	e measured data in the PC folder in the KS2	
	format fi	le.	
Sampling Frequ	ency 1, 2	, 10, 20, 50 Hz	
Measure Mode	Manual,	Manual (Set Record Data), Interval, Analog Trigger	
Measurement F	unctions	MEASURE or ORIGINAL	
		MEASURE The measured value	
		= Sensor output value - Initial value	
		ORIGINAL The measured value	
		= Sensor output value	
Calibr. Const. Operation Sets the Calibr. const. operation ON/OFF of			
all channels at one time.			
Calibr. const. operation: The measured value			
		CAL coefficient + Offset	
Channel Condit	ions Me	asuring ON/OFF, Measuring mode, Range, Calibr.	
	con	st., Offset, Unit, Initial value, Channel name,	
		asuring range, Rated capacity, Rated output,	
	Deci Digits, Chk. Val. (Up), Chk. Val. (Down)		
	(Dis	splay items can freely be selected.)	
Measuring Initia		Measures the initial value of each sensor.	
Manual Measur	ement	Records data from REC to STOP or from REC to	
		the number of data, specified on the Manual	
		(Set Record Data).	
Interval Measurement Records data automatically based		Records data automatically based on the pre-set	
		starting time and recording interval.	

Analog Trigger Mea				
Starts/stops recording data based on the pre-set trigger conditions.				
(Trigger level value: Fixed)				
End trigger Setta				
Delay Up to 3000		art and end.		
Trigger channel A	,			
Trigger level Phys				
Trigger slope Pos				
(Trigger level valu				
End trigger Setta				
Delay Up to 3000		art and end.		
Trigger channel A				
Trigger level Phys	ical quantity			
Trigger slope Pos				
Changing Stroke	Changes the da	ta, before the stoke and after		
	the stoke, wher	using a displacement transducer.		
Static Masurement	Every time the I	DCS-100A starts recording data,		
		dditionally saves the moving-averaged		
		in a single CSV format file.		
	*Measure Mode	e: Manual and Interval only.		
Burnout Checking	(USM-51B/52B	only.)		
Loading TEDS Sense	or Information	Loads the TEDS information		
		automatically and sets the channel		
		conditions. (USM-51B/52B only.)		
Setting Parameter a	and Loading Par	ameter		
Loads and sets the	e UCAM-550A in	ternal parameter.		
■Setting Environm	ent			
Setting Hardware	e Configuration	Sets the number of units,		
		device names, and measuring units.		
		Loads the measuring unit		
		configuration from the UCAM-550A		
Communication	Check	Loads the UCAM-550A version.		

■Dimensions








NTB-100/200 Series

Network Terminal Box



Digitization of field measurements

- Network output conforms with to CAN, enables a single wire connection
- •The wide area, decentralized arrangement will be useful for the infrastructure of building and civil engineering.
- Digitizing data adjacent to the sensor, enables transmission of digital data robust against noise.
- ●Compact, lightweight and affordable, allowing a small-sized system to be built on site easily.
- Various ways of docking and connection are provided, broadening system applications.
- Measurement is started immediately with the NTB-10A software.

NTB-100/200 series is a measuring instrument that extends with one cable, and a decentralized arrangement.

A single unit measures 4 channels, and allows up to 99 units to be connected, so measurement up to 396 channels is possible.

By placing an NTB near a sensor, only a single communication cable is required to build a total distance of a 1 km wide area network

The digital transmission is hardly affected by noise, thus useful for building a wide area network.

Directly connects various sensors including strain gages, facilitates measurement in the field such as construction or building site, or for indoor experiments and researches.

Voltage as well as thermocouples are measured by NTB-201A.

Allows SME-100A/101A (page 3-49) to be connected.

NTB-100 Series Specifications

П	Network Terminal Box Models					
	Models*	Bridge excitation	Sensor input terminal	Quarter bridge		
	NTB-100B-120	Constant-voltage	One-touch terminal	120 Ω		
NTB-101A-120 Constant-voltage NTB-100B-350 Constant-voltage NTB-101A-350 Constant-voltage NTB-110B-350 Constant-current NTB-111A-350 Constant-current		Screw soldering terminal	120 Ω			
		One-touch terminal	350 Ω			
		Constant-voltage	Screw soldering terminal	350 Ω		
		Constant-current	One-touch terminal	For Full bridge only		
		Constant-current	Screw soldering terminal	For Full bridge only		
	to a long agreement to be					

*Control Software NTB-10A Standard accessory. NTB-10A is optional for models with suffix "-0".

Network Terminal Box and Measuring Targets

			NTB Models			
Bridge	Measuring targets			General-purpose strain measurement		Civil engineering measurement
excitation				NTB-100B-120 NTB-101A-120	NTB-100B-350 NTB-101A-350	NTB-110B-350 NTB-111A-350
		Quarter bridge	120 Ω	Yes		
	Strain gages	Quarter bridge	350 Ω		Yes	
Constant voltage		Half-bridge 120 to 1000 Ω	Active-active system	Yes	Yes	
		Full-bridge 120 to 1000 Ω	Full bridge	Yes	Yes	
	61.1		Full bridge			Yes
Constant current	Civil engineering transducers	Full bridge 350 Ω	Civil engineering transducer with thermal sensors			Yes

Channels	4
Scanning Speed	Approx. 0.5 s/channel: 0 to \pm 30 k \times 10 ⁻⁶ strain
	Approx. 1 s/channel: \pm 30 k \times 10 ⁻⁶ strain or more
	Approx. 1 s/channel: With civil engineering
	transducers with a thermal
	sensor
Bridge Excitation	Approx. 2 VDC for constant-voltage bridge excitation
	Approx. 5.6 mA for constant-current bridge excitation
	(At bridge resistance 350 Ω)
Measuring Range	Strain measurement
	$0 \text{ to } \pm 300 \text{ k} \times 10^{-6} \text{ strain (Constant-voltage bridge excitation)}$
	$0 \text{ to } \pm 30 \text{ k} \times 10^{-6} \text{ strain (Constant-current bridge excitation)}$
	Temperature measurement with civil engineering
	transducers with a thermal sensor: -30.0 to 70.0°C
Resolution	Strain measurement
	0 to \pm 30 k \times 10 ⁻⁶ strain: 1 \times 10 ⁻⁶ strain
	$\pm 30 \text{ k to} \pm 300 \text{ k} \times 10^{-6} \text{ strain:} 10 \times 10^{-6} \text{ strain}$
	Temperature measurement with civil engineering
	transducers with a thermal sensor: 0.1°C
Accuracy	Strain measurement
	0 to \pm 30 k \times 10 ⁻⁶ strain: \pm (0.05% of reading + 2) \times 10 ⁻⁶ strain
	\pm 30 k to \pm 300 k \times 10 ⁻⁶ strain: \pm (0.1% of reading + 20) \times 10 ⁻⁶ strain
	Temperature measurement with civil engineering
	transducers with a thermal sensor: ± 0.5°C
TEDS	Reads information from TEDS-installed sensors.
	Channel name writing (Kyowa ID only)



	Mode Provided ON/OFF using "OPT.3" DIP switch.
Interfaces D	edicated interface conforming to CAN, cable extension up to 1 km
Operating T	
Operating H	lumidity 20 to 85% (Non-condensing)
Power Supp	ly 11 to 16 VDC
Current Con	sumption (At 12 VDC)
	Constant-voltage bridge excitation
	Operation: 100 mA or less
	Waiting: 60 mA or less
	Standby (In power save mode): 40 mA or less
	Constant-current bridge excitation
	Operation: 70 mA or less
	Waiting: 60 mA or less
	Standby (In power save mode): 40 mA or less
Dimensions	One-touch type: $150 \text{ W} \times 28 \text{ H} \times 55 \text{ D}$ mm (Excluding protrusions)
	Screw soldering type: $150 \text{ W} \times 28 \text{ H} \times 110 \text{ D} \text{ mm}$ (Excluding protrusions
Weight	One-touch type: Approx. 310 g
	Screw soldering type: Approx. 650 g
Standard Accessories	DC power cable P-76, ground wire P-72, wire connection seals, rubber feet, screwdriver (For one-touch type only), terminal block (For screw soldering type only), control software (NTB-10A), instruction manual (CD-R)
Optional Accessories	Y cable N-103 (10 cm) Communication cable N-102 (1 m) Communication cable H-11681 (3 m) Communication cable H-11682 (5 m) Communication cable H-11683 (10 m) **Please contact us for communication cables other than those listed above. AC adapter SA-10A-EDS (100 to 240 VAC) (For U.S.A.: UNI318-1215-EDS) Connection board/clip CN-1A DIN rail mounting plate Terminal resistor CANTERM120 USB/CAN converter LEAFLIGHT HS V2

NTB-201A Specifications

Channels	4
Scanning Speed	Approx. 0.5 s/channel
Measuring Targets	Voltage, thermocouples

Voltage-output Measurement

	Range	Measuring range	Resolution	Accuracy	Input resistance
	10 V 0 to ±10.0000 V 50 V 0 to ±50.000 V		100 μV	±(0.1% of reading+0.0003 V)	Approx. 1 MΩ
			1 mV	±(0.1% of reading+0.003 V)	Approx. 1 MΩ

Thermocouples

Range	Accuracy (Resolution: 0.1 °C)		
-200.0 to	-200.0 to below -100°C	±(0.2% of reading +0.3°C)	
1230.0°C	-100.0 to 1230.0°C	±(0.1% of reading +0.2°C)	
-200.0 to -200.0 to below -100		±(0.2% of reading +0.3°C)	
400.0°C -100.0 to 400.0°C		±(0.1% of reading +0.2°C)	
-200.0 to	-200.0 to below -100°C	±(0.2% of reading +0.3°C)	
660.0°C	-100.0 to 660.0°C	±(0.1% of reading +0.2°C)	
-200.0 to	-200.0 to below -100°C	±(0.2% of reading +0.3°C)	
870.0°C	-100.0 to 870.0°C	±(0.1% of reading +0.2°C)	
0.0 to	0.0 to below 100°C	±(0.2% of reading +0.8°C)	
1760.0°C	+100.0 to 1760.0°C	±(0.125% of reading +0.6°C)	
-200.0 to	-200.0 to below -100°C	±(0.2% of reading +0.3°C)	
1300.0°C	-100.0 to 1300.0°C	±(0.1% of reading +0.2°C)	
	-200.0 to 1230.0°C -200.0 to 400.0°C -200.0 to 660.0°C -200.0 to 870.0°C 0.0 to 1760.0°C -200.0 to	-200.0 to	

* Accuracy of Internal Reference-junction Compensator Within ±0.5 °C, when temperature balanced at input terminals, and the ambient temperature is 0 to 50 °C. Within ±1.0 °C, when temperature balanced at input terminals, and

the ambient temperature is -10 to 0 °C.

Notes:

- 1. Accuracies do not include the accuracies of the internal reference junction compensator and the sensors.
- 2. The reference junction compensator is switchable between internal and external.
- 3. The thermocouple resistance should be 1 $k\Omega$ or less

5. The trembedaple resistance should be 1 kgz of less.				
Check Functions	Burnout check			
Power Save Mode	Provided ON/OFF using "OPT.3" DIP switch.			
Interfaces	Dedicated interface conforming to CAN.			
Operating Temperatu	ure -10 to 50°C			
Operating Humidity	20 to 85% (Non-condensing)			
Power Supply	11 to 16 VDC			
Current Consumption	Operation: 100 mA or less			
(At 12 VDC)	Waitng: 100 mA or less			
	Standby (In power save mode): 40 mA or less			
Dimensions	150 W \times 28 H \times 55 D mm (Excluding protrusions)			
Weight	Approx. 320 g			

Note: TEDS function is unusable.

Standard Accessories DC power cable P-76

Ground wire P-72

NTB power supply box NTB-20A NTB relay box NTB-21A

The power supply line and CAN communications line are integrated into one wire, enabling decentralized arrangement outdoors or in other locations where securing a power supply is difficult.

•NTB power supply box NTB-20A

■Power save function (AUTO mode)

When the PC power supply is OFF, then the power supply of the NTB-20A connected by a USB cable is off.

■Power supply output limitation function

When a power supply exceeding the power supply range for operating the NTB-20A is input, for safety, the power supply output from the serial connector and the OUT connector is turned OFF.

●NTB Series Connected Units and Cable Length

With USB port

NTB series connected units	Cable length
1	200 m or less
2	100 m or less

When AC adapter or DC power supply used

NTB series connected units	Cable length		
1	1000 m or less		_
2	840 m or less	nsed	When SA-10A-EDS used
3	560 m or less		S
4	470 m or less	-12	
5	330 m or less	When UIA345-12	≰
6	280 m or less	A3	9
7	240 m or less	5	S.
8	200 m or less	Je l	en
9	180 m or less	⋛	된
10	160 m or less		
11	150 m or less		
12	130 m or less		
13	120 m or less		
14	120 m or less		
15	110 m or less		
16	100 m or less	,	<u> </u>

Power Save Functions	Provided
	In POWER switch "AUTO" mode (*1)
Operating Temperature	e -10 to 50°C
Operating Humidity	20 to 85% (Non-condensing)
Power Supply Input	USB port: 5 VDC
	External power supply: 11 to 16 VDC
	(AC adapter, DC power supply)
Current Consumption	When using 12 VDC (Using AC adapter)
	OFF mode: 7.0 mA or less
	AUTO mode: 7.0 mA
	ON mode: 30.0 mA or less
	When using 5 VDC (Using USB port)
	OFF mode: 5.0 mA or less
	AUTO mode: 30.0 mA or less
	ON mode: 30.0 mA or less
Dimensions	150 W \times 28 H \times 55 D mm (Excluding protrusions)
Weight	Approx. 260 g
·	· · · · · · · · · · · · · · · · · · ·

(*1) In "AUTO" mode, turning off the PC power supply automatically turns OFF the power supply to the NTB-20A (NTB power supply box). When using "AUTO" mode, ensure that the PC and NTB-20A (NTB power supply box) are connected using a USB cable.

Optional Accessories Connection cable N-38 (1 m), N-39 (2 m) Communication cable N-102 (1 m) Communication cable H-11681 (3 m) Communication cable H-11682 (5 m) Communication cable H-11683 (10 m)

•NTB relay box NTB-21A

■Power supply output limitation function

When power supply exceeding the range is input into NTB, the power supply output from the serial connector is turned to OFF.

Input Voltage Range	11 to 16 VDC
Operating Temperature	-10 to 50°C
Operating Humidity	20 to 85% (Non-condensing)
Dimensions	$150 \text{ W} \times 28 \text{ H} \times 29 \text{ D} \text{ mm}$ (Excluding protrusions)
Weight	Approx. 160 g

Optional Accessories Power and communication cable N-114




●Network terminal box control software NTB-10A


Operating Environmer	nt
OS	Windows® 8/8.1, Windows® 10
	Japanese/English, 32/64 bits support
CPU	Core 2 Duo, 2 GHz or advanced
Memory	If 32-bit OS, 2 GB or more
	If 64-bit OS, 4 GB or more
Hard Disk	Empty storage 10 MB or more
	(Excluding the target data file size.)
Display	1024×768 pixels or more
USB/CAN Converter	r Manufacture: KVASER
	Model: LEAFLIGHT HS V2
Measuring Units	NTB series: 1 to 99 (Max. 396 channels)
Measuring Functions	RELATIVE measurement (Relative value
	measurement): Each value is obtained by
	subtracting the ZERO value.
	*ZERO value is equivalent to the initial unbalance
	value. Capable of obtaining the ZERO value at
	arbitrary timig.
Channels Conditions	Meas channel ON/OFF, CAL coefficient calculation
	ON/OFF, CAL coefficient, Offset, Unit, Dec. digits,
	resistance at 0°C, CH Name (20 characters)
Measuring Condition File	Load and save

Measuring Operations	MONITOR Meas (Measures ZERO value during
	MONITOR measurement.)
	One-time measurement
	Continuous measurements
	INTERVAL Meas (To be specified the number of
	measurements)
Interval Measurement	Interval start time
	Interval time
	Repeat 0 to 9999 (0 to infinite)
	Interval measuring steps: 5
Numeric Display	Available windows: 1
	Window switch: List only
Graph Display	Y-time, BAR graph
	Max. 8 channels/graph
Measured Data Saving Function	The measured data is saved with the CSV format.
TEDS	Reads sensor's information and sets to channel
	condition automatically.
	Channel name writing
Data File Destination	PC hard disk
File Split	No split
	Split every hour
	Split every day


Dimensions




NTB-101A-120



Case A 4-NTB docked connection (*Up to 8 units are possible)




Case B 4-NTB distributed connection (*Up to 99 units are possible)



Case C If u

If using an NTB power supply (NTB-20A) and NTB relay boxes (NTB-21A) for dispersed usage

(The diagram below uses 4 units, and the cable length will differ depending on the connected units. See table on page 3-46.)



*If power and communication cable is other than 50 m in length, please contact us.

NTB-10A is installed



SME-30A/31A/100A/101A

Handy Data Logger



Compact & lightweight Palm size, therefore easily to carry

- Built-in bridge circuit for direct connection of a strain gage
- ●Wide measuring range: ±300 k ×10⁻⁶ strain
- Data saved in a CSV file in SD card is read and controlled by a PC.
- Driven by AA batteries (Easy to get)
- TEDS compatible (Not only reading, but also writing possible)

No time waiting for measuring after power on. The strap is useful for field inspection and for confirming proper sensor installation.

The SD card (option) simplifies data transmission to PC. Using the attached input cable, a strain gage is easily connected.

The SME-100A/101A measures data of up to 33 channels by connecting the NTB-100/200 series.



Function Models	Channels	AC adapter compatible	NTB-100/200 series connection
SME-30A	1		
SME-31A	ı	Yes	
SME-100A	1		Yes
SME-101A	Max. 33	Yes	res

SME-30A/31A/100A/101A Specifications

	1 (when using s	ingle SME)
		els by connecting the NTB.
		els (SME-100A/101A+ 32 channels
	of the NTB)	
Sampling Period	Approx. 0.5 s: 0	to $\pm 30 \text{ k} \times 10^{-6} \text{ strain}$
		0 k ×10 ⁻⁶ strain or more
		l engineering transducers with
		nermal sensor
Measuring Function		ement (Relative value measurement):
		nined by subtracting the ZERO value.
		uivalent to the initial unbalance value.
Arithmetic Operation		ining the ZERO value at arbitrary timing
Measuring Targets		ain-gage transducers,
wicasaring largets		g transducers with a thermal sensor
	Bridge systems	Compatible gage resistance
	Quarter bridge	120, 240, and 350 Ω
	Half/full bridge	120 to 1000 Ω
Bridge Excitation	Constant-voltag	ge bridge excitation: Approx. 2 VDC
	Constant-currer	nt bridge excitation: Approx. 5.6 mA
	(Bridge resistan	
Measuring Range	At strain measu	
		onstant-voltage bridge excitation)
		onstant-current bridge excitation)
		rature with civil engineering
		al sensor: -30.0 to 70.0°C
	n measurement 0 k ×10 ⁻⁶ strain: 1 >	v10-6 ctrain
	$0 \pm 300 \text{ k} \times 10^{-6} \text{ strains}$	
		rature with civil engineering
	icer with a therma	
Accuracy (With Full		
At full b	oridge strain measu	ırement
		05% of reading $+2)\times10^{-6}$ strain
		$\pm (0.1\% \text{ of reading } + 20) \times 10^{-6} \text{ strain}$
		ature with civil engineering
transdu		
		al sensor: ± 0.5°C
Check Functions In	sulation resistance	al sensor: \pm 0.5°C measurement: 2 M to 100 M Ω
Check Functions In	sulation resistance esistance measure	al sensor: \pm 0.5°C measurement: 2 M to 100 M Ω ment: 0 to 20 k Ω
Check Functions In	sulation resistance esistance measure ent 1 min to 99	al sensor: \pm 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 k Ω n 59 min in 1 min steps
Check Functions Ir Re Interval Measureme	esistance measure ent 1 min to 99 Starting time	al sensor: \pm 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 k Ω n 59 min in 1 min steps e: year/month/day/hour/minute
Check Functions In Re Interval Measureme	esistance measure ent 1 min to 99 Starting time SD card (Op	al sensor: \pm 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 k Ω in 59 min in 1 min steps e: year/month/day/hour/minute cion)
Check Functions Ir Re Interval Measureme	isulation resistance esistance measure ent 1 min to 99 Starting time SD card (Opi 256 MB, 512	al sensor: \pm 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 k Ω in 59 min in 1 min steps e: year/month/day/hour/minute cion) E MB, 1 GB, 2 GB (FAT16)
Check Functions In Re Interval Measureme	isulation resistance esistance measure ent 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and S	al sensor: \pm 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 k Ω in 59 min in 1 min steps e: year/month/day/hour/minute cion)
Check Functions In Runterval Measurement Storage Applicable Cards	sulation resistance esistance measure ent 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and S	al sensor: \pm 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 k Ω in 59 min in 1 min steps e: year/month/day/hour/minute cion) PMB, 1 GB, 2 GB (FAT16) DXC not supported)
Check Functions In R Interval Measureme Storage Applicable Cards Display	sulation resistance esistance measure ent 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and S	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cion) e MB, 1 GB, 2 GB (FAT16) DXC not supported) ne LCD, 128 × 64 nation from TEDS-installed sensors.
Check Functions In Relative Interval Measurement Storage Applicable Cards Display TEDS	sulation resistance esistance measure ent 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and S Monochrom Reads inform Channel nar (Kyowa ID o	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cion) e MB, 1 GB, 2 GB (FAT16) DXC not supported) ne LCD, 128 × 64 nation from TEDS-installed sensors.
Check Functions In Relatives Interval Measurement Storage Applicable Cards Display TEDS Operating Tempera	sulation resistance esistance measure ent 1 min to 99 Starting time SD card (Opt 256 MB, 512 (SDHC and S Monochrom Reads inform Channel nar (Kyowa ID o	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute tion) e MB, 1 GB, 2 GB (FAT16) DXC not supported) te LCD, 128 × 64 nation from TEDS-installed sensors. The writing only in up to 10)
Check Functions In Reconstructions In Reconstruction Interval Measurement Storage Applicable Cards Display TEDS Operating Tempera Operating Humidity	sulation resistance esistance measure ent 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and S Monochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute tion) e MB, 1 GB, 2 GB (FAT16) DXC not supported) the LCD, 128 × 64 mation from TEDS-installed sensors. The writing only in up to 10) Non-condensing)
Check Functions In Relative Storage Applicable Cards Display TEDS Operating Tempera Operating Humidity Power Supply 2 /	sulation resistance esistance measure ent 1 min to 99 Starting time SD card (Opt 256 MB, 512 (SDHC and S Monochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C 20 to 85% (I AA alkaline batteria	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute tion) e MB, 1 GB, 2 GB (FAT16) DXC not supported) te LCD, 128 × 64 nation from TEDS-installed sensors. The writing only in up to 10) Non-condensing)
Check Functions In Reconstructions In Reconstructions In Reconstruction Interval Measurement	sulation resistance esistance measure ent 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and S Monochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C 20 to 85% (I AA alkaline batterionsecutive Operatio	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute tion) e MB, 1 GB, 2 GB (FAT16) DXC not supported) the LCD, 128 × 64 mation from TEDS-installed sensors. The writing only in up to 10) Non-condensing) the condensing of the condension of the condens
Check Functions In Recognition	sulation resistance esistance measure esistance measure starting time SD card (Opi 256 MB, 512 (SDHC and S Monochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C // 20 to 85% (I AA alkaline batterionsecutive Operatio //ith alkaline batter	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) e MB, 1 GB, 2 GB (FAT16) DXC not supported) the LCD, 128 × 64 nation from TEDS-installed sensors. The writing only in up to 10) Non-condensing) es on Time Approx. 10 h tesis
Check Functions In Reconstructions In Reconstructions In Reconstruction Interval Measurement	sulation resistance esistance measure esistance measure that 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and S Monochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C (20 to 85% (IAA alkaline batterinsecutive Operation) in the substitute of th	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cion) e MB, 1 GB, 2 GB (FAT16) DXC not supported) ne LCD, 128 × 64 nation from TEDS-installed sensors. ne writing nly in up to 10) Non-condensing) es con Time Approx. 10 h ies) e batteries are also used.
Check Functions In Richard Measurement Storage Applicable Cards Display TEDS Operating Tempera Operating Humidity Power Supply 2 / (W	sulation resistance esistance measure esistance measure and 1 min to 99 starting time. SD card (Opi 256 MB, 512 (SDHC and SMonochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C 20 to 85% (I AA alkaline batterionsecutive Operation and Channel natelickel metal hydridin AC adapter (Option 1 minutes).	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) e MB, 1 GB, 2 GB (FAT16) DXC not supported) the LCD, 128 × 64 nation from TEDS-installed sensors. The writing only in up to 10) Non-condensing) es on Time Approx. 10 h tesis
Check Functions In Richard Measurement Storage Applicable Cards Display TEDS Operating Tempera Operating Humidity Power Supply 2 / Company	sulation resistance esistance measure esistance measure esistance measure ent 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and SMOnochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C / 20 to 85% (If AA alkaline batterio/ith alkaline batterio/ith alkaline batteriickel metal hydridin AC adapter (Opi ME-31A/101A.	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) 2 MB, 1 GB, 2 GB (FAT16) DXC not supported) ne LCD, 128 × 64 nation from TEDS-installed sensors. ne writing nly in up to 10) Non-condensing) es on Time Approx. 10 h ies) e batteries are also used. cional, SW-0522E) is provided for
Check Functions In Richard Measurement Storage Applicable Cards Display TEDS Operating Temperating Humidity Power Supply 2 / Company	sulation resistance esistance measure esistance measure esistance measure ent 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and SMOnochrom Reads inform Channel nare (Kyowa ID o ture -10 to 50°C / 20 to 85% (I AA alkaline batterio insecutive Operatio //ith alkaline batteriickel metal hydridin AC adapter (Opi ME-31A/101A. wer is automatical	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) 2 MB, 1 GB, 2 GB (FAT16) DXC not supported) ne LCD, 128 × 64 nation from TEDS-installed sensors. ne writing nly in up to 10) Non-condensing) es on Time Approx. 10 h ies) ne batteries are also used. citonal, SW-0522E) is provided for
Check Functions In Richard Measurement Storage Applicable Cards Display TEDS Operating Temperating Humidity Power Supply 2 / Company	sulation resistance esistance measure esistance measure esistance measure ent 1 min to 99 starting time SD card (Opi 256 MB, 512 (SDHC and SMOnochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C / 20 to 85% (IAA alkaline batterionsecutive Operationsecutive Operationsecutiv	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) 2 MB, 1 GB, 2 GB (FAT16) DXC not supported) ne LCD, 128 × 64 nation from TEDS-installed sensors. ne writing nly in up to 10) Non-condensing) es on Time Approx. 10 h ies) e batteries are also used. cional, SW-0522E) is provided for
Check Functions In Relatives Interval Measurement Storage Applicable Cards Display TEDS Operating Temperal Operating Humidity Power Supply 2 / Company	sulation resistance esistance measure esistance measure esistance measure ent 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and SM Onochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C / 20 to 85% (IAA alkaline batterionsecutive Operatio/Irth alkaline batteriickel metal hydridin AC adapter (Opi ME-31A/101A. wer is automatical tected for 5 minut th an interval of 3	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) 2 MB, 1 GB, 2 GB (FAT16) DXC not supported) ne LCD, 128 × 64 nation from TEDS-installed sensors. ne writing nly in up to 10) Non-condensing) ness no Time Approx. 10 h ies) ne batteries are also used. citional, SW-0522E) is provided for ly turned off if no key operation is es. In interval measuring mode
Check Functions In Relatives Interval Measurement Storage Applicable Cards Display TEDS Operating Tempera Operating Humidity Power Supply 2 / Co. (W. *N. *A. *A. *A. *A. *A. *A. *A. *A. *A. *A	sulation resistance esistance measure esistance measure esistance measure and 1 min to 99 Starting time SD card (Opt 256 MB, 512 (SDHC and S Monochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C / 20 to 85% (ID A alkaline batterionsecutive Operation AC adapter (Opt ME-31A/101A). Wer is automatical tected for 5 minut th an interval of 3 tomatically turned	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) 2 MB, 1 GB, 2 GB (FAT16) DXC not supported) the LCD, 128 × 64 nation from TEDS-installed sensors. The writing nly in up to 10) Non-condensing) the batteries are also used. citional, SW-0522E) is provided for ly turned off if no key operation is the ses. In interval measuring mode minutes or longer, power is
Check Functions In Reconstructions In Reconstructions In Reconstructions In Reconstruction Interval Measurement In	sulation resistance esistance measure esistance measure esistance measure and 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and S Monochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C 20 to 85% (I AA alkaline batterion secutive Operation AC adapter (Opi ME-31A/101A. weer is automatical tected for 5 minut th an interval of 3 tomatically turned on again 1 m started. (ON/OFF of started.)	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) E MB, 1 GB, 2 GB (FAT16) DXC not supported) the LCD, 128 × 64 mation from TEDS-installed sensors. The writing maty in up to 10) Non-condensing) the session Time Approx. 10 h ties) the batteries are also used. The session is provided for Ly turned off if no key operation is the session of the power of the next measurement of Auto Power Off is settable.)
Check Functions In Recognition	sulation resistance esistance measure esistance measure esistance measure and 1 min to 99 Starting time SD card (Opi 256 MB, 512 (SDHC and S Monochrom Reads inform Channel nar (Kyowa ID o ture -10 to 50°C 20 to 85% (IPA alkaline batterion secutive Operation Ac adapter (Opi ME-31A/101A. wer is automatically turned than interval of 3 tomatically turned red on again 1 m started. (ON/OFF of 8 W × 41 H × 108.	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cion) E MB, 1 GB, 2 GB (FAT16) DXC not supported) the LCD, 128 × 64 mation from TEDS-installed sensors. The writing maty in up to 10) Non-condensing) the session Time Approx. 10 h ties) the batteries are also used. The session interval measuring mode minutes or longer, power is Loff during standby period and inute before the next measurement of Auto Power Off is settable.) The session interval mestarement of Auto Power Off is settable.)
Check Functions In Richard Measurement Storage Applicable Cards Display TEDS Operating Tempera Operating Humidity Power Supply 2 / Company	sulation resistance esistance measure esistance es	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) E MB, 1 GB, 2 GB (FAT16) DXC not supported) the LCD, 128 × 64 mation from TEDS-installed sensors. The writing maty in up to 10) Non-condensing) the session Time Approx. 10 h ties) the batteries are also used. The citional, SW-0522E) is provided for the session interval measuring mode minutes or longer, power is the off during standby period and inture before the next measurement of Auto Power Off is settable.) The Day of the settable of the during standby period and inture before the next measurement of Auto Power Off is settable.) The Day of the settable of the during batteries of the during protrusions of the settable of the during batteries.
Check Functions In Richard Measurement Storage Applicable Cards Display TEDS Operating Tempera Operating Humidity Power Supply 2 / Compliance Display Storage Auto Power Off Power Supply Storage Auto Power Off Power Supply Storage Storag	sulation resistance esistance measure esistance esistanc	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) 2 MB, 1 GB, 2 GB (FAT16) DXC not supported) ne LCD, 128 × 64 nation from TEDS-installed sensors. The writing nly in up to 10) Non-condensing) es on Time Approx. 10 h ties) a batteries are also used. citional, SW-0522E) is provided for ly turned off if no key operation is es. In interval measuring mode minutes or longer, power is off during standby period and intute before the next measurement of Auto Power Off is settable.) 4 D mm (Excluding protrusions) ding batteries) U (EMC)
Check Functions In Richard Measurement Storage Applicable Cards Display TEDS Operating Tempera Operating Humidity Power Supply 2 / Compliance Dimensions 18 Weight Ag Compliance Dimensions In Richard Measurement Power Offer Richard Measurement Power Of	sulation resistance esistance measure esistance es	al sensor: ± 0.5°C e measurement: 2 M to 100 M Ω ment: 0 to 20 kΩ n 59 min in 1 min steps e: year/month/day/hour/minute cition) 2 MB, 1 GB, 2 GB (FAT16) DXC not supported) ne LCD, 128 × 64 nation from TEDS-installed sensors. ne writing nly in up to 10) Non-condensing) es on Time Approx. 10 h ies) e batteries are also used. citional, SW-0522E) is provided for ly turned off if no key operation is es. In interval measuring mode minutes or longer, power is off during standby period and intute before the next measurement of Auto Power Off is settable.) 4 D mm (Excluding protrusions) ding batteries) U (EMC) U, (EU)2015/863

Standard Accessories Input cable U-119

AA alkaline battery × 2 Shoulder belt

Hand strap

Instruction manual (CD-R)

Communication cable N-102 (SME-100A/101A) AC adapter SW-0522E (For SME-31A/101A) Temperature measuring adapter for SME SMET-1A

Optional Accessories

3-49

SMET-1A Specifications

Measuring Targets	Thermocouples (K, T)
Channels	1	
Sampling Frequencies	Approx. 0.5 s	
Input	Terminal block	
	Applicable wires	Solid wire: UL AWG14 to 28
		Twisted wire: LIL AWG20 to 24

Measuring Range, Accuracy, Resolution

Types	Measuring range	Resolution	Acc	curacy	Accuracy of internal reference junction compensator (25 ±10°C)
К	-200.0 to		-200.0 to below -100.0°C	±(0.2% of specified value + 0.6)°C	±2.0 °C
K	1230.0°C		-100.0 to 1230.0°C	±(0.1% of specified value + 0.4)°C	±1.0 °C
+	-200.0 to	0.1°C	-200.0 to below -100.0°C	±(0.2% of specified value + 0.6)°C	±2.0 °C
T	400.0°C		-100.0 to 400.0°C	±(0.1% of specified value + 0.4)°C	±1.0°C

Notes: 1. Accuracy does not include the accuracy of the sensor.

- For the standard junction compensator, switching between internal and external is possible using the SME.
 Thermocouple resistance is 1 kΩ or less.


Check Functions	Burnout check (By operation of SME)
Operating Temperature	e -10 to 50°C
Operating Humidity	20 to 85% (Non-condensing)
Dimensions	42 W × 33 H ×29.5 D mm (Excluding protrusions)
Weight	Approx. 35 g
Compliance	Directive 2014/30/EU (EMC)
	Directive 2011/65/EU, (EU)2015/863
	(10 restricted substances) (RoHS)


Standard Accessories Mounting screw×2

Instruction manual (CD-R)



■Dimensions





SME-30A/31A/100A/101A (SME-31A/100A/101A is the same in dimensions.)

RMH-301B

Digital Strain Recorder





Suitable for long-term measurement in the absence of personnel under the environment without external power supply

- •Small & lightweight
- Equipped with a display used to confirm setting conditions and measured values
- Easy to collect data by USB memory


RMH-301B is a battery-powered data collection device with low power consumption, suitable for long-term measurement in the absence of personnel at the places without external power supply such as long-distance mountainous and heavy-snowfall area.

Enables to strain-gage civil engineering transducers and civil engineering transducers with a thermal sensor and of single-channel measurement.

Equipped with operation panel and display enables operation relating to measuring condition setting and measurement.

The optional software (RMH-390A) can be used to control and collect data via USB interface.

Dimensions



Hardware Channels	1	
		acduseurs.
Applicable Transducers		
		engineering transducers
Compatible Bridge Res		ransducer with a thermal sensor
	Max. 2.0 km	-uii-briage system)
Cable Length) F mama?) shiplidad sabla)
		0.5 mm²) shielded cable)
Gage Factor	2.00 fixed	A D C (C
Bridge Current		A DC (Constant current)
Temperature Measurer		1.55/5
		A DC (Constant current)
Measuring Range	Strain:	±20000 ×10 ⁻⁶ strain
	Temperature:	-30.0 to 70.0°C
Resolution	Strain:	1 ×10 ⁻⁶ strain
	Temperature:	0.1°C
Measuring Accuracy	Strain:	±0.1%FS
	Temperature:	±0.5°C
Data Storage	Strain:	30720 times
	Temperature:	30720 times
		ature: 20475 times
Clock		the Gregorian calendar),
	month, date, ho	
Measuring Interval	1 to 59 minutes	(1 minute/step)
	1 to 99 hours (1	hour/step)
Display	LCD (16 digits×2	2 lines)
Operation	Arrow keys, ON	/OFF, SET, ESC
Interface	USB1.1*	
Power Supply	6 to 15 VDC, op	tional battery pack
Current Consumption		n: 100 mA or less
•	Standby status:	
Input Specifications	Bolt (M3)	
		s-fitted terminal: RAV, 1.25-3 or
		equivalent
Operating Temperatur	e -20 to 50°C (0 t	to 50°C for data collection)
Operating Humidity	10 to 95% (Nor	
		ductive noise of a bulk motor
<u>- 1</u>	must not be p	
Dimensions		66.5 D mm (Excluding protrusion
Weight	Approx. 180 g	zo.s z (zziciaa.i.g protrasio.i
		l Accessories)
	3307 (Optiona	
	Windows Vista®	(32 hits, Jananese version)
os		(32 bits, <u>Japanese version</u>)
	USB Interface (R	MH-301B)
os	USB Interface (R CD-ROM or DVI	MH-301B) D
OS Interface	USB Interface (R CD-ROM or DVI (For software in:	MH-301B) D stallation)
OS Interface CPU	USB Interface (R CD-ROM or DVI (For software in: PentiumIII, 1 GH	MH-301B) D stallation) Hz or advanced
OS Interface CPU Memory Required	USB Interface (R CD-ROM or DVI (For software in: PentiumIII, 1 GH RAM 512 MB or	MH-301B) O stallation) Hz or advanced r more
OS Interface CPU	USB Interface (R CD-ROM or DVI (For software in: PentiumIII, 1 GH RAM 512 MB or Hard disk capac	MH-301B) contained by the stallation of the sta
OS Interface CPU Memory Required	USB Interface (R CD-ROM or DVI (For software in: PentiumIII, 1 GH RAM 512 MB or Hard disk capac (For installation	MH-301B) cstallation) Hz or advanced more city: 20 MB or more n, excluding that for data)
OS Interface CPU Memory Required	USB Interface (R CD-ROM or DVI (For software in: Pentium I , 1 GH RAM 512 MB or Hard disk capac (For installation Spare capacity:	MH-301B) cstallation) Hz or advanced r more city: 20 MB or more a, excluding that for data) 10 MB or more
OS Interface CPU Memory Required Hard Disk	USB Interface (R CD-ROM or DVI (For software in: Pentium I , 1 GH RAM 512 MB or Hard disk capac (For installation Spare capacity: (Excluding that	MH-301B) obstallation) Hz or advanced r more city: 20 MB or more a, excluding that for data) 10 MB or more for saving measuring data)
OS Interface CPU Memory Required	USB Interface (R CD-ROM or DVI (For software in: Pentium I , 1 GH RAM 512 MB or Hard disk capac (For installation Spare capacity: (Excluding that High resolution	MH-301B) cstallation) Hz or advanced more city: 20 MB or more a, excluding that for data) 10 MB or more for saving measuring data) video (Super VGA):
OS Interface CPU Memory Required Hard Disk	USB Interface (R CD-ROM or DVI (For software in: Pentium I , 1 GH RAM 512 MB or Hard disk capac (For installation Spare capacity: (Excluding that High resolution 800 × 600 or mo	MH-301B) cstallation) Hz or advanced more city: 20 MB or more a, excluding that for data) 10 MB or more for saving measuring data) video (Super VGA):
CPU Memory Required Hard Disk	USB Interface (R CD-ROM or DVI (For software in: Pentium I , 1 GH RAM 512 MB or Hard disk capac (For installation Spare capacity: (Excluding that High resolution 800 × 600 or mo	MH-301B) cstallation) Hz or advanced more city: 20 MB or more a, excluding that for data) 10 MB or more for saving measuring data) video (Super VGA): ore conitor: 1024 x768
OS Interface CPU Memory Required Hard Disk	USB Interface (R CD-ROM or DVI (For software in: PentiumIII, 1 GI- RAM 512 MB or Hard disk capac (For installation Spare capacity: (Excluding that High resolution 800 × 600 or mo Adapter and mo Full-color or mo	MH-301B) cstallation) Hz or advanced more city: 20 MB or more a, excluding that for data) 10 MB or more for saving measuring data) video (Super VGA): cre conitor: 1024 ×768 re
OS Interface CPU Memory Required Hard Disk	USB Interface (R CD-ROM or DVI (For software in: PentiumIII, 1 GI- RAM 512 MB or Hard disk capac (For installation Spare capacity: (Excluding that High resolution 800 × 600 or mo Adapter and mo Full-color or mo	MH-301B) cstallation) Hz or advanced more city: 20 MB or more a, excluding that for data) 10 MB or more for saving measuring data) video (Super VGA): ore contor: 1024 x768

Collects data by USB memory.

Optional Accessories USB cable N-38 (1 m), N-39 (2 m) Battery Pack RB-5A (5 Ah), RB-10A (10 Ah) Control Software RMH-390A

* Some models of USB memory may not collect data correctly.

For recommended models, please contact us.

* Control Software RMH-390A is Japanese version only.



RMH-310A

Digital Strain Recorder




Suitable for long-term measurement in the absence of personnel under the environment without external power supply

- Display is provided to enable confirmation of setting conditions and measured values.
- Data can easily be collected in USB memory.
- No control software required. Keys are provided for operation as an independent unit.
- •Measurement with thermocouples possible (K, T)

RMH-310A is a battery-operated digital strain recorder featuring low power consumption. Thus, it is suitable for unattended long-term measurement in remote places, mountainous regions and heavy snowfall districts where no power supply is available. This 10-channel recorder can connect to straingage civil engineering transducers, civil engineering transducers with temperature measuring function and thermocouples. The operating panel and display enable the user to set measuring conditions and perform measurement-related operation.

Dimensions



Collects data by USB memory.

Specifications

pecifications	
Channels	10
Applicable Transducers	Strain-gage civil engineering transducers
	Civil engineering transducer with a thermal sensor
	Strain-gage transducers
	Thermocouples (Types K and T)
Compatible Bridge	Resistance 350 Ω (Full-bridge system)
Cable Length	Max. 2.0 km (4-conductor (0.5 mm ²) shielded cable)
Gage Factor	2.00 fixed
Bridge Current	Approx. 2.19 mA DC (Constant current)
Measuring Range	Strain $\pm 20000 \times 10^{-6}$ strain
ivieasuring hange	
	Temperature (Civil engineering transducer with a
	thermal sensor) -30.0 to 70.0°C
	Temperature (Thermocouple) K:-200 to 1200 °C
	T: -200 to 350°C
Resolution	Strain 1 × 10 ⁻⁶ strain
	Temperature (Civil engineering transducer with a
	thermal sensor) 0.1°C
	Temperature (Thermocouple) 0.1°C
Accuracy	Strain ±0.1% FS
	Temperature (Civil engineering transducer with a
	thermal sensor) ±0.5°C
	Temperature (Thermocouple) (Reference value)
	±(0.1% of reading +1.0)°C
	Internal point-of-contact compensator: Within ±2.0°C
	(At the time of an input terminal temperature balance)
	Note: The accuracy of an internal reference
	point-of-contact compensator and accuracy
	of a thermocouple are not included in
	measurement accuracy.
Temperature Stability	Strain Zero point Within ±1 ×10 ⁻⁶ strain/°C
	Sensitivity Within ±0.02%/°C
	Temperature (Civil engineering transducer with a
	thermal sensor)
	Zero point Within ±0.025%FS/°C
	Sensitivity Within ±0.04%/°C
	Temperature (Thermocouple)
	Zero point Within ±0.025%FS/°C
	Sensitivity Within ±0.04%/°C
Measuring Time	Within 40 s/10 channels (Scanning)
	rement Current 0.24 mA DC (Constant current)
Data Storage	32000 times/channel
Clock	Year (2 digits of the Gregorian calendar),
	month, date, hour, and minute
Measuring Interval	1 to 59 minutes (1 minute/step)
	1 to 99 hours (1 hour/step)
Check Function	Sensor check (Parallel resistance method and
	during strain measurement)
	Battery voltage
	Memory check
Display	LCD (20 digits × 4 lines, with no back light)
Display	
Display Functions	The contents of the data below are displayed on LCD.
	Measurement state, current time, data acquisition,
	real-time monitor, measurement start, measurement
	stop, condition setting, self-check, date setting,
	backup data collection, and version display
Operation	Arrow keys, ON/OFF, SET, ESC
Interface	USB 2.0 (Only saved in USB memory)
Power Supply	6 to 15 VDC, optional battery pack
Current Consumption	During operation: 100 mA or less
p	Standby status: 100 µA at 6 VDC
Input Specifications	M3 terminals for both solder and screw
Number of Measu	
	7000 times or more (When measuring at intervals
	of 10 minutes at 23°C using the optional RB-10A
	battery pack [10 Ah])
Operating Tompar	
Operating Temper	
	-20 to 50°C (Varies depending on the operating
Omenstinan II III	temperature when using USB memory)
Operating Humidi	
Operating Environ	ment Dust or the inductive noise of a bulk motor
	must not be present.
Dimensions	170 W × 230 H × 60 D mm
	(Excluding protrusions)
Weight	2 kg or less (Excluding the battery)
Others	Lightning surge protector provided (SD4-75)
,	
	Battery cable (For battery pack other than RB-10A)
	USB memory for collection data (Industrial temperature range extended model)
	*Auxiliary tool, instruction manual, specifications, outside
	drawings are saved in the provided USB memory.
	Menu sheet
	D D DD E4 (E 41) DD 404 (40 41)

Optional Accessories Battery Pack RB-5A (5 Ah), RB-10A (10 Ah)



Data Recorders/Analyzers


Presently, strain/stress measuring instruments are required not only to enable stable measurement of microvolt signals in indoor and outdoor applications but also to provide data processing capability for compact portable packages. Furthermore, recent advancements in electronics and the trends in information-related fields toward multimedia and downsizing have generated diversified needs including:

- Simultaneous measurement of static or dynamic variables ranging from strain/stress to load, pressure, acceleration, displacement, torque, temperature and frequency using not only strain gages and transducers but also voltage-output sensors, thermocouples and pulse-output sensors
- Real-time monitoring to enable smooth measurement under the engineer's judgment and control


- Statistical processing and waveform analysis of variables under measurement for time and labor savings
- Unattended wireless operation

To cope with these demands, Kyowa has been making every effort to:


- •Diversify signal conditioners, develop multichannel signal conditioner systems and make the processing speed higher,
- •Downsize the instruments and systems,
- Add monitor functions,
- •Enable processing of data under measurement,
- Provide instruments and systems with various interfaces such as USB and LAN for operation under PC control,
- •Enable long-term data recording with various storage media such as hard disk and flash memory card.











Note: For LAN connection, use straight cables and a LAN hub.

CTRS-100 Series

Compact & Tough

Compact Recorder



Compact and tough data logger

- Modular type for easy expansion and up to 128 channels
 High installation and flexibility
 Shock resistance: 490 m/s² (50 G)
 All channels synchronous 20 kHz (For 4 channels)

- Measurement of 1 channel at max. 100 kHz (For strain or voltage measurement)

 Wireless real-time monitoring is possible (When using wireless LAN unit)
- •CAN FD compatible (When using CAN unit)

CTRS-100 Series is a compact, lightweight and impact-resistant construction, this can be applied to measurements of various stress in environments where exposed to vibrations and impact in limited spaces such as driving test of two-wheeled vehicles and on actual ships, and to measurements on table-tops.

Configuration





■Main Unit



Compact Recorder CTRS-100A

■Remote Controller



Remote Control Unit CTRS-RCU010A

■Battery



Battery Unit CTRS-BATT010A

■Measuring Units



Strain/Voltage Unit CTRS-CDV010A

Voltage Unit



Thermocouple Unit CTRS-CTA010A

■Expansion Units



CAN Unit CTRS-CAG010A

Wireless LAN Unit for U.S.* CTRS-WLAN011A *CTRS-WLAN010A for Japan



Synchronization Unit CTRS-SYNC010A

CTRS-100A Specifications

RS-100A Specific	cations
Control Unit Specific	cations
Connector	
USB Connector	Micro USB Type-B
Remote Control Co	onnector Used to connect the remote control unit
External I/O Conn	ector Model: ECA.0B.307.CLN
	Compatible connector: FGA.0B.307.CLAD52
Operating Switch	POWER
Main Unit Display	Status LED
Iviairi Offic Display	SD card access indicator LED
Data Dasardina Madi	
Data Recording Media	Kyowa recommended industrial-use SD card SD standards: SDHC
	Capacity: 4 GB, 16 GB
	Format: FAT32
	(Operation is not guaranteed if an SD card
	other than the recommended product is used.)
Communication Inte	<u> </u>
	Ethernet*1 (10/100BASE-T)
Number of Units tha	at Can Be Connected
Measuring Unit	Up to 7 units can be connected per CTRS-100A
	(Total of 32 channels)
Expansion Unit	Up to 5 units can be connected per CTRS-100A
1	However, 2 or more same units cannot be
	connected and used.
Synchronization bet	
Synchronization N	Method Use a synchronization unit and
	synchronous cable to connect
NA	CTRS-100As.
Maximum Numbe	er of Units that Can Be Synchronized
	The maximum is four CTRS-100As,
	and a maximum of 128 measurement channels
	can be synchronized.
Recorded Data	Data is recorded to each unit's SD card or a PC. *2
Recorded Data	
File Saving Locatio	n SD card
<u> </u>	PC*2
Data Format	Kyowa standard format KS3
Maximum Data Fil	la Siza // GR/1-data-fila
Maximum Data Fi	
	(1 GB = 1000000000 bytes) *3
Maximum Data Fi	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC
	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data
Data Collection	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC
Data Collection Measurement Condi	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method
Data Collection Measurement Condi Online Setting	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC)
Data Collection Measurement Condi	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition
Data Collection Measurement Condi Online Setting	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC)
Data Collection Measurement Condi Online Setting Offline Setting	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition
Data Collection Measurement Condi Online Setting Offline Setting	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording.
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In Trigger) Automatic recording is performed
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In Trigger) Automatic recording is performed based on the trigger condition setting.
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. Id Trigger) Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger of the trigger condition settings Automatic recording is performed based on the recording start time and recording interval
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. Id Trigger) Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the start of the trigger condition settings and the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings.
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. Id Trigger) Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. Id Trigger) Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k,
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2° series
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger of the trigger condition settings and the trigger condition setting. Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2° series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048,
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. Id Trigger) Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2 ⁿ series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. Id Trigger) Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2° series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set:
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method Frequency	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. Id Trigger) Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2" series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set: 100 kHz / number of measurement channels
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. Id Trigger) Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2** series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set: 100 kHz / number of measurement channels Clock input from an external device is used as
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method Frequency	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2" series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set: 100 kHz / number of measurement channels Clock input from an external device is used as the sampling clock.
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method Frequency	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2" series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set: 100 kHz / number of measurement channels Clock input from an external device is used as the sampling clock.
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method Frequency	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the trigger condition settings. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2° series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set: 100 kHz / number of measurement channels Clock input from an external device is used as the sampling clock. A frequency from 1 Hz to 100 kHz can be set in 1-Hz increments.
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method Frequency	(1 GB = 1000000000 bytes) ¹³ Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2" series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set: 100 kHz / number of measurement channels Clock input from an external device is used as the sampling clock. A frequency from 1 Hz to 100 kHz can be set in
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method Frequency	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition settings and the trigger condition settings. Automatic recording is performed based on the trigger condition settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2° series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set: 100 kHz / number of measurement channels Clock input from an external device is used as the sampling clock. A frequency from 1 Hz to 100 kHz can be set in 1-Hz increments. Input a clock within the range of the specified
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method Frequency	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2° series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set: 100 kHz / number of measurement channels Clock input from an external device is used as the sampling clock. A frequency from 1 Hz to 100 kHz can be set in 1-Hz increments. Input a clock within the range of the specified frequency ±5%.
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method Frequency	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2° series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set: 100 kHz / number of measurement channels Clock input from an external device is used as the sampling clock. A frequency from 1 Hz to 100 kHz can be set in 1-Hz increments. Input a clock within the range of the specified frequency ±5%. Voltage level: High-level voltage 2.4 to 5 V
Data Collection Measurement Condi Online Setting Offline Setting Recording Modes Manual Trigger (Compoun Interval Sampling Method Frequency	(1 GB = 1000000000 bytes) *3 Online collection: Collect by control software (PC) Offline collection: Collect by directly reading data from an SD card to the PC ition Setting Method Set by control software (PC) Set by reading the measurement-condition settings on the SD card The user performs operations to start or stop recording. In the trigger condition setting. Automatic recording is performed based on the trigger condition setting. Automatic recording is performed based on the recording start time and recording interval settings. Synchronous sampling of all channels 1-2-5 series 1, 2, 5, 10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k, 20k, 50k, 100k Hz 2° series 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096, 8192, 16384, 32768, 65536 Hz Maximum sampling frequency that can be set: 100 kHz / number of measurement channels Clock input from an external device is used as the sampling clock. A frequency from 1 Hz to 100 kHz can be set in 1-Hz increments. Input a clock within the range of the specified frequency ±5%.

Trigger Type	·Analog input signal (Analog trigger)
	·External trigger input signal
	(No-voltage contact, open collector, signal
	with high-level voltage 2.4 to 5 V and low-lev
	voltage 0 to 0.8 V)
	·Manual (If the REC button is pressed in the
	trigger awaiting state, recording starts.)
Trigger Level	Any level within the range of ±FS can be set.*
Trigger Slope	Slope (positive), slope (negative)
Pre-trigger	Specify the amount of data to save from befo
	the start trigger point.
	Any amount up to 524288 data items/the
	number of measurement channels can be set
Post-trigger	Specify the amount of data to save from after
	the end trigger point.
	Any amount up to 524288 data items/the
	number of measurement channels can be set
Backup Function	
Backup Target	Setting conditions, balance-adjustment value
	(Zero suppress value)
Saving Location	Internal nonvolatile memory
External Clock Outp	
Signal Level	5 VDC
J.g.i.a. 2010.	The inverted or non-inverted signal can be se
Division	A clock signal that is synchronized with the
DIVISION	sampling clock is divided and output.
	Any division ratio in the range from 1 to 6553
	can be set.
Output Modes	Select from always output the clock, only outp
Output Modes	
Other Eunstians	it while recording, or no output it.
Other Functions	<u> </u>
	he Number of Data Items to Record
	he Number of Data Items to Record When the specified number of data items is
Specification of the	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes.
Specification of the	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption 15
Specification of the	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption ^{*5} While recording, if the power supply is
Specification of the	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption '5 While recording, if the power supply is interrupted due to a power outage, etc.,
Specification of the	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption*5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery
Specification of the	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption*5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fil
Specification of the	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption '5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down.
Specification of the	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption*5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fil being recorded and then shut down. If the option to shut down is selected, you can
Specification of the	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption '5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fil being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the
Specification of the Automatic Recovery	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption '5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fil being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state.
Specification of the	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption 55 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state.
Specification of the Automatic Recovery	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption 55 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. ery Function You can select whether to resume recording of the standard or the power is restored or enter the standard or the s
Specification of the Automatic Recovery	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption*5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. ery Function You can select whether to resume recording of enter the standby state when the POWER
Specification of the Automatic Recovery	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption 55 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. ery Function You can select whether to resume recording of the standard or the power is restored or enter the standard or the s
Specification of the Automatic Recovery	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption*5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. ery Function You can select whether to resume recording of enter the standby state when the POWER
Specification of the Automatic Recovery	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption '5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. ery Function You can select whether to resume recording of enter the standby state when the POWER switch is turned off while recording and then turned back on.
Automatic Recove	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption "5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. ery Function You can select whether to resume recording or enter the standby state when the POWER switch is turned off while recording and then turned back on.
Automatic Recove	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption '5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. ery Function You can select whether to resume recording or enter the standby state when the POWER switch is turned off while recording and then turned back on. ment Automatically assign a file number or recording
Automatic Recove Recording Recove File Name Assign	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption '5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fil being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. ery Function You can select whether to resume recording or enter the standby state when the POWER switch is turned off while recording and then turned back on. ment Automatically assign a file number or recording date to the recorded-data file name.
Automatic Recove	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption *5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fil being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. ery Function You can select whether to resume recording or enter the standby state when the POWER switch is turned off while recording and then turned back on. ment Automatically assign a file number or recording date to the recorded-data file name.
Automatic Recove Recording Recove File Name Assign	the Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. The sery Function in Power Interruption Subtile recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. The subtile standby state when the POWER switch is turned off while recording and then turned back on. The subtile standby state when the POWER switch is turned off while recording and then turned back on. The subtile standby state when the recording and then turned to the recorded data file name. The subtile standby state is the subtile standby state of the recorded data file name.
Automatic Recove Recording Recove File Name Assign	he Number of Data Items to Record When the specified number of data items is recorded, recording automatically finishes. ery Function in Power Interruption *5 While recording, if the power supply is interrupted due to a power outage, etc., you can select whether to switch to battery power and continue recording or close the fill being recorded and then shut down. If the option to shut down is selected, you can select whether to resume recording after the power is restored or enter the standby state. ery Function You can select whether to resume recording of enter the standby state when the POWER switch is turned off while recording and then turned back on. ment Automatically assign a file number or recording date to the recorded-data file name.

■Measuring Unit Specifications			
Item		Strain Measurement	Voltage Measurement
Channels 4			
Input	Connector NDIS4109 (Small round 9 pins) receptacle Model: EPRC07-RX9FNDIS		pins) receptacle
Connector Compatible Plug		NDIS4109 (Small round 9 pins) plug Model: EPRC07-P9MNDIS	
Measuring Targets Strain gages*6 Strain-gage transducers Voltage		Voltage	
Compatible Bridge Resistance		When bridge excitation is set to 2 V 120 to 1000Ω When bridge excitation is set to 5 V 350 to 1000Ω	_
Gage Factor		2.00 fixed	
Bridge Excitation/ Sensor Excitation		2, 5 VDC	2, 5 VDC*7 OFF (0 V)
		A maximum of 20 mA per	channel can be output.





Input Imped	ance	_	3.6 MΩ±10 %
Input Modes		Balanced differential input	
	Setting Method	Any range method or OFF	
Measuring Range Range Setting Steps		Minimum: 1000×10^{-6} strain Maximum: 50000×10^{-6} strain	Minimum: 1 V Maximum: 50 V
	•1000 to 10000 × 10 ⁻⁶ strain 100 × 10 ⁻⁶ strain steps •10000 to 50000 × 10 ⁻⁶ strain 1000 × 10 ⁻⁶ strain steps	•1 to 10 V 0.1 V steps •10 to 50 V 1 V steps	
Range Accur	acy	Within ±0.2% FS	1 1 31003
Nonlinearity		Within ±0.1% FS	
Temperature Stability	Zero Point	Within ±(0.009% FS + 0.9 × 10 ⁻⁶ strain)/°C	Within ±(0.009% FS + 0.21 mV)/°C
Stability	Sensitivity	Within ±0.03%/°C	
Time Stability	Zero Point	Within ±(0.09% FS + 9 × 10 ⁻⁶ strain)/8 h	Within ±(0.09% FS + 0.1 mV)/8 h
Justiney	Sensitivity	Within ±0.3%/8 h	
Setting Balance Adjustment		measured value t OFF: Do not execute b NONE: Balance adjustme	adjustment and set the o zero. alance adjustment again
O _I M Ac M Ac Ra	Operating Method	Execute the balance operation by using the control software '2 or operate the special-remote-control BAL switch.	
	Adjustment Method	Auto balance (Saved in nonvolatile memory)	
	Adjustment Range	Within $\pm 10000 \times 10^{-6}$ strain	Within ±10 V
	Accuracy	Within \pm (0.1% FS + 2×10^{-6} strain)	Within ±0.1% FS
	NONE Accuracy	Within ±1% FS*8	Within ±0.2% FS
Input Range		Within $\pm 60000 \times 10^{-6}$ strain	Within ±60 V
Common-mode Input Voltage		_	Within ±20 V
Absolute Maximum Rating	Input	±5 V	±70 V
Frequency Response		DC to 20 kHz, -3 ± 1 dB (At	20 kHz)
	Transfer Characteristics	5th-order Butterworth	
LDE	Cutoff Frequency	10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k Hz as well as ${\rm FLAT}^{*9}, {\rm AUTO}^{*10}$	
LPF	Amplitude Ratio at Cutoff Point	-3±1 dB	
	Attenuation Characteristics	-30±3 dB/oct.*11	
HPF	Cutoff Frequency	0.2, 1 Hz and OFF	
AD	Resolution		
Conversion	Method	Synchronous sampling of a	all channels
Indicator		Channel-status LED	
Other	Input Resistance Check Functions	Bridge resistance check fur Accuracy within ±2% Used for sensor connection	
Functions	TEDS	Read the TEDS information	

■ General Specification	S
Power Connector	Model: ECP.1S.302.CLL
Power Supply	10 to 30 VDC
Power Consumption	Approx. 3.5 W (When supplying 12 VDC)
Operating Temperature	-10 to 50°C
Operating Humidity	20 to 90% (Non-condensing)
Storage Temperature	-20 to 60°C
Vibration Resistance	49.0 m/s ² (5 G), 5 to 200 Hz
Shock Resistance	490 m/s ² (50 G), 11 ms or less, half sine wave
Dimensions	53.2 W × 92 H × 94 D mm
	(Excluding protrusions or protectors)
Weight	Approx. 420 g
Terminal	GND terminal: M3 bind
Utility Nuts	Size: M4, 12 places

measurement conditions.*2

- * The measuring unit specifications apply to the state in which the temperature has stabilized after a preheating time of 30 minutes.
- *1 A separate synchronization unit and special communication cable are necessary.
- *2 Only when online control is performed by a PC
- *3 Maximum recording time depends on number of measurement channels and sampling frequency.
 - Maximum recording time: 1000000000 ÷ number of measurement channels ÷sampling frequency
- *4 Analog input signal only
- *5 Only when the battery unit is connected
- *6 A separate bridge box is necessary.
- *7 When the sensor excitation is 2 VDC, the positive side of the sensor excitation is +1 V and the negative side is -1 V. When the sensor excitation is 5 VDC, the positive side of the sensor excitation is $+2.5\,\mathrm{V}$ and the negative side is $-2.5\,\mathrm{V}$.
- *8 When the bridge resistance is 350 Ω
- *9 When FLAT is set, the cutoff frequency is set to approx. 25 kHz. However, the cutoff point amplitude ratio specification is not applied.
- *10 When AUTO is set, the cutoff frequency is set to approx. 1/4 the specified sampling frequency.
- *11 Excluding cutoff frequencies over 5 kHz

Standard Accessories

Stack-connector caps (female) ×2 SD card (4 GB) USB cable CTRS DC power cable P-79 Ground wire P-78 Ballpoint screwdriver Input connector caps ×4

Optional Accessories

CTRS AC adapter UIA345-12-L-JP (For U.S.A.: UNI345-1238-L-US) Various measuring units Various expansion units Remote control unit Connector cap BRA.0B.200.PCSG Connector cap BRA.1B.200.PCSG 4109P-S32-7 (4-conductor shielded) N-129 4109P-S32-7 (6-conductor shielded) U-136 4109P-BNC plug U-137 4109P-BNC jack U-129 4109P-R05 jack U-138 EXTERNAL I/O cable U-133 SD card (4 GB) SD card (16 GB) RP-SDFC16SW1 Dynamic Data Acquisition Software DCS-100A (Please use the latest version.)

CTRS-CDV010A Specifications

Channels	n	Strain Measurement 4	Voltage Measurement
Input	Connector Shape	NDIS4109 (Small round 9 p Model: EPRC07-RX9FNDIS	oins) receptacle
Connector	Compatible Plug	NDIS4109 (Small round 9 p Model: EPRC07-P9MNDIS	pins) plug
Measuring Targets		Strain gages*1 Strain-gage transducers	Voltage
Compatible Resistance	ompatible Bridge esistance When bridge excitation is set to 2 V 120 to 1000 Ω When bridge excitation is set to 5 V 350 to 1000 Ω		_
Gage Factor		2.00 fixed	_
Bridge Excitation/ Sensor Excitation		2, 5 VDC	2, 5 VDC *2 OFF (0 V)
		A maximum of 20 mA per	
Input Imped Input Mode		— 3.6 MΩ±10% Balanced differential input	
III put Wouc	Setting		•
	Method Settable	Any range method or OFF Minimum: 1000 × 10 ⁻⁶ strain	Minimum: 1 V
Measuring	Range	Maximum: 50000 × 10 ⁻⁶ strain	Maximum: 50 V
Range	Setting	•1000 to 10000 × 10 ⁻⁶ strain 100 × 10 ⁻⁶ strain steps	•1 to 10 V 0.1 V steps
	Steps	•100 × 10 • strain steps •10000 to 50000 × 10 • strain	•10 to 50 V
		1000 × 10 ⁻⁶ strain steps	1 V steps
Range Accu		Within ±0.2% FS	
Nonlinearity	Zero	Within ±0.1% FS Within ± (0.009% FS +	W/ithin + (0.0009/ ES)
Temperature	Point	0.9 × 10 ⁻⁶ strain)/°C	Within ± (0.009% FS + 0.21 mV)/°C
Stability	Sensitivity	Within ±0.03%/°C	· · · · · · · · · · · · · · · · · · ·
T:	Zero	Within ± (0.09% FS +	Within ± (0.09% FS +
Time Stability	Point	9 × 10 ⁻⁶ strain)/8 h	0.1 mV)/8 h
Judinity	Sensitivity	Within ±0.3%/8 h For each channel, ON, OFF	
			adjustment and set the
Balance Adjustment		NONE: Balance adjustme	o zero. alance adjustment again.
		OFF: Do not execute b NONE: Balance adjustme check the initial u	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control
	Operating	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software ^{*3} or operate the s	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control ipecial-remote-control
	Operating Method Adjustment Method	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software ^{*3} or operate the s BAL switch.	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control special-remote-control
	Operating Method Adjustment Method Adjustment	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software ^{*3} or operate the s BAL switch. Auto balance (Saved in no	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control special-remote-control
	Operating Method Adjustment Method Adjustment Range	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software ³ or operate the s BAL switch. Auto balance (Saved in no Within±10000 × 10 ⁻⁶ strain Within± (0.1% FS +	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control ipecial-remote-control involatile memory) Within ±10 V
	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software ³ or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 ⁶ strain Within ± (0.1% FS + 2 × 10 ⁶ strain)	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control special-remote-control nvolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS
Adjustment	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software ¹³ or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 ⁻⁶ strain Within ± (0.1% FS + 2 × 10 ⁻⁶ strain) Within ±1% FS ⁻¹⁴	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control special-remote-control nvolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS
Adjustment Input Range Common-m	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software ¹³ or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 ⁻⁶ strain Within ± (0.1% FS + 2 × 10 ⁻⁶ strain) Within ±1% FS ⁻¹⁴	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control special-remote-control nvolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±60 V
Input Range Common-m Voltage Absolute Maximum Rating	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy ode Input	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software * or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 * strain Within ± (0.1% FS + 2 × 10 * strain) Within ±1% FS * 4 Within ±60000 × 10 * strain	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control incolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±60 V Within ±20 V ±70 V
Input Range Common-m Voltage Absolute Maximum Rating	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy ode Input	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software '3 or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 6 strain Within ± (0.1% FS + 2 × 10 6 strain) Within ±1% FS '4 Within ±60000 × 10 6 strain ±5 V	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control incolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±60 V Within ±20 V ±70 V
Input Range Common-m Voltage Absolute Maximum Rating Frequency F	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy ode Input Input Response Transfer	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software *3 or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 *6 strain Within ± (0.1% FS + 2 × 10 *6 strain) Within ±1% FS *4 Within ±60000 × 10 *6 strain ±5 V DC to 20 kHz, -3 ±1 dB (At	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control incolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±60 V Within ±20 V ±70 V 20 kHz)
Input Range Common-m Voltage Absolute Maximum Rating Frequency F	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy Input Response Transfer Characteristis Cutoff	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software 3 or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 5 strain Within ± (0.1% FS + 2 × 10 5 strain) Within ±1% FS 4 Within ±60000 × 10 5 strain ±5 V DC to 20 kHz, -3 ±1 dB (At 5th-order Butterworth 10, 20, 50, 100, 200, 500, 1k	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control incolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±60 V Within ±20 V ±70 V 20 kHz)
Input Range Common-m Voltage Absolute Maximum Rating Frequency F	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy Input Input Input Cateristic Cutoff Frequency Amplitude Ratio at	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 fstrain Within ± (0.1% FS + 2 × 10 fstrain) Within ±1% FS fstrain —— ±5 V DC to 20 kHz, -3 ±1 dB (At 5th-order Butterworth 10, 20, 50, 100, 200, 500, 1k FLAT fs, AUTO fstrain, 200, 500, 1k FLAT fs, AUTO fstrain, 200, 500, 1k FLAT fs, AUTO fstrain, 200, 500, 1k	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control incolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±60 V Within ±20 V ±70 V 20 kHz)
Input Range Common-m Voltage Absolute Masimum	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy Input Response Transfer Characteristis Cutoff Frequency Amplitude Ratio at Cutoff Point Attenuation	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software '3 or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 6 strain Within ± (0.1% FS + 2 × 10 6 strain) Within ±1% FS 4 Within ±60000 × 10 6 strain ±5 V DC to 20 kHz, -3 ±1 dB (At 5th-order Butterworth 10, 20, 50, 100, 200, 500, 1k FLAT 5, AUTO 6	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control incolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±60 V Within ±20 V ±70 V 20 kHz)
Input Range Common-m Voltage Absolute Maximum Rating Frequency F	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy Input Response Transfer Characteristis Cutoff Frequency Amplitude Ratio at Cutoff Point Attenuation Characteristis Cutoff Cutoff	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software 3 or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 5 strain Within ± (0.1% FS + 2 × 10 5 strain) Within ±1% FS 4 Within ±60000 × 10 5 strain ±5 V DC to 20 kHz, -3 ±1 dB (At 5th-order Butterworth 10, 20, 50, 100, 200, 500, 1k FLAT 5, AUTO 5 -3±1 dB -30±3 dB/oct. 7 0.2, 1 Hz and OFF	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control incolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±60 V Within ±20 V ±70 V 20 kHz)
Input Range Common-m Voltage Absolute Maximum Rating Frequency F	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy Input Response Transfer Characteristis Cutoff Frequency Amplitude Ratio at Cutoff Point Attenuation Characteristis Cutoff Frequency Cutoff Cutoff Frequency Amplitude Cutoff Frequency Amplitude Cutoff Frequency Attenuation Characteristis Cutoff Frequency	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software 3 or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 5 strain Within ± (0.1% FS + 2 × 10 5 strain) Within ±1% FS 4 Within ±60000 × 10 5 strain ±5 V DC to 20 kHz, -3 ±1 dB (At 5th-order Butterworth 10, 20, 50, 100, 200, 500, 1k FLAT 5, AUTO 5 -3±1 dB -30±3 dB/oct. 7 0.2, 1 Hz and OFF	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control involatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±60 V Within ±20 V ±70 V 20 kHz) , 2k, 5k, 10k Hz as well as
Input Range Common-m Voltage Absolute Maximum Rating Frequency F	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy Input Response Transfer Characteristis Cutoff Frequency Amplitude Ratio at Cutoff Point Attenuation Characteristis Cutoff Frequency Amplitude Ratio at Cutoff Point Attenuation Characteristis Cutoff Frequency Resolution Method	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software 3 or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 5 strain Within ± (0.1% FS + 2 × 10 5 strain) Within ±1% FS 4 Within ±60000 × 10 5 strain ±5 V DC to 20 kHz, -3 ±1 dB (At 5th-order Butterworth 10, 20, 50, 100, 200, 500, 1k FLAT 5, AUTO 5 -3±1 dB -30±3 dB/oct. 7 0.2, 1 Hz and OFF 24 bits	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control involatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±60 V Within ±20 V ±70 V 20 kHz) , 2k, 5k, 10k Hz as well as
Input Range Common-m Voltage Absolute Maximum Rating Frequency F	Operating Method Adjustment Method Adjustment Range Accuracy NONE Accuracy Input Response Transfer Characteristis Cutoff Frequency Amplitude Ratio at Cutoff Point Attenuation Characteristis Cutoff Frequency Amplitude Ratio at Cutoff Point Attenuation Characteristis Cutoff Frequency Resolution	OFF: Do not execute b NONE: Balance adjustme check the initial u voltage). Execute the balance opera software 3 or operate the s BAL switch. Auto balance (Saved in no Within ±10000 × 10 5 strain Within ± (0.1% FS + 2 × 10 5 strain) Within ±1% FS 4 Within ±60000 × 10 5 strain ±5 V DC to 20 kHz, -3 ±1 dB (At 5th-order Butterworth 10, 20, 50, 100, 200, 500, 1k FLAT 5, AUTO 5 -3±1 dB -30±3 dB/oct. 7 0.2, 1 Hz and OFF 24 bits Synchronous sampling of a	o zero. alance adjustment again. ent can be disabled to inbalanced value (Input tion by using the control pecial-remote-control nvolatile memory) Within ±10 V Within ±0.1% FS Within ±0.2% FS Within ±20 V ±70 V 20 kHz) , 2k, 5k, 10k Hz as well as all channels LED nction

Power Supply	Supplied by the CTRS-100A or CTRS-BATT010A
Power Consumption	Approx. 2.1 W (When supplying 12 VDC)
Operating Temperature	-10 to 50°C
Operating Humidity	20 to 90% (Non-condensing)
Storage Temperature	-20 to 60°C
Vibration Resistance	49.0 m/s ² (5 G), 5 to 200 Hz
Shock Resistance	490 m/s ² (50 G), 11 ms or less, half sine wave
Dimensions	26.6 W × 92 H × 94 D mm
	(Excluding protrusions and protectors)
Weight	Approx. 240 g
Utility Nuts	Size: M4, 6 places

- * The measuring unit specifications apply to the state in which the temperature has stabilized after a preheating time of 30 minutes.
- *1 A separate bridge box is necessary.
- *2 When the sensor excitation is 2 VDC, the positive side of the sensor excitation is +1 V and the negative side is -1 V.

 When the sensor excitation is 5 VDC, the positive side of the sensor excitation is +2.5 V and the negative side is -2.5 V.
- *3 Only when online control is performed by a PC.
- *4 When the bridge resistance is 350 Ω
- *5 When FLAT is set, the cutoff frequency is set to approx. 25 kHz. However, the cutoff point amplitude ratio specification is not applied.
- *6 When AUTO is set, the cutoff frequency is set to approx. 1/4 the specified sampling frequency.
- *7 Excluding cutoff frequencies over 5 kHz

Standard Accessories	Stack-connector cap (female) Stack-connector cap (male) Input connector caps x4
Optional Accessories	4109P-S32-7 (4-conductor shielded) N-129 4109P-S32-7 (6-conductor shielded) U-136 4109P-BNC plug U-137 4109P-BNC jack U-129 4109P-R05 jack U-138

CTRS-CVPS010A Specifications

Channels	4 (Isolated input circuit)
Input Connector	
Connector Shape	NDIS4109 (Small round 9 pins) receptacle
	Model: EPRC07-RX9FNDIS
Compatible Plug	NDIS4109 (Small round 9 pins) plug
	Model: EPRC07-P9MNDIS
Measuring Targets	Voltage
Sensor Excitation	5, 10 VDC, OFF
	Accuracy: Within ±0.2%
	Channel 1 and 2: A maximum of 35 mA per
	channel can be output.
	Channel 3 and 4: A maximum of 15 mA per
	channel can be output.
Input Impedance	(1.8 MΩ+1.8 MΩ) ±10%
Input Modes	Balanced differential input
Measuring Range	-
Setting Method	Any range method or OFF
Settable Range	Minimum: 0.2 V
	Maximum: 50 V
Setting Steps	0.2 to 10 V: 0.1 V steps
	10 to 50 V: 1 V steps
Range Accuracy	Within ±0.2% FS
	(Apply to an ambient temperature of 23 ±5°C
	and a stable temperature after 30 minutes of
	preheating time.)
Nonlinearity	Within ±0.1% FS
Temperature Stability	
Zero Point	Within ±(0.009% FS + 0.21 mV)/°C
Sensitivity	Within ±0.03%/°C
Time Stability	
Zero Point	Within ±0.05% FS/8 h
Sensitivity	Within ±0.05%/8 h
Zero Suppress	
Setting	For each channel, ON, OFF, or NONE can
	be selected.
	ON: Execute zero suppress and set the
	measured value to zero.
	OFF: Do not execute zero suppress again.
	NONE: Zero suppress can be disabled to
	check the initial unbalanced value
	4
	(Input voltage).
Operating Method	(Input voltage). Execute the zero suppress by using the control
Operating Method	



	**	
	••	<i>y</i>
Data	a Recor	ders/
- 1	Analyze	ers

Adjustment Method	Auto balance (Saved in nonvolatile memory)
Adjustment Range	When 0.2 to 0.9 V range: Within ±5 V
-	When 1 to 50 V range: Within ±10 V
Accuracy	Within ±0.1% FS
NONE Accuracy	When 0.2 to 0.4 V range: Within ±1 mV
	When 0.5 to 50 V range: Within ±0.2% FS
	(Apply to an ambient temperature of 23 ±5°C
	and a stable temperature after 30 minutes of
	preheating time.)
Input Voltage Range	Within ±60 V
Common-mode Input \	
Absolute Maximum Ra	
Input	±70 V
Frequency Response	DC to 20k Hz (At 20k Hz input, -3 ±1 dB)
LPF	De to Zoit I Z (it Zoit I Z II pag 3 Z I ab)
	5 5th-order Butterworth
Cutoff Frequency	10, 20, 50, 100, 200, 500, 1k, 2k, 5k, 10k Hz,
	FLAT, AUTO
	When FLAT is set, the cutoff frequency is set to
	approx. 25k Hz.
	When AUTO is set, the cutoff frequency is set to
	approx. 1/4 the specified sampling frequency.
Amplitude Ratio at Cut	roff Point -3+1 dR
	When the cutoff frequency is less than 5k Hz:
Attendation characteristics	-30 ±3 dB/oct.
	When the cutoff frequency exceeds 5k Hz:
	-30 (+3, -12) dB/oct.
HPF	30 (13) 12) 43, 504
Cutoff Frequency	0.2, 1 Hz and OFF
Attenuation Character	
AD Conversion Resolut	ion 24 bits
Sampling Method	Synchronous sampling of all channels
Indicator	Status LED, channel-status LED
Other Functions	,
TEDS	Read the TEDS information and apply it to the
	measurement conditions.
	(Only when online control is performed by a PC.)
Isolation	Between input to GND (Non-isolated between
	channels), withstand voltage 250 VAC for
	1 minute.
Power Supply	Supplied by the CTRS-100A or CTRS-BATT010A
Power Consumption	Approx. 3.1 W (When supplying 12 VDC)
Operating Temperature	
Operating Humidity	20 to 90% (Non-condensing)
Storage Temperature	-20 to 60°C
Vibration Resistance	49.0 m/s ² (5 G), 5 to 200 Hz
Shock Resistance	490 m/s ² (50 G), 11 ms or less, half sine wave
Dimensions	26.6 W × 92 H × 94 D mm
	(Excluding protrusions and protectors)
Weight	Approx. 240 g
Utility Nuts	Size: M4, 6 places
•	· · ·

Standard Accessories Stack-connector cap (female) Stack-connector cap (male) Input connector caps × 4

Optional Accessories 4109P-S32-7(6-conductor shielded) U-136

4109P-BNC PLUG U-137 4109P-BNC jack U-129 4109P-R05 JACK U-138

CTRS-CTA010A Specifications

CTRS-CTA010A Sp	ecifications
Channels	4
Input Connector*1	
Connector Shape	Push-in spring connection
Connection Capacity	Conductor cross section solid / flexible
	0.2 mm ² 1.5 mm ²
	Conductor cross section AWG / kcmil 2416
	Stripping length 8 mm
Measuring Targets	Thermocouples
Measuring Targets*2	K, T, J, N
Measuring Range	K: -200.0 to 1370.0 C
	T: -200.0 to 400.0 C
	J: -200.0 to 1200.0 C
	N: -200.0 to 1300.0 C
Resolution	0.1 °C
Accuracy	
External Reference Ju	unction Compensator
Above -100 C Withi	n 0.1% of reading 0.4 °C
Below -100 C Withi	n 0.2% of reading 0.6 °C
Internal Reference Ju	nction Compensator
Ambient temperatur	re 15 °C to 3 °C
Above -100 C Wit	hin 0.1% of reading 1.4 °C
Below - 100 C Witl	nin 0.2% of reading 1.6 °C
Ambient temperatur	re -10 °C to 50 °C
Above -100 C Wit	hin 0.1% of reading 2.4 °C
Below -100 C Witl	nin 0.2% of reading 2.6 °C
Sampling System	Scanning
Inside Sampling Frequencie	s Approx. 0.5 Hz, approx. 2.0 Hz
Indicator	State indicator LED
Check Functions	Burnout check
Withstand Voltage	500VAC for 1min. between input and case
	(Output)
Power Supply	Supplied by the CTRS-100A or CTRS-BATT010A
Power Consumption	Approx. 0.7 W (when supplying 12 VDC)
Operating Temperature	
Operating Humidity	20 to 90% (Non-condensing)
Storage Temperature	-20 to 60 °C
Vibration Resistance	49.0 m/s ² (5 G), 5 to 200 Hz
Shock Resistance	490 m/s ² (50 G), 11 ms or less, half sine wave
	$92 \text{ H} \times 94 \text{ D}$ mm (Excluding protrusions or protectors)
	$92 \text{ H} \times 127 \text{ D}$ mm (Excluding protrusions or
	, including the temperature measuring adapter)
	0 g, excluding the temperature measuring adapter
	0 g, including the temperature measuring adapter
Utility Nuts Size: M4, 6	places

^{*}The measuring unit specifications apply to the state in which the temperature has stabilized after a preheating time of 30 minutes.

^{*2} Thermocouple resistance 1 $k\Omega$ or less

Standard Accessories	Stack-connector cap (female) Stack-connector cap (male)
	Temperature measuring adapter CT-3A-4
Ontional Accessories	Temperature measuring adapter CT-3A-A

^{*1} Mounted on temperature measuring adapter

CTRS-CAG010A Specifications

CTRS-CAG010A Spec	cifications
CAN Ports	2
CAN Port Connector	ECB.1B.303.CLN LEMO made
	(Compatible plug FGB.1B.303.CLAD62Z)
CAN Protocol	ISO/DIS 11898-1 compliant
	*Support for CAN and CAN FD Frames
Supported Physical Layer	ISO 11898-2 and ISO 11898-5
	*Low Speed CAN not supported
Termination Resistor	Implementation (Selectable ON/OFF)
Communication Speed	1000, 800, 500, 250, 125, 100, 83.3, 62.5,
	50, 33.3, 25, 20, 10 kbps
CAN FD Data Bit Rate	5, 4, 2, 1, 0.5 Mbps, OFF
	*Limited by communication speed. Refer to
	The Configurable CAN FD Data Bit Rate Table.
CAN Recording Mode	Selected CAN ID mode (max. 1024 messages)
	All CAN ID mode
	*CAN trigger is not available
	(with all CAN ID mode).
Listen Only Mode	(Selectable ON/OFF)
	*CAN data output is not available with listen
	only mode.
CAN Data Output	Predetermined CAN data can be output up
	to 32 messages at one time.
CAN Data Output Timing	Output at start/ Output at stop/
	Interval/ Manual
CAN Trigger	Received CAN messages can be used as
	trigger source.
CAN Trigger Type	Manual / Analog / Digital / Composite
Other Function	Automatic communication speed check
Power Supply	Supplied by the CTRS-100A or CTRS-BATT010A
Power Consumption	Approx. 0.6 W (when supplying 12 VDC)
Operating Temperature	-10 to 50°C
Operating Humidity	20 to 90% (Non-condensing)
Storage Temperature	-20 to 60°C
Vibration Resistance	49.0 m/s ² (5 G), 5 to 200 Hz
Shock Resistance	490m/s^2 (50 G), 11 ms or less, half sine wave
Dimensions	26.6 W × 92 H × 94 D mm
	(Excluding protrusions or protectors)
Weight	Approx. 220 g
Utility Nuts	Size: M4, 6 places
The Configurable CAN ED	Data Bit Bata Table

The Configurable CAN FD Data Bit Rate Table

Communication Speed [kbps]	CAN FD Data Bit Rate [Mbps]
1000, 800	2, 1, OFF
500, 250	5, 4, 2, 1, 0.5, OFF
125	2, 1, 0.5, OFF
100, 83.3, 62.5	1, 0.5, OFF
50, 33.3	0.5, OFF
25, 20, 10	OFF

Standard Accessories	Stack-connector cap (female) Stack-connector cap (male)
Optional Accessories	CTRS CAN cable 9-pin male D-sub U-135

CTRS-BATT010A Specifications

Type of Battery	Lithium-ion battery
	United Nations Recommendations on the Transport
	of Dangerous Goods UN 38.3 safety tests: Passed
	The UN 38.3 safety test certification and a certificate
	of Safe Transport of Chemical Goods (Test Report)
	issued by the Shanghai Research
	Institute of Chemical Industry, China: Received
Input (DC IN)	10 to 30 VDC
	Connector: ECP.1S.302.CLL (LEMO)
	Compatible plug: FFA.1S.302.CLA** (LEMO)
	** stands for the collet type, size number, etc.
Output Voltage	e 10 VDC
Current	t Maximum: 2.5 A (Ambient temperature: 0 to 40°C)
	Maximum: 1.5 A (Ambient temperature: -10 to 0°C)
	Maximum: 2.0 A (Ambient temperature: 40 to 50°C)
Operating Switch	Battery-check switch
	Press once: Remaining battery power check
	The battery-check LED indicates the
	remaining battery power.
	Hold down (For approx. one second):
	Battery integrity check
	The battery-check LED indicates the
	integrity.

Indicator Status	s LEDs: 1
Duri	ing external-power operation: Lit up in blue
Duri	ing battery operation: Lit up in purple
(The	LED flashes purple when the remaining battery
pow	ver is less than 30%.)
Whe	en an error occurs: Flashes red
Batte	ry-check LEDs: 3
Whe	en checking the remaining battery power (Lit up
in b	lue)
	/●/● 100 to 70%
)/●/- 69 to 30%
	/-/- 29 to 0%
	* Flashes red at 5% or less
	en checking the integrity (Lit up in purple)
	/●/● Good
	/●/— Caution
	/-/- Replacement required
Whe	en an error occurs: Flashes red (All 3)
(●:	Lit up, -: Off)
Charging Time*1	
When Charging the B	attery Alone
	or less (Ambient temperature 10 to 40°C)
7.0 h	or less (Ambient temperature 0 to 10°C)
When Supplying Pow	er to the System and Charging the Battery at
the Same Time	
	or less (Ambient temperature 10 to 40°C)
10.0 k	or less (Ambient temperature 0 to 10°C) *2
Discharge Time Durin	g 2.5 A (25 W) output: 60 min or more
	g 0.5 A (5 W) output: 300 min or more
	en using a new battery at an ambient
	perature of 25 ±10°C
(Refe	rence) The power consumption of each unit is
	as follows:
	CTRS-100A 3.5 W
	CTRS-CDV010A 2.1 W
	CTRS-SYNC010A 0.3 W
Because the total power of	consumption in the case of analog measurement
on 32 channels + the use	of synchronization unit is approx. 18.5 W,
operation for 80 minutes	
Operating Temperature	
Charging	0 to 40°C
Discharging	-10 to 50°C
Operating Humidity	20 to 90% (Non-condensing)
Storage Temperature	-20 to 50°C
* In the case of long-term	n storage for one month or more, avoid high
temperatures or humid	ity, and store the unit at 40°C or less.
Vibration Resistance	49.0 m/s² (5 G), 5 to 200 Hz
Shock Resistance	490 m/s ² (50 G), 11 ms or less, half sine wave
Dimensions	53.2 W × 92 H × 94 D mm
	(Excluding protrusions or protectors)
Weight	Approx. 570 g
Utility Nuts	Size: M4, 12 places
Battery Pack Replaceme	
<u> </u>	(Replacement by the user is not possible.)
tariful I in the second	

- $^{\star}1$ If the battery is hot, it may stop charging before it is fully charged for safety reasons. This is not a malfunction.
- *2 Depending on the environment, charging may stop before the battery is fully charged for safety reasons. This is not a malfunction.

Standard Accessories Stack-connector cap (male)

Optional Accessories CTRS AC adapter UIA345-12-L-JP (For U.S.A.: UNI345-1238-L-US) CTRS DC power cable P-79 Connector cap BRA.1B.200.PCSG



CTRS-WLAN010A/011A Specifications

CIK3-VVL	ANUTU	A/UTTA Specifications
Iter	m	Details
Supported F	unctions	Collection of collected data, setting of measurement conditions, real-time monitoring *1
Operating Switch		"WIRELESS": Enables or disables the wireless LAN unit operation. "SETUP": Use the "Easy connection function" *2. "RESET": Reset SSID and security key to factory default.
Indicator		Status LED, Wireless LAN status LED (2.4 GHz and 5 GHz)
	Compliance Standard	IEEE 802.11 a/b/g/n/ac
	Frequency	2.4 GHz and 5 GHz
Radio	Channel	CTRS-WLAN010A 2.4 GHz:1 to 13 ch 5 GHz:36, 40, 44, 48 ch (W52) *3 CTRS-WLAN011A 2.4 GHz:1 to 11 ch 5 GHz:36, 40, 44, 48 ch (W52) *3 149, 153, 157, 161, 165 ch (W58) *3
Section	Security	WPA2-PSK(AES), WPA-PSK(AUTO/TKIP) *4, None
	Network Type	Access point mode
	Number of Simultaneous Connections to a PC	1
	Antenna	Built-in antenna
	Country *5	CTRS-WLAN010A: Japan CTRS-WLAN011A: U.S.
	Other Functions	Easy connection function, DHCP server function *6
Power Supp		Supplied by the CTRS-100A or CTRS-BATT010A
Power Cons		Approx. 2.0 W (When supplying 12 VDC)
Operating Te		-10 to 50°C
Operation Hu		20 to 90% (Non-condensing)
Storage Tem		-20 to 60°C
Vibration Re		49.0 m/s ² (5 G), 5 to 200 Hz
Shock Resist		490 m/s ² (50 G), 11 ms or less, half sine wave
Dimensions		26.6 W × 92 H × 94 D mm (Excluding protrusions or protectors)
Weight		Approx. 200 g
Utility Nuts		Size: M4, 6 places

- *1 Depending on the radio wave environment of the installation location, the monitor may stop due to a decrease in the transfer rate of wireless LAN communication.
- *2 Communicate with WPS (Wi-Fi Protected Setup) compatible devices and use wireless LAN Easy to configure complex security settings.
 (Equivalent to WPS 2.0)
 *3 5 GHz band is for indoor use only. (Do not use outdoors)
 *4 When WPA-PSK(AUTO/TKIP) is selected, the "Easy connection function"
- cannot be used.
- *5 Not available in other countries.
 *6 The IP address of the wireless connection device (PC) can be set automatically.

Standard Accessories	Stack-connector cap (male) Stack-connector cap (female)	
Optional Accessories	CTRS Network Utility Software	

*Free of charge, please download from our website.

CTRS-SYNC010A Specifications

	•
Connector	Synchronous input connector
	Synchronous output connector
Indicator	Status LED
	REMOTE LED
Operating Switch	
4-bit DIP Switch	ETHERNET-USB communication switch: 1 bit
	Device ID setting: 2 bits
	Reserved: 1 bit
Synchronous Operatio	n Function
Number of Unit that	t Can Be Connected
	A maximum of four units can be connected in
	a cascade by using synchronous cable.
Recorded Data	Recorded data can be saved to the SD card for
	each CTRS-100A as a separate file or to a PC
	(Only when online control is performed by the PC).
Ethernet Communicatio	n Communication is possible by connecting a
	communication cable.
	* Ethernet communication is possible at a
	distance of up to 52.8 m by extending the
	communication cable by using an RJ-45 relay
	connector (Kyowa recommended items) and
	LAN cable (Kyowa recommended items).
Distance between Device	es 2 m or less
Power Supply	Supplied by the CTRS-100A or CTRS-BATT010A
Operating Temperatur	re -10 to 50°C
Operating Humidity	20 to 90% (Non-condensing)
Storage Temperature	-20 to 60°C
Vibration Resistance	49.0 m/s² (5 G), 5 to 200 Hz
Shock Resistance	490 m/s ² (50 G), 11 ms or less, half sine wave
Power Consumption	Approx. 0.3 W

Dimensions	26.6 W × 92 H × 94 D mm
	(Excluding protrusions and protectors)
Weight	Approx. 200 g
Utility Nuts	Size: M4, 6 places
Standard Accessories	Stack-connector cap (female) Stack-connector cap (male)
Optional Accessories	CTRS sync cable N-130 CTRS communication cable N-131 LAN cable 20m NWYC5E-STP-S-BL-20 LAN cable 50m LD-CTTBU500 RJ-45 relay adapter ADT-EX-STPN Connector cap BRA.1B.200.PCSG

CTRS-RCU010A Specifications

REC Start recording. Operating method: Press the button once. STOP Stop recording. Operating method: Press the button once or twice." BAL Execute a balance operation. Operating method: Press the button twice or hold it down." READ Read the condition settings from the SD card. Operating method: Hold down the button. OPTION 1, OPTION 2 Use the control software to assign any function to these buttons for use. Operating method: Press the button once. • Monitor • Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED REC LED BAL LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60°C 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance Shock Resistance 490 m/s² (5 G), 5 to 200 Hz Shock Resistance Approx. 0.2 W Dimensions 46 W x 90 H x 20 D mm (Excluding protrusions) Weight Approx. 120 g Utility Nuts Size: M3, 6 places	Operating Button Switch	:h
STOP Stop recording. Operating method: Press the button once or twice." BAL Execute a balance operation. Operating method: Press the button twice or hold it down." READ Read the condition settings from the SD card. Operating method: Hold down the button. OPTION 1, OPTION 2 Use the control software to assign any functior to these buttons for use. Operating method: Press the button once. • Monitor • Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED REC LED BAL LED REC LED BAL LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60°C Vibration Resistance 490 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (5 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g	REC	
Operating method: Press the button once or twice." BAL Execute a balance operation. Operating method: Press the button twice or hold it down." READ Read the condition settings from the SD card. Operating method: Hold down the button. OPTION 1, OPTION 2 Use the control software to assign any functior to these buttons for use. Operating method: Press the button once. • Monitor • Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED REC LED BAL LED REC LED BAL LED OPTION 1 LED OPTION 1 LED OPTION 2 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60°C Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 49.0 m/s² (5 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		
twice." BAL Execute a balance operation. Operating method: Press the button twice or hold it down." READ Read the condition settings from the SD card. Operating method: Hold down the button. OPTION 1, OPTION 2 Use the control software to assign any function to these buttons for use. Operating method: Press the button once. • Monitor • Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED Rec LED REC LED BAL LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Temperature -20 to 60°C Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g	STOP	Stop recording.
BAL Execute a balance operation. Operating method: Press the button twice or hold it down.* READ Read the condition settings from the SD card. Operating method: Hold down the button. OPTION 1, OPTION 2 Use the control software to assign any function to these buttons for use. Operating method: Press the button once. • Monitor • Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED REC LED REC LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature -20 to 60°C Vibration Resistance Vibration Resistance Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		
Operating method: Press the button twice or hold it down.*1 READ Read the condition settings from the SD card. Operating method: Hold down the button. OPTION 1, OPTION 2 Use the control software to assign any function to these buttons for use. Operating method: Press the button once. • Monitor • Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED Rengining-SD-card-space indicator LED REC LED BAL LED REC LED BAL LED OPTION 1 LED OPTION 1 LED OPTION 2 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature -20 to 60°C Vibration Resistance Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight		twice.*1
hold it down.*1 READ Read the condition settings from the SD card. Operating method: Hold down the button. OPTION 1, OPTION 2 Use the control software to assign any function to these buttons for use. Operating method: Press the button once. •Monitor •Delete the latest data file •Over reset •PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED REC LED REC LED READ LED OPTION 1 LED OPTION 1 LED OPTION 1 LED OPTION 2 LED OPTION 2 LED Operating Temperature -10 to 50°C Operating Humidity Storage Temperature Vibration Resistance Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g	BAL	
READ Read the condition settings from the SD card. Operating method: Hold down the button. OPTION 1, OPTION 2 Use the control software to assign any function to these buttons for use. Operating method: Press the button once. • Monitor • Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED REC LED BAL LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED OPTION 2 LED OPTION 2 LED Operating Temperature -10 to 50°C Operating Humidity Storage Temperature Vibration Resistance Vibration Resistance Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		Operating method: Press the button twice or
Operating method: Hold down the button. OPTION 1, OPTION 2 Use the control software to assign any function to these buttons for use. Operating method: Press the button once. • Monitor • Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED REC LED BAL LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight		hold it down.*1
OPTION 1, OPTION 2 Use the control software to assign any function to these buttons for use. Operating method: Press the button once. • Monitor • Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED Remaining-SD-card-space indicator LED REC LED REC LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60°C Vibration Resistance Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (5 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight	READ	Read the condition settings from the SD card.
to these buttons for use. Operating method: Press the button once. •Monitor •Delete the latest data file •Over reset •PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED Remaining-SD-card-space indicator LED REC LED REC LED BAL LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60°C Vibration Resistance Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (5 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight		
Operating method: Press the button once. • Monitor • Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED Range-over indicator LED REC LED BAL LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature -20 to 60°C Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g	OPTION 1, OPTION 2	
•Monitor •Delete the latest data file •Over reset •PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED Range-over indicator LED REC LED BAL LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature -20 to 60°C Vibration Resistance Shock Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		
• Delete the latest data file • Over reset • PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED Range-over indicator LED REC LED REC LED BAL LED READ LED OPTION 1 LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature -20 to 60°C Vibration Resistance Shock Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		Operating method: Press the button once.
•Over reset •PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED Range-over indicator LED REC LED REC LED BAL LED READ LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature Vibration Resistance Vibration Resistance Power Consumption Approx. 0.2 W Dimensions Vierbulant LED Vibration Resistance Power Consumption Approx. 0.2 W Dimensions Vierbulant LED Vibration Resistance Vibration Resistance Approx. 0.2 W Dimensions Vierbulant LED Vibration Resistance Vibration Resistance Approx. 0.2 W Dimensions Vierbulant LED Vibration Resistance Vibration Resistance Approx. 0.2 W Dimensions Vierbulant LED Vibration Resistance Vibration Resistance Approx. 0.2 W Vibration Resistance Approx. 0.2 W Approx. 120 g		•Monitor
PAUSE Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED Range-over indicator LED REC LED BAL LED READ LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature Vibration Resistance Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		•Delete the latest data file
Indicator Status LED Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED REC LED BAL LED READ LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (50 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		•Over reset
Remaining-battery-power indicator LED Remaining-SD-card-space indicator LED Range-over indicator LED REC LED REC LED BAL LED READ LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (5 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		•PAUSE
Remaining-SD-card-space indicator LED Range-over indicator LED REC LED BAL LED READ LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature Vibration Resistance Vibration Resistance Shock Resistance Power Consumption Approx. 0.2 W Dimensions REC LED OPTION 1 LED OPTION 1 LED OPTION 2 LED OPTION 2 LED OPTION 3 LED OPTION 3 LED OPTION 4 LED OPTION 5 LED OPT	Indicator	
Range-over indicator LED REC LED BAL LED READ LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60°C Vibration Resistance Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 49.0 m/s² (5 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		
REC LED BAL LED READ LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60°C Vibration Resistance Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (5 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		
BAL LED READ LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature -20 to 60°C Vibration Resistance Shock Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 49.0 m/s² (5 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		
READ LED OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature -20 to 90% (Non-condensing) Storage Temperature -20 to 60°C Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 49.0 m/s² (5 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		
OPTION 1 LED OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature -20 to 60°C Vibration Resistance Shock Resistance Power Consumption Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		BAL LED
OPTION 2 LED Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity Storage Temperature -20 to 60°C Vibration Resistance Vibration Resistance Power Consumption Approx. 0.2 W Dimensions Very March 120 g Other Functions Built-in buzzer 20 to 50°C 20 to 90% (Non-condensing) -20 to 60°C 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (50 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		READ LED
Other Functions Built-in buzzer Strap hole Operating Temperature -10 to 50°C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60°C Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (50 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		
Strap hole Operating Temperature -10 to 50 °C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60 °C Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (50 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		OPTION 2 LED
Operating Temperature -10 to 50°C Operating Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60°C Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (50 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g	Other Functions	Built-in buzzer
Operating Humidity Storage Temperature Vibration Resistance Shock Resistance Power Consumption Dimensions 20 to 90% (Non-condensing) -20 to 60°C 49.0 m/s² (5 G), 5 to 200 Hz 490 m/s² (50 G), 11 ms or less, half sine wave Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		•
Storage Temperature -20 to 60°C Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (50 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W x 90 H x 20 D mm (Excluding protrusions) Weight Approx. 120 g	Operating Temperature	-10 to 50°C
Vibration Resistance 49.0 m/s² (5 G), 5 to 200 Hz Shock Resistance 490 m/s² (50 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W x 90 H x 20 D mm (Excluding protrusions) Weight Approx. 120 g		
Shock Resistance 490 m/s² (50 G), 11 ms or less, half sine wave Power Consumption Approx. 0.2 W Dimensions 46 W × 90 H × 20 D mm (Excluding protrusions) Weight Approx. 120 g		
Power Consumption Approx. 0.2 W Dimensions 46 W x 90 H x 20 D mm (Excluding protrusions) Weight Approx. 120 g	Vibration Resistance	
Dimensions 46 W x 90 H x 20 D mm (Excluding protrusions) Weight Approx. 120 g	Shock Resistance	
Weight Approx. 120 g	Power Consumption	
<u> </u>		$46 \text{ W} \times 90 \text{ H} \times 20 \text{ D} \text{ mm}$ (Excluding protrusions)
Utility Nuts Size: M3, 6 places		Approx. 120 g
	Utility Nuts	Size: M3, 6 places

- *1 This can be switched by using the control software.
 * Hold down: To press and hold down a button for at least one second. Press twice: To press a button switch twice within 0.5 seconds.

DCS-100A software, specification for control of CTRS-100 series *For details of DCS-100A, see chapter 4.

Units	Up to 4 units (up to 128 analog channels.)
Interfaces	USB (USB2.0 High Speed) or Ethernet* (10/100BASE-1
	*A separate synchronous unit and special
	communication cable are necessary.
Saving Format	Saves the measured data in the CTRS-100A SD card
	or PC folder.
	When saving to the SD card of CTRS-100A, save the
	KS3 file to the SD card of CTRS-100A.
	Save and convert to a KS2 file (01.06) when
	retrieving the PC.
	When saving to PC folder, save as KS2 file (01.06).
Channel Conditions	Measuring ON/OFF, Measuring mode,
	Range (Arbitrary input), HPF, LPF,
	Balance adjustment ON/OFF/NONE,
	Input resistance check ON/OFF, Calibr. const., Offset
	Cable correction value, Offset ZERO Value, Unit,
	Channel name, Measuring range, Rated capacity,
	Rated output, Deci Digits, Chk. Val. (Up),
	Chk. Val. (Down), Offset ZERO ON/OFF,
	TEDS User Data, TEDS Sensor Model,
	TEDS Sensor S/N, TEDS ROMID
TEDS	(Display items can freely be selected.)
TEDS	Loads the TEDS information automatically and sets
Catting D	the channel conditions.
setting Parameter ar	nd Loading Parameter
Coving and Leeding	Loads and sets the CTRS-100A internal parameter.
Saving and Loading	
	Loads and saves the meas condition file.
	(Extension: C1H) The meas condition file includes environment
	settings, channel conditions, measuring conditions,
	display conditions on graphs and on numeric windows, and arithmetic operation conditions
	(Optional).
Saving and Loading	CTRS-100A Condition File
Saving and Loading	Loads and saves the CTRS-100A condition file
	(Extension:SET) by using the SD card.
Collecting Data File	Convert KS3 files in CTRS-100A SD card to KS2 files
Concerning Data File	and recover.
	and recover.
Deleting Data File	
Deleting Data File	PC deletes the file (KS3) saved in the CTRS-100A SD card.
	PC deletes the file (KS3) saved in the CTRS-100A SD card.
Formatting SD Card	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card.
Formatting SD Card Setting Environment	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card.
Formatting SD Card	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card.
Formatting SD Card Setting Environment	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names.
Formatting SD Card Setting Environment Setting Hardware	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names.
Formatting SD Card Setting Environment Setting Hardware Communication Check	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A
Formatting SD Card Setting Environment Setting Hardware Communication Check	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDS, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. **Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file).
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. **Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. **Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. **LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). ** When saving to PC folder, Up to 1 CAN unit to be measured.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series,
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. **Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. **LEDS, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). ** When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual **Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock)
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the Manual Sampling Frequen	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. **Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. **LEDS, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). ** When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual **Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) **Limited by the number of channels.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. **Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDS, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual *Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) * Limited by the number of channels.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the Manual Sampling Frequen	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. **Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual **Weasured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2" series, external clock) * Limited by the number of channels. **H Up to 1000000000 data Manual, Manual (Set Record Data), Interval,
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. ECOnfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDS, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2 ⁿ series, external clock) *Limited by the number of channels. H Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger,
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C Measure Modes	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. **Configuration** Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. **LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). **When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual **Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) **Limited by the number of channels. **H Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C Measure Modes	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2 ⁿ series, external clock) * Limited by the number of channels. CH Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C Measure Modes	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) * Limited by the number of channels. CH Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger nent Records data from REC to STOP or from REC to
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C Measure Modes	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDS, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2" series, external clock) * Limited by the number of channels. H Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger nent Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data).
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the Manual Measure Modes Manual Measurem	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2" series, external clock) * Limited by the number of channels. H Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger nent Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Recorindg start time settable.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the Manual Measure Modes Manual Measurem	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDS, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) *Limited by the number of channels. H Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger Thent Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Recorindg start time settable.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the Manual Measure Modes Manual Measurem Interval Measurem	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) * Limited by the number of channels. CH Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger nent Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Recoring start time settable.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the Manual Measure Modes Manual Measurem	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. **Configuration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. **LEDS, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). ** When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual **Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) **Limited by the number of channels. **H Up to 1000000000 data **Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, **Manual Trigger, Complex Trigger **Nent Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Recorindg start time settable. **Nent Starts/stops recording data based on the preset starting time and recording interval. **Each Starts/stops recording data based on the preset starting time and recording interval.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C Measure Modes Manual Measurem Interval Measurem Trigger Measurem	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDS, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) * Limited by the number of channels. H Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger nent Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Recorindg start time settable. nent Starts/stops recording data based on the preset trigger conditions.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C Measure Modes Manual Measurem Interval Measurem Trigger Measurem Common Trigger C	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDS, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) * Limited by the number of channels. CH Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger nent Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Recorindg start time settable. nent Records data automatically based on the preset starting time and recording interval. Ent Starts/stops recording data based on the preset trigger conditions.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C Measure Modes Manual Measurem Interval Measurem Trigger Measurem Common Trigger C End Trigger	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) * Limited by the number of channels. CH Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger nent Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Recorindg start time settable. nent Records data automatically based on the preset starting time and recording interval. ent Starts/stops recording data based on the preset trigger conditions. Conditions Settable
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C Measure Modes Manual Measurem Interval Measurem Trigger Measurem Common Trigger C	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2° series, external clock) * Limited by the number of channels. H Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger nent Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Recorindg start time settable. nent Records data automatically based on the preset starting time and recording interval. ent Starts/stops recording data based on the preset trigger conditions. Settable Up to 524288 data for both start and end.
Formatting SD Card Setting Environment Setting Hardware Communication Check Device Confirmation Others When the CAN Unit Recording CAN Data CAN Data Output When Saving the N Sampling Frequen Number of Data/C Measure Modes Manual Measurem Interval Measurem Trigger Measurem Common Trigger C End Trigger	PC deletes the file (KS3) saved in the CTRS-100A SD card. PC formats the CTRS-100A SD card. EConfiguration Sets Interface, the number of units and device names. Loads the hardware configurations from the CTRS-100A Loads the CTRS-100A version. LEDs, on the CTRS-100A front panel, light up. Remote control unit operation beep, balance standard value, PAUSE ON/OFF, detailed hardware information display is Installed Records up to 1024 message CAN data per one unit (as the KC3 file). * When saving to PC folder, Up to 1 CAN unit to be measured. Start, Stop, Interval, Manual Measured Data in the CTRS-100A SD Card cies 1 Hz to 100k Hz (1-2-5 series, 2 ⁿ series, external clock) * Limited by the number of channels. EH Up to 1000000000 data Manual, Manual (Set Record Data), Interval, Analog Trigger, External Trigger, Manual Trigger, Complex Trigger nent Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Recorindg start time settable. nent Records data automatically based on the preset starting time and recording interval. ent Starts/stops recording data based on the preset trigger conditions. Settable

Analog Trigger Co Trigger Channe	
umaer i nanne	
Trigger Level	Physical quantity
Trigger Slope	Positive or Negative
External Trigger C	
Trigger Slope	Positive or Negative
Manual Trigger Co	
Complex Trigger	
Trigger Source	Select from the analog channels (any 4 channels of
rrigger source	the master unit), external trigger, or manual trigger.
	Capable of judging the trigger source by using the
	logical AND and OR operators.
Trigger Level	Physical quantity
Trigger Slope	Positive or Negative
CAN Trigger Con	
Common CAN	Trigger conditions
End Trigger	Settable
Delay	Only end.
	With measurement CH: Up to 174762 s,
	No measurement CH: Up to 65535 s
	The delay time varies with the sampling frequency
	and the number of channels.
Manual Trigger Co	
Analog Trigger C	onditions
Trigger Channel	Any 1 signal of the master unit
Trigger Level	Physical quantity
Trigger Slope	Positive or Negative
Digital Trigger Co	onditions
	Any 1 signal of the master unit
Trigger Bit	Any 1 bit
Trigger Slope	Positive, Negative, or Level
Complex Trigger	
Trigger Source	Trigger channel (any 8 signals of the master unit)
	Select form analog trigger or digital trigger.
	Trigger sources can be logically identified by
	AND / OR at once.
Repeated Recordi	
	the DCS-100A saves data, every preset
	number of data or every preset interval,
	in the KS3 format file.
	*Measure Mode: Manual (Set Record Data)
	only.
Data File	File name, File Title,
	Grant rule: File No. or Recording start time.
Thad C : d	File No.: 3 to 5 digits.
	Measured Data in the PC Folder
Sampling Frequer	ncies 1 Hz to 100k Hz (1-2-5 series, 2 ⁿ series, external clock)
File Size	*Limited by the number of channels.
	Up to the data drive capacity.
Measure Modes	Manual, Manual (Set Record Data), Interval, Analog Trigger
Manual Measurer	
iviariuai ivieasurei	the number of data, specified on the Manual
	(Set Record Data).
Interval Measuren	
	preset starting time and recording interval.
Analog Trigger M	easurement Starts/stops recording data based on
g mggci W	the preset trigger conditions.
	Settable
End Triager	
End Trigger	
End Trigger	Delay Up to 524288 data for both start and end.
	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels
Trigger Channels	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels; Any 1 channel
Trigger Channels Trigger Level	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels Any 1 channel Physical quantity
Trigger Channels Trigger Level Trigger Slope	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels Any 1 channel Physical quantity Positive or Negative
Trigger Channels Trigger Level Trigger Slope	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data,
Trigger Channels Trigger Level Trigger Slope	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels; Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data, the DCS-100A additionally saves the
Trigger Channels Trigger Level Trigger Slope	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data,
Trigger Channels Trigger Level Trigger Slope	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels: Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file.
Trigger Channels Trigger Level Trigger Slope Static Measurement	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels: Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file. *Measure Mode: Manual and Interval only.
Trigger Channels Trigger Level Trigger Slope Static Measurement	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels: Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file. *Measure Mode: Manual and Interval only. g When recording data for a long time, the DCS-100A
Trigger Channels Trigger Level Trigger Slope Static Measurement	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels: Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file. *Measure Mode: Manual and Interval only. g When recording data for a long time, the DCS-100A saves data, every preset number of data or every
Trigger Channels Trigger Level Trigger Slope Static Measurement	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file. *Measure Mode: Manual and Interval only. g When recording data for a long time, the DCS-100A saves data, every preset number of data or every preset interval, in the KS2 format file.
Trigger Channels Trigger Level Trigger Slope Static Measurement	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file. *Measure Mode: Manual and Interval only. g When recording data for a long time, the DCS-100A saves data, every preset number of data or every preset interval, in the KS2 format file. *Measure Mode: Manual (Set Record Data) only.
Trigger Channels Trigger Level Trigger Slope Static Measurement	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file. *Measure Mode: Manual and Interval only. When recording data for a long time, the DCS-100A saves data, every preset number of data or every preset interval, in the KS2 format file. *Measure Mode: Manual (Set Record Data) only. File name, File Title
Trigger Channels Trigger Level Trigger Slope Static Measurement	Delay Up to 524288 data for both start and end. *The delay time varies with the number of channels Any 1 channel Physical quantity Positive or Negative t Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file. *Measure Mode: Manual and Interval only. g When recording data for a long time, the DCS-100A saves data, every preset number of data or every preset interval, in the KS2 format file. *Measure Mode: Manual (Set Record Data) only.



Outline


Amplifier

Checker


Other

Dimensions


Compact Recorder CTRS-100A



Strain/Voltage Unit CTRS-CDV010A




Thermocouple Unit CTRS-CTA010A




*Including the temperature measuring adapter


Battery Unit CTRS-BATT010A



Synchronization Unit CTRS-SYNC010A



Wireless LAN Unit for U.S. CTRS-WLAN011A*1




 $^{*}1$ CTRS-WLAN010A is the same in dimensions.


CAN Unit CTRS-CAG010A

19.1 60 6xM4 d=6 (27.4) (96) 94

Voltage Unit CTRS-CVPS010A



Remote Control Unit CTRS-RCU010A





Simplified Configuration of the CTRS-100 Series







Table of Conversion cable for NDIS4109 (Small round 9 pins) Please use the conversion cables below if the end of the transducer or bridge box cable is the NDIS4102 (7 pins) or a similar connector.

Models	Sensor side	Measuring instrument side
N-129	S32-7 (4 pins)	
U-129	BNC jack	
U-136	S32-7 (6 pins)	4109p
U-137	BNC plug	
U-138	R05 jack	





EDX-10 Series

Compact Recording System



Compact & lightweight, with a simple configuration, all channels synchronous 20 kHz high-speed sampling (For 4 channels)

■Control Unit EDX-10B





This unit controls measuring units and performs communication with PC via USB interface.

The EDX-10 series is measuring instruments that measure simply by being connected to a PC using the USB interface.

The EDX-11A and EDX-14A measure strain-gage transducers, pressure, displacement, etc.
The EDX-12A measures voltage, the EDX-15A measures force, pressure, displacement, and voltage, and the

EDX-13A measures temperature with a thermocouple. A single unit for 4-channel measurement, 4 units for 16 channels, thus it is suitable for small-scale measurement.

Up to 4 measuring units are powered by USB interface, no separated power supply is required.

- •With stacked connection, no synchronization cable is required, therefore wiring-saving.
- Max. sampling frequency 20 k Hz for 4 channels of a single measuring unit in sync.
- Compact & lightweight
- Simple connection using USB interface
- •The standard accessory, Dynamic Data Acquisition Software DCS-100A, makes it easier to monitor or acquire data.
- Data is recorded as KS2, which is Kyowa standard file format. The optional Data Analysis Software reads the file.
- Sensors are easily connected with one-touch input cables or input adapters.

Specifications

Interfaces	USB2.0 compliant
	Connector configuration: USB standard B receptacle
Measurement Units	Max. 4 (16 channels)
Sampling Frequencies	1 Hz to 20 k Hz (1 to 4 channels)
	1 Hz to 10 k Hz (1 to 8 channels)
	1 Hz to 5 k Hz (1 to 16 channels)
Operating Temperature	0 to 40°C
Operating Humidity	20 to 90% (Non-condensing)
Power Supply	5 VDC USB bus-power*1,*2, or AC adapter*3
Current Consumption	140 mA or less (5 VDC)
Weight	Approx. 170 g
Dimensions	84.0 W × 26.6 H × 84.0 D mm
	(Excluding protrusions)
Control Software	DCS-100A
Compliance	Directive 2014/30/EU (EMC)
	Directive 2011/65/EU, (EU)2015/863
	(10 restricted substances) (RoHS)

Standard Accessories USB cable N-38 (1 m)
Ground wire P-72 (5 m)
DVD (Dynamic data acquisition software DCS-100A)

Optional Accessories AC adapter UN310-0515 (For U.S.A.: UN312-0520)

- *1 When using USB bus-power, please connect directly to the USB port of the PC without using a USB hub.
- *2 The number of measuring units at USB bus-power operation, refer to the following table.

USB ports	The number of EDX-11A	The maximum number of the unit
USB 3.0	0	Max. 4
	1	Max. 2
	2	IVIdX. 2
USB 2.0	0	Max. 2
	1	Max. 1

^{*3} When using AC adapter, the maximum connection units is 4 units in any combination of EDX-11A, 12A, 13A, 14A and 15A.

■Strain Measuring Unit EDX-14A



A low power consumption unit for measuring strain based on the DC bridge excitation.

Specifications

Measuring Targets	Strain-gage transducers, strain gages*
Channels	4
Measuring Range	10 k, 50 k ×10 ⁻⁶ strain (2 steps)
Compatible Bridge Resistance	120 Ω to 1 kΩ
Bridge Excitation	1 VDC
Gage Factor	2.00 fixed
Range Accuracy	Within ±0.3%FS
Balance Adjustment	Within ±1/2 F.S. of setting range
Nonlinearity	Within ±0.1%FS
AD Converter	24 bits
Frequency Response	DC to 2 kHz
LPF	Transfer characteristic: 2nd order Butterworth
	Cutoff frequencies: 100 Hz, 2 k Hz
Operating Temperature	0 to 40°C
Operating Humidity	20 to 90% (Non-condensing)
Input Connector	D-sub 37-pin connector
Power Supply	5 VDC supplied by control unit
Current Consumption	140 mA or less
	(120 Ω load with all channels connected,
	at power supply 5 VDC)
Weight	Approx. 150 g
Dimensions	84.0 W × 26.6 H × 84.0 D mm
	(Excluding protrusions)
Compliance	Directive 2014/30/EU (EMC)
	Directive 2011/65/EU, (EU)2015/863
	(10 restricted substances) (RoHS)

^{*}Bridge boxes or input adapters are required for strain measurement.

Optional Accessories Bridge box connection cable U-126 (50 cm) Input connector set EDX10-DSUB Input adapter UI-51A One-touch type input adapter UI-52A Bridge adapter for quarter bridge system UI-53B-120/350
Bridge adapter for quarter bridge system UI-54B-120/350 One-touch type input adapter UI-55A

■Strain/Voltage Measuring Unit EDX-15A



A unit for measuring both strain and voltage.

Specifications

Specifications	
Measuring Targets	Strain gage transducer and strain gage (*1)
	Voltage (Unbalanced input)
Channels	4
Measuring Range	Strain measurement: 10k, 50k×10 ⁻⁶ strain (2 range)
	Voltage measurement: 10, 50 V (2 range)
Compatible Bridge Resistance	Strain measurement: 120 to $1k\Omega$
	Voltage measurement:-
Bridge Excitation	Strain measurement: 1 VDC
	Voltage measurement:-
Gage Factor	Strain measurement: 2.00 fixed
	Voltage measurement:-
Range Accuracy	Within ±0.3%FS
Balance Adjustment	Within ±1/2 F.S. of setting range
Nonlinearity	Within ±0.1%FS
AD Converter	24 bits
Frequency Response	DC to 2 kHz
LPF	Transfer characteristic: 2nd order Butterworth
	Cutoff frequencies: 100 Hz, 2 k Hz
Operating Temperature	0 to 40°C
Operating Humidity	20 to 90% (Non-condensing)
Input Connector	D-sub 37-pin connector
Power Supply	5 VDC supplied by control unit
Current Consumption	150 mA or less
	(120 Ω load with all channels connected,
	at power supply 5 VDC)
Weight	Approx. 150 g
Dimensions	84.0 W × 26.6 H × 84.0 D mm
	(Excluding protrusions)
Compliance	Directive 2014/30/EU (EMC)
	Directive 2011/65/EU, (EU)2015/863
	(10 restricted substances) (RoHS)
*D:1 1 1	antors are required for strain measurement

^{*}Bridge boxes or input adapters are required for strain measurement.

Standard Accessories Strain input cable U-124 (30 cm) Conversion adapter FV-1A ×4 Bridge box connection cable U-126 (50 cm)

Optional Accessories

Input connector set EDX10-DSUB

Input adapter UI-51A One-touch type input adapter UI-52A Bridge adapter for quarter bridge system UI-53B-120/350

Bridge adapter for quarter bridge system UI-54B-120/350 One-touch type input adapter UI-55A BNC input cable U-125 (30 cm)



■Voltage Measuring Unit EDX-12A



A unit for measuring voltage

Specifications

Measuring Targets	Voltage
Channels	4 (Single end)
Measuring Range	10 V, 50 V (2 steps)
Range Accuracy	Within ±0.3%FS
Balance Adjustment	Within ±1/2 F.S. of setting range
Nonlinearity	Within ±0.1%FS
AD Converter	24 bits
Frequency Response	DC to 2 kHz
LPF	Cutoff frequencies: Lo(100Hz), Hi(2kHz)
	Transfer characteristic: 2nd order Butterworth
Operating Temperature	0 to 40°C
Operating Humidity	20 to 90% (Non-condensing)
Input Connector	D-sub 37-pin connector
Power Supply	5 VDC supplied by control unit
Current Consumption	110 mA or less (5 VDC)
Weight	Approx. 150 g
Dimensions	84.0 W × 26.6 H × 84.0 D mm
	(Excluding protrusions)
Compliance	Directive 2014/30/EU (EMC)
	Directive 2011/65/EU, (EU)2015/863
	(10 restricted substances) (RoHS)
Standard Assessmina	

Standard Accessories Input adapter UI-51A Optional Accessories

BNC input cable U-125 (30 cm) Bridge box connection cable U-126 (50 cm) Input connector set EDX10-DSUB One-touch type input adapter UI-52A

■Thermocouple Measuring Unit EDX-13A



A unit for measuring temperature by using thermocouples

Specifications

Measuring Targets	Thermocouples			
Channels	4			
Measuring Targets	K, T, J, N (Resistance of thermocouple: 1 $k\Omega$ or less			
	(See the table below for details about the			
	temperature measuring range, etc.)			
Check Functions	Burnout check			
AD Converter	24 bits			
Sampling System	Scanning			
Inside Sampling Frequencies	Approx. 0.5 Hz, approx. 2.0 Hz			
Operating Temperature	0 to 40°C			
Operating Humidity	20 to 90% (Non-condensing)			
Input Connector	Screw type terminal box			
Power Supply	5 VDC supplied by control unit			
Current Consumption	120 mA or less (5 VDC)			
Weight	Approx. 130 g			
Dimensions	84.0 W × 26.6 H × 84.0 D mm			
	(Excluding protrusions)			
Compliance	Directive 2014/30/EU (EMC)			
	Directive 2011/65/EU, (EU)2015/863			
	(10 restricted substances) (RoHS)			
Standard Accessories Termina	al box 1piece, screwdriver 1piece			

Types Range Accuracy (Resolution: 0.1 °C) \pm (0.2% of reading + 0.6°C) \pm (0.1% of reading + 0.4°C) −200.0 to below -100.0°C −100.0 to 1370.0°C −200.0 to 1370.0°C −200.0 to below -100.0°C −100.0 to 400.0°C \pm (0.2% of reading + 0.6°C) \pm (0.1% of reading + 0.4°C) -200.0 to 400.0°C \pm (0.2% of reading + 0.6°C) \pm (0.1% of reading + 0.4°C) −200.0 to below -100.0°C −100.0 to 1200.0°C −200.0 to 1200.0°C −200.0 to below -100.0°C −100.0 to 1300.0°C \pm (0.2% of reading + 0.6°C) -200.0 to 1300.0°C \pm (0.1% of reading + 0.4°C)

+1 0°C (Input terminal temperature at equilibrium) (Ambient temperature: 25 ±10°C) Mount the EDX-13A on the bottom when using it with measuring units other than the EDX-13A.


Accuracy of internal reference junction compensator

(Input terminal temperature in equilibrium) For temperatures other than those in the ambient temperature and operating temperature described above

Note: The measurement accuracy does not include the accuracy of the internal reference junction compensator and thermocouples.

- The measurement error of the internal reference junction compensator
- = Error due to the measurement accuracy
- + Error of the internal reference junction compensator
- + Error of the thermocouples

To satisfy the accuracy of internal reference junction compensator ±1.0°C, measurement conditions are as follows. Condition 1: Mount the EDX-13A on the bottom when using it with measuring units other than the EDX-13A. Condition 2: When measuring data, put the units down.





■Strain Measuring Unit EDX-11A



A unit for measuring strain based on the DC bridge excitation.

Specifications

Measuring Targets	Strain-gage transducers, strain gage*
Channels	4
Measuring Range	10 k, 50 k ×10 ⁻⁶ strain (2 steps)
Balance Adjustment	Within ±1/2 F.S. of setting range
Compatible Bridge Resistance	120 Ω to 1 kΩ
Bridge Excitation	2 VDC
Gage Factor	2.00 fixed
Range Accuracy	Within ±0.3%FS
Nonlinearity	Within ±0.1%FS
AD Converter	24 bits
Frequency Response	DC to 2 kHz
LPF	Transfer characteristic: 2nd order Butterworth
	Cutoff frequencies: 100 Hz, 2 k Hz
Operating Temperature	0 to 40°C
Operating Humidity	20 to 90% (Non-condensing)
Input Connector	D-sub 37-pin connector
Power Supply	5 VDC supplied by control unit
Current Consumption	180 mA or less
	(120 Ω load with all channels connected,
	at power supply 5 VDC)
Weight	Approx. 150 g
Dimensions	84.0 W × 26.6 H × 84.0 D mm
	(Excluding protrusions)
Compliance	Directive 2014/30/EU (EMC)
	Directive 2011/65/EU, (EU)2015/863
	(10 restricted substances) (RoHS)

^{*}Bridge boxes or input adapters are required for strain measurement.


Standard Accessories	Strain input cable U-124 (30 cm)
Optional Accessories	Bridge box connection cable U-1


Bridge box connection cable U-126 (50 cm)
Input connector set EDX10-DSUB
Input adapter UI-51A
One-touch type input adapter UI-52A, UI-55A
Bridge adapter for quarter bridge system UI-53B-120/350
Bridge adapter for quarter bridge system UI-54B-120/350

DCS-100A software (standard accessory), specification for control of EDX-10B


roi details of DC3	-100A, see chapter 4.
Units	Up to 4 units (up to 16 channels)
Interfaces	USB
Saving Format	Saves the measured data in the PC folder in the
	KS2 format file.
Channel Conditions	Measuring ON/OFF, Measuring mode, Range,
	Low-pass filter, Balance adjustment
	ON/OFF, Calibr. const., Offset, Unit,
	Channel name, Measuring range, Rated capacity,
	Rated output, Deci Digits, Chk. Val. (Up), Chk. Val.
	(Down)(Display items can freely be selected.)
Sampling Frequency	1 Hz to 20k Hz (1/2/5 system)
	*Limited by the number of channels.
Measure Mode	Manual, Manual (Set Record Data), Interval,
	Analog Trigger
Manual Measurement	Records data from REC to STOP or from REC to
	the number of data, specified on the Manual
	(Set Record Data).
Interval Measurement	Records data automatically based on the pre-set
	starting time and recording interval.
Analog Trigger Measu	rement Starts/stops recording data based on the
	pre-set trigger conditions.
Trigger Condition	End trigger Settable
99	Delay Up to 262144 data/CH for both start and end.
	The delay time varies with the number of channels.
	Trigger channel Any 1 channel
	Trigger level Physical quantity
	Trigger slope Positive or Negative
Static Measurement	Static measurement Every time the DCS-100A
Static Weasarement	starts recording data, the DCS-100A additionally
	saves the moving-averaged measured data in a
	single CSV format file.
	*Measure Mode: Manual and Interval only.
Repeated Recording	When recording data for a long time,
Repeated Recording	the DCS-100A saves data, every pre-set number
	of data or every pre-set interval, in the KS2
	format file.
	*Measure Mode: Manual (Set Record Data) only.
Setting Environment	ivicasare ivioue. Iviariaal (set Necora Data) Offly.
	onfiguration
	ninguration
Setting Hardware Co	Sate the device names and measuring units
Setting Hardware Co	Sets the device names and measuring units.
Setting Hardware Co	Sets the device name to the EDX-10B.
Setting hardware Co	












Simplified configuration of the EDX-10 series





EDX-200A

Universal Recorder



Improved real-time processing function with high-speed DSP

- •Incorporated real-time digital filter. 8th digital filter enables acquisition of clear waveform.
- High-speed/low-speed dual sampling Measurement of high-speed and low-speed phenomena while reducing data quantities is possible.
- All channels synchronous 10 kHz high-speed sampling (For 32 channels) Measurement of 3 channels synchronous at max. 100 kHz
- Variety of input conditioner cards
- ●One-wire synchronous (Except EDX-200A-1) With a maximum of 8 units, large scale measurements in distributed arrangement can be supported.

● Conditioner cards (See page 3-93.)

Strain/Voltage/Acceleration Measurement Card CVM-41A Strain/Voltage Measurement Card CDV-40B(-F) Dynamic Strain Amplifier Card DPM-42B DPM-42B-F DPM-42B-I DPM-42B-I-F CTA-40A Thermocouple Card CFV-40A F/V Converter Card Charge Amplifier Card CCA-40A(-F) **CAN Card** CAN-41A CDV-44AS/46AS Strain/Voltage Measurement Isolation Card Constant Current Amplifier Card CDA-44AS/45AS **AD Converter Cards** AD-40AS(-F)

Option cards (See page 3-81.)

Multichannel CAN card ECAN-40A Time synchronization card ETIM-40A GPS/multichannel CAN card EGPC-40A

Specifications

Models Slots for optional functions Slots for Model name DCS-100A*2 DCS-101A*3 Channels cards EDX-200A-2H Yes EDX-200A-2H-0 16 2 EDX-200A-2H-1 Yes Yes EDX-200A-4H Yes EDX-200A-4H-0 4 32 EDX-200A-4H-1 Yes Yes EDX-200A-4T Yes EDX-200A-4T-0 32 4 EDX-200A-4T-1 Yes Yes EDX-200A-1 Yes EDX-200A-1-1 Yes Yes

Notes: *1. Max. input channels are when 8 channels input cards inserted. *2. Dynamic Data Acquisition Software

*3. Simultaneous Acquisition of Video and Numeric Data/Arithmetic

Operati	ions/FFT Analysis Optional Software
Measuring Targets	Strain (Gage, transducer), voltage, thermocouples,
	pulse (F/V), piezoelectric acceleration (Built-in amplifier),
	CAN signals, GPS
Conditioner Cards f	for Analog Inputs
	The conditioner cards for EDX series
	(For the details, see page 3-93.)
	[Note] The EDX-200A-4T can use only the CVM-41A,
	CDV-40B, CDV-40B-F and CAN-41A which
	performed temperature extension processing.
	When you use the EDX-200A-4T, you cannot
	replace any conditioner cards.
	[Note] The EDX-200A limits the number of CFV-40A.
	EDX-200A-1/2H: The number of CFV-40A is up to 1.
	EDX-200A-4H: The number of CFV-40A is up to 2.
Conditioner Cards 1	for CAN Data Inputs
	CAN card (2 ports, max. 256 channels): CAN-41A
	[Note] Can install one CAN-41A to the final slot.
	[Note] The EDX-200A-4T can use only the CAN-41A
	which performed temperature
	extension processing.
	When you use the EDX-200A-4T,
	you cannot replace any conditioner cards.
Voice Memo Input	1 channel (Voice memo can be recorded with
	measured data.)
	The RCU-42A (optional) is necessary.
	To playback the recorded voice memo,
	use the DAS-200A (optional).
Sampling	
	Simultaneously all channels
Sampling Mode	Normal: Records all channels' data at the same
	sampling clock.
	Dual: Enables high-speed sampling or low-speed
	sampling to every CH for recording.



C 1' 5	
Sampling Frequencies Normal-sampling Mo	nde
	to 100 kHz
1 Hz 1	to 2 kHz When using CAN-41A
2 ⁿ series 2 to 6	55536 Hz
	2048 Hz When using CAN-41A
Dual-sampling Mode	
	peed sampling [Sf]
1-2-5	5 series 1 Hz to 100 kHz 1 Hz to 2 kHz when using CAN-41A
2 ⁿ se	
2 30	2 to 2048 Hz when using CAN-41A
Low-sp	peed sampling [Ss]
1-2-5	series The division frequencies from
	high-speed sampling, and $Ss \le Sf/4$
2 ⁿ se	
Classical	high-speed sampling, and $Ss \le Sf/4$
Channels Normal-sampling Mod	e Max. 32 channels, 320 k/I (I is the integer part
Normal-sampling Mod	of the set sampling frequency.)
Dual-sampling Mode	Max. 64 channels, 320 k/I (I is the integer part
	of the set sampling frequency.). "High-speed
	and low-speed" setting counts as 2 channels.
When Using CAN-41A	EDX-200A-4H Max. 24 + Channels of CAN data
	EDX-200A-2H Max. 8 + Channels of CAN data
	EDX-200A-1 Channels of CAN data EDX-200A-4T Max. 24 + Channels of CAN data
The Number of Sampling	
Normal-sampling Mod	e
	00/ The number of channels" or less
Dual-sampling Mode	
High-s	peed sampling frequency: "320000/ The number
#. v. 1	of channels" or less.
	speed and low-speed" setting counts as 2 channels.
	worth filter (IIR) f filter: LPF, HPF
	of a filter: 1 to 8
	ude ratio at cutoff point: -3dB
Attenu	nation: -6 × N dB/oct. (N is order of the filter)
	aneously use with built-in LPF possible.
	ation on CAN data not possible.
Data Recording Unit CF card	ı
	ty: 128 MB to 16 GB (our recommended only)
	uum data file size (available data file size to be
record	·
	the number of repeat times is 1:4 GB/data file the number of repeat times is 2:1 GB/data file
	1000000000 bytes)
Indicator Chann	el status display LED:
EDX-2	200A-2H: 16; EDX-200A-4H/4T: 32; EDX-200A-1: 8
	atus display LED:
	200A-2H/4H/4T: 7; EDX-200A-1: 4
	atus display organic EL monitor:
	200A-2H/4H/4T: 1; EDX-200A-1: 0
Control Switch	- diada a sa tha sa diada a
REC/PAUSE: Starts and	ne display on the small indicator.
STOP : Stops data	
BAL. : Execute the	
	sets conditions.
	he pre-set arbitrary function.
ID : Sets the ED	X-200A identification No.
POWER : POWER sw	
	ommunication interface (USB /LAN)
	1 does not have the UP/DOWN switch and
ID switch. External Control Connector	CONT IN and CONT OUT for remarks as a trail
External Control Connecto	or CONT. IN and CONT. OUT (for remote control and synchronous operation)
	[NOTE] The EDX-200A-1 does not have the
	CONT. OUT connector for the
	synchronous operation
Communication interface	usb(USB2.0 High Speed) 1 port
	Connector: Series B receptacle connector
	LAN(10/100BASE-T) 2 ports
	LAN IN connector: For PC communication
	LAN OUT connector For synchronous operation
	Connector: RJ45 modular jack connector [NOTE] The EDX-200A-1 does not have the
	LAN OUT connector for the
	synchronous operation.
Synchronous Operation	synchronous operation. Max. 8 EDX-200A units can be connected for
Syncinonous Operation	synchronous operation by using synchronous
	cables N-95 N-128.
	Max. 8 EDX-200A units can be connected for
	synchronous operation by using LAN cables.
	[NOTE] The synchronous operation is not
	available with the EDX-200A-1.

How To Setti	ing Condition	าร	
			n the PC via the LAN or USB
	interface.		
Offline setti	ing: Set meas	uring conditions by	y allowing the EDX-200A to
			in the CF card. (Use DCS-100A
Saving Cond		asuring conditions	ards' setting conditions and
			ry in the EDX-200A.
			can immediately start data
		y set conditions.	
Measuring N			trigger measurement/
Manual M		val measurement The user starts an	d stops data recording,
Widiradirivi	casarcinent		is stopped according to
		the previously set	
			be recorded simultaneously
Tui manau Ma		when measuring	in this mode cally recorded with preset
rrigger ivie	easurement	trigger conditions	
			asurement is not available
			ta of the CAN-41A
Interval M	easurement		ally recorded with preset
	Available mea	interval condition	dual-sampling mode
,			Low-speed sampling channel
		measurement	Manual measurement
	Trigger	measurement	Manual measurement
			Interval measurement
C: : 1		measurement	Interval measurement
Starting and	Stopping Da	ta Recording	arts/stops by using the PC,
		panel switches or	
Balance Oper	ration		of the strain input channel and
			uppress of the voltage input CH
			y using the PC, control switches
Format of Re	corded Data	(on the front pane KYOWA's standar	
romat or Ke	corueu Data		it can be analyzed using the
			A Data Analysis Software.
Data Collecti	on	Online data collec	tion using the PC or
			tion by allowing the PC to
TEDS Function		directly read the C	vailable only when online
TED3 FUNCTIO	וונ	control from the F	
			conditioner cards: CDV-40B (-F),
			M-42B-I (-F), CCA-40A (-F),
			4AS, CDA-45AS, CVM-41A
Power Suppl	У	EDX-200A-4H: 10 EDX-200A-2H: 10	
		EDX-200A-2H. 10	
		EDX-200A-4T: 10	
			RM12BRD-4PH (Hirose)
Current Cons	sumption	EDX-200A-2H: Ap	
			th 4 CDV-40B cards installed)
		(12 VDC with	th 2 CDV-40B cards installed)
		EDX-200A-4T: Ap	
			th 4 CDV-40B cards installed)
		EDX-200A-1: Ap	
0 " T			th 1 CDV-40B card installed)
Operating To Operating H		20 to 90% (Non-c	00A-4T: -20 to 65°C)
Storage Tem			200A-4T: -30 to 70°C)
Vibration Re	sistant		
			n axis 15 cycles (Non-operating)
			n axis 15 cycles (Operating)
Dimensions			294.2 m/s ² for EDX-200A-1
Difficiations	(Excluding pi		5 W × 132.5 H ×255 D mm
			0 W × 132.5 H ×255 D mm
			5.2 W × 142.8 H ×255D mm
\\\o:=k+			W x 53 H x 257 D mm
Weight			prox. 2.1 kg (Approx. 2.6 kg th 4 CDV-40B cards installed.)
			prox. 1.8 kg (Approx. 2.0 kg
		wit	h 2 CDV-40B cards installed.)
			prox. 3.7 kg (Approx. 4.2 kg
			h 4 CDV-40B cards installed.)
			rox. 0.9 kg (Approx. 1.1 kg h 1 CDV-40B card installed.)
Compliance		Directive 2014/3	
		(EDX-200A-1 only	y)
			5/EU, (EU)2015/863
		(10 restricted sub (EDX-200A-1 only	
		(LDV-ZOOA- LOUI)	y <i>)</i>





Standard Accessories

DC power cable P-76

USB cable N-38

Ground wire P-72

CF card (1 GB) inserted in the slot

Fuses (8 A for 4-slot model, 5 A for 2-slot model)

Dummy panel

Installed on the free slots before shipment

EDX-200A-4H: 3 pcs

EDX-200A-2H: 1pc

EDX-200A-4T: None

EDX accessory bag

Dynamic data acquisition software DCS-100A (DVD)*

*DCS-100A is optional for models with suffix "-0

Instruction manual (In English & Japanese, in the above DVD)

Optional Accessories

Synchronous cable N-128

EDX-200A AC adapter 4H, 4T: UEA360-1540 (For U.S.A.: SPU61A-106 15 V) EDX-200A AC adapter 2H, -1: UIA345-12 (For U.S.A.: UNI345-1238) Fixing adapter EDX dummy panel EDX1P-DUMMY Remote control unit RCU-42A Battery unit for instantaneous power failure EDB-41B (EDX-200A-2H/4H) Monitor unit EMON-20A

DCS-100A software (standard accessory), specification for control of EDX-200A

(Not included with EDX-200A-4H-0, EDX-200A-2H-0) *For details of DCS-100A, see chapter 4.

Tor actains or Des	TOUA, see chapter 4.
Units	Up to 8 units (up to 256 channels.)
Interfaces	LAN or USB
Saving Format	Saves the measured data in the EDX-200A CF card
	or PC folder in the KS2 format file.
Channel Conditions	Measuring ON/OFF, Measuring mode, Range,
	High-pass filter, Low-pass filter, Balance adjustment
	ON/OFF, CAL range, CAL ON/OFF, Calibr. const.,
	Offset, Unit, Channel name, Measuring range,
	Rated capacity, Rated output, Deci Digits,
	Chk. Val.(Up), Chk. Val. (Down), Internal sensitivity
	compensation ON/OFF, Offset ZERO ON/OFF,
	Digital filter (High-pass filter: Any cutoff frequency,
	Low-pass filter: Any cutoff frequency), Sampling
	frequency (High, Low, High + Low)
	(Display items can freely be selected.)
Loading TEDS Sensor I	nformation
	Loads the TEDS information automatically and sets
	the channel conditions.
Dual-sampling Measu	rement
	The high-speed sampling data and low-speed
	sampling data appear on the Numeric windows/
	Graph windows.
	The high-speed sampling data and low-speed
	sampling data are saved in different files.
Setting Parameter and	l Loading Parameter
	Loads and sets the EDX-200A internal parameter.
Collecting Data File	PC collects the KS2 format file saved in the
	EDX-200A CF card, via LAN/USB.
Deleting Data File	PC deletes the KS2 format file saved in the
	EDX-200A CF card, via LAN/USB.
Formatting CF Card	PC formats the EDX-200A CF card via LAN/USB.
Setting Environment	
Setting Hardware Co	
	Sets the number of units and device names.
	Loads the hardware configurations from the EDX-200A.
	Loads the EDX-200A version.
Setting IP Address	PC sets the EDX-200A via LAN/USB.
	Saves the IP address setting file in the CF card.
Device Confirmation	LEDs, on the EDX-200A front panel, light up.
Others	Oscillator switching (internal/external), operating
	beep sound, balance standard value, AD data
	format (16 bits/24 bits), synchronous operation

mode (Use or Not in use) Applicable Optional Cards

Applicable optional cards					
Functions		synchronization)	Point ZERO (Manual) Measurement *1, *2	Recording GPS Data *1, *2	Setting DIO *3
ECAN-40A	Yes				Yes
ETIM-40A		Yes	Yes	Yes	Yes
EGPC-40A	Yes	Yes	Yes	Yes	Yes

- *1: When data is saved in CF card
- *2: When the card is installed in host EDX
- ${}^{\star}3$: When control signals are from a remote control unit
 - A. Data is saved in the CF card.
 - $B.\ If\ synchronous\ operation,\ only\ host\ EDX\ is\ settable.$

CAN Data Acquisition	Max. 512 channels/unit of CAN data is possible.
	(In the EDX-200A CF Card, as the E4A file).
Point Zero Manual Me	
	In multiple units of EDX-200A, allows acquisition
	to be started at zero second (0 ms) based on clock
GPS Synchronous Inter	data of GPS satellite.
dra synchronous inter	Allows multiple units of EDX-200A to be started
	acquisition based on clock data of GPS satellite.
GPS Data Acquisition	Monitors and records GPS data such as latitude,
	longitude, direction of movement, speed.
	GPS data is saved to CF card in EDX-200A as
	NMEA format.
DIO Settings	
I/O Points	Max. 8
I/O Settings	Sets every bit of digital input, digital output,
	and remote-control input.
	ns for Saving Data in CF Card
Sampling Frequencies	
	(1-2-5 series, 2° series, or external clock)
	(Depends on measuring channels. Dual sampling is supported.)
Data File Size	Max. 4 GB
Measuring Modes	Manual, manual (Data points preset), interval,
	analog trigger, external trigger, and composite
	trigger
Manual Measurement	Measurement is made from a press of the REC
	button to a press of the STOP button or by
	completion of recording using a preset number of
	measurements.
Interval Measurement	Measurement is made automatically at preset
	intervals from the preset starting time.
Trigger Measurement	Start/stop recording based upon specified
	trigger conditions.
Common Trigger Conditi	
End Trigger	Settable
Delay	Up to 262144 data for both start and end.
Analog Trigger	The delay time varies with the number of channels
Trigger Channels	Any channel
Trigger Level	Sets in physical quantity.
Trigger Slope	Up, down
External Trigger Condi	
Trigger Slope	Up, down
Composite Trigger Cor	
Trigger Source	Select from the analog channels (Any 4 channels o
	the master unit), external trigger, or manual trigger
	Capable of judging the trigger source by using the
	logical AND and OR operators.
Trigger Level	Sets in physical quantity.
Trigger Slope	Up, down on In long-term data acquisition, a specified
Repetition Acquisition	amount of data (or time) is saved in KS2 file.
	*Workable in manual mode (Data points preset)
■Measuring Conditio	ns for Saving Data in PC Hard Disk
Sampling Frequencies	
Janualliu Freduencies	
Jamping Frequencies	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series,
Data File Size	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock)
	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock) Capacity of the hard disk
Data File Size	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger
Data File Size	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to
Data File Size Measuring Modes	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger
Data File Size Measuring Modes Manual Measurement	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data).
Data File Size Measuring Modes	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset
Data File Size Measuring Modes Manual Measurement Interval Measurement	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval.
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval.
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement data based on the preset trigger conditions. Settable
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement data based on the preset trigger conditions. Settable Up to 262144 data for both start and end.
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement g data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels.
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay Trigger Channels	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement g data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels. Any 1 channel
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay Trigger Channels Trigger Level	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement g data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels. Any 1 channel Physical quantity
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay Trigger Channels Trigger Level Trigger Slope	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement g data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels. Any 1 channel Physical quantity Up, down
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay Trigger Channels Trigger Level	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement g data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels. Any 1 channel Physical quantity Up, down Every time the DCS-100A starts recording data,
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay Trigger Channels Trigger Level Trigger Slope	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement g data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels. Any 1 channel Physical quantity Up, down Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay Trigger Channels Trigger Level Trigger Slope	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement g data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels. Any 1 channel Physical quantity Up, down Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay Trigger Channels Trigger Level Trigger Slope Static Measurement	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels. Any 1 channel Physical quantity Up, down Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file in manual and interval modes.
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay Trigger Channels Trigger Level Trigger Slope	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels. Any 1 channel Physical quantity Up, down Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file in manual and interval modes. In long-term data acquisition, a specified
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay Trigger Channels Trigger Level Trigger Slope Static Measurement	1 Hz to 100 kHz (1-2-5 series, 2 ⁿ series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels. Any 1 channel Physical quantity Up, down Every time the DCS-100A starts recording data, the DCS-100A additionally saves the moving-averaged measured data in a single CSV format file in manual and interval modes. In long-term data acquisition, a specified amount of data (or time) is saved in KS2 file.
Data File Size Measuring Modes Manual Measurement Interval Measurement Analog Trigger Measu Starts/stops recording End Trigger Delay Trigger Channels Trigger Level Trigger Slope Static Measurement	1 Hz to 100 kHz (1-2-5 series, 2° series, or external clock) Capacity of the hard disk Manual, manual (Data points preset), interval, and analog trigger Records data from REC to STOP or from REC to the number of data, specified on the Manual (Set Record Data). Records data automatically based on the preset starting time and recording interval. rement data based on the preset trigger conditions. Settable Up to 262144 data for both start and end. The delay time varies with the number of channels. Any 1 channel Physical quantity Up, down Every time the DCS-100A starts recording data, the DCS-100A additionally saves the movingaveraged measured data in a single CSV format file in manual and interval modes. In long-term data acquisition, a specified

●Remote Control Unit RCU-42A


The front panel operation of the mainframe can be performed on this remote control unit. With a buzzer from the unit, an alarm sound can be clearly heard even when the sound from the device is missed.




Control Functions	REC/PAUSE: Starts/pauses data acquisition
	STOP: Stops data acquisition
	BAL: Balancing
	OPT. : Optional function
	VOICE MEMO: Recording with the built-in microphone
Indication	Recording, pausing and balancing are indicated with LED.
Buzzer	Equivalent to the EDX recorder unit buzzer
Cable Length	Approx. 1.5 m
Dimensions	35 W× 125 H×22 D (mm) *Excluding protrusions
Weight	Approx. 220 g


■ Dimensions


EDX-200A-2H



EDX-200A-4H










Simplified configuration of the EDX-200A









EDX-200A-2H/4H/4T Option Cards



The option cards for EDX-200A which can measure CAN data and GPS information.

■Multichannel CAN Card ECAN-40A

- ●CAN input of up to 512 channels
- ●Capable of CAN data output
- •With software DCS-105A to read CANdb files.

With this card installed in the option slot, CAN input of up to 512 channels can be added without sacrificing the number of analog input channels.

■Time Synchronization Card ETIM-40A

- Enable synchronized interval measurement between remotely-placed EDX-200A units by receiving clock data from GPS satellite.
- GPS sensor (Standard Accessory)

ETIM-40A inserted to the option slot enables synchronous interval measurement among multiple units of EDX-200A based on clock data of GPS satellite. GPS data including position data, also can be acquired.

■GPS/Multichannel CAN Card EGPC-40A

- Simultaneous acquisition of GPS & CAN data (Up to 512 channels)
- •GPS data acquisition without using a PC

EGPC-40A inserted to the option slot enables simultaneous acquisition of CAN and GPS data or synchronous start of multiple units of EDX-200A.

ECAN-40A Specifications

	EDX-200A-4H EDX-200A-2H		
Applicable Models			
	(Installed in option slot)		
	*For EDX-200A-4T, please use ECAN-40A M72.		
CAN Ports	2 (High-speed CAN/low-speed CAN selectable)		
Channels Up to 512 (Total for 2 ports)			
Compatible CAN In	put Channels CAN2.0A/B (Conforming to ISO-11898,		
	ISO-11519-2)		
	peed CAN		
	0, 800, 500, 250, 125, 100, 83.3, 62.5, 50, 33.3, 25, 20,		
	10 [kbps]		
Low s	peed CAN		
125	, 100, 83.3, 62.5, 50, 33.3, 25, 20, and 10 [kbps]		
CAN Data Output			
Output at start: O	utput any given CAN data when AD conversion starts		
Output at stop: Ou	utput any given CAN data when AD conversion stops		
Manual output: O	utput any given CAN data at an arbitrary timing.		
Interval output: O	utput any given CAN data in a predetermined fixed cycle.		
Digital I/O			
I/O Points	Max. 8		
I/O Settings	Switch among digital input, digital output and		
	remote-controlled input for each bit		
	(Common applied to all).		
	*Remote control input: Start and stop measuring,		
	execute BAL, etc.		
Input Type	Isolated type, TTL level input		
Input Voltage	Max. 5 VDC		
Isolation Method	s Digital isolator		
Output Type	Isolated type, open collector type output		
	(With 10 kΩ internal pull-up resistors)		
Output Voltage	5 VDC		
Output Current	25 mA max. (Per point)		
Isolation Method			
Connector Type	CAN port D-sub connector (Male) 9-pin		
, , , , , , , , , , , , , , , , , , ,	Digital I/O port MDR connector (Female) 14-pin		
Operation Tempera	ture 0 to 50°C, ECAN-40A M72 is -20 to 65°C		
Operation Humidit			
Storage Temperatu	-		
Dimensions	22.0 W × 128.0 H × 221.5 D mm		
Weight	Approx. 170 q		
Compliance	Directive 2014/30/EU (EMC)		
	Directive 2011/65/EU, (EU)2015/863		
	(10 restricted substances) (RoHS)		
	(10 restricted substances) (Norra)		

Note: When using EDX-200A and DCS-101A for arithmetic operation, no CAN measurement is possible.

Standard Accessories Connector plug for digital I/O ports CANdb File Read Optional Software DCS-105A



ETIM-40A Specifications

Applicable Models	EDX-200A-4H, EDX-200A-2H
	(Installed in the option slot)
	*For EDX-200A-4T, please use ETIM-40A M72.
Synchronization	Synchronizes the recording start time of remote
	EDX-200A units by using the time data received
	from GPS satellites.
GPS Data	Latitude, longitude, elevation, course over ground,
	speed, time, receiving conditions, the number
	of satellites in use, etc.
	Saving format: NMEA format
Digital I/O	
I/O Points	Max. 8
I/O Settings	Switch among digital input, digital output and
	remote-controlled input for each bit
	(Common applied to all).
	*Remote control input: Start and stop measuring,
	execute BAL, etc.
Input Type	Isolated type, TTL level input
Input Voltage	Max. 5 VDC
Isolation Methods	Digital isolator
Output Type	Isolated type, open collector type output
	(With 10 kΩ internal pull-up resistors)
Output Voltage	5 VDC
Output Current	25 mA max. (Per point)
Isolation Methods	Digital isolator
Connector Type	GPS sensor port D-sub connector (Male) 9-pin
	Digital I/O port MDR connector (Female) 14-pin
Operation Temperature	0 to 50 °C
	ETIM-40A M72 is -20 to 65°C
Operation Humidity	20 to 90% (Non-condensing)
Storage Temperature	-20 to 60 °C
	ETIM-40A M72 is -30 to 70°C
Dimensions	22.0 W × 128.0 H × 221.5 D mm
Weight	Approx. 160 g
Compliance	Directive 2014/30/EU (EMC)
	Directive 2011/65/EU, (EU)2015/863
	(10 restricted substances) (RoHS)

Standard Accessories Connector plug for digital I/O ports
GPS sensor (Cable length: 5 m)
Shell case

EGPC-40A Specifications

Applicable Models EDX-200A-4H, EDX-200A-2H (Installed in option slot) *For EDX-200A-4T, please use EGPC-40A M7: I/O Ports GPS/CAN Shared Port 1 Dsub connector 9 pin CAN only port 1 Dsub connector 9 pins (male Digital I/O port 1 MDR connector 14 pins (fer	
*For EDX-200A-4T, please use EGPC-40A M7: I/O Ports GPS/CAN Shared Port 1 Dsub connector 9 pir CAN only port 1 Dsub connector 9 pins (male Digital I/O port 1 MDR connector 14 pins (fer	
I/O Ports GPS/CAN Shared Port 1 Dsub connector 9 pin CAN only port 1 Dsub connector 9 pins (male Digital I/O port 1 MDR connector 14 pins (fer	
CAN only port 1 Dsub connector 9 pins (male Digital I/O port 1 MDR connector 14 pins (fer	
Digital I/O port 1 MDR connector 14 pins (fer	
	nale)
Channels Up to 512	
Compatible CAN Versions CAN2.0A/B (Conforming to ISO-118	98,
ISO-11519-2)	
Baud Rates High speed CAN	
1000, 800, 500, 250, 125, 100, 83.3, 62.5, 5	0, 33.3,
25, 20, and 10 [kbps]	
Low speed CAN	
125, 100, 83.3, 62.5, 50, 33.3, 25, 20, and 1) [kbps]
CAN Data Output	
Output at start: Output any given CAN data when AD conversion	
Output at stop: Output any given CAN data when AD conversion	
Manual output: Output any given CAN data at an arbitrary timing	
Interval output: Output any given CAN data in a predetermined fix	
GPS Data Latitude, longitude, elevation, course over	
speed, time, receiving conditions, the number	er
of satellites in use, etc.	
Saving format: NMEA format	
Synchronization Synchronizes the recording start time of remo	
EDX-200A units by using the time data receiv	ed
from GPS satellites.	
Digital I/O	
I/O Points Max. 8	
I/O Settings Switch among digital input, digital output an	d
remote-controlled input for each bit	
remote-controlled input for each bit (Common applied to all).	
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc.	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator)	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors)	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors) Output Voltage 5 VDC	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors) Output Voltage 5 VDC Output Current 25 mA max. (Per point)	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop mease execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors) Output Voltage 5 VDC Output Current 25 mA max. (Per point) Operation Temperature 0 to 50 °C	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors) Output Voltage 5 VDC Output Current 25 mA max. (Per point) Operation Temperature 0 to 50 °C EGPC-40A M72 is -20 to 65°C	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors) Output Voltage 5 VDC Output Current 25 mA max. (Per point) Operation Temperature 0 to 50 °C EGPC-40A M72 is -20 to 65°C Operation Humidity 20 to 90% (Non-condensing)	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors) Output Voltage 5 VDC Output Current 25 mA max. (Per point) Operation Temperature 0 to 50 °C EGPC-40A M72 is -20 to 65 °C Operation Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60 °C	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors) Output Voltage 5 VDC Output Current 25 mA max. (Per point) Operation Temperature 0 to 50 °C EGPC-40A M72 is -20 to 65 °C Operation Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60 °C EGPC-40A M72 is -30 to 70 °C	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors) Output Voltage 5 VDC Output Current 25 mA max. (Per point) Operation Temperature 0 to 50 °C EGPC-40A M72 is -20 to 65 °C Operation Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60 °C EGPC-40A M72 is -30 to 70 °C Dimensions 22.0 W × 128.0 H × 221.5 D mm	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors) Output Voltage 5 VDC Output Current 25 mA max. (Per point) Operation Temperature 0 to 50 °C EGPC-40A M72 is -20 to 65 °C Operation Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60 °C EGPC-40A M72 is -30 to 70 °C Dimensions 22.0 W × 128.0 H × 221.5 D mm Weight Approx. 170 g	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type	uring,
remote-controlled input for each bit (Common applied to all). *Remote control input: Start and stop meas execute BAL, etc. Input Type Isolated type (Digital isolator), TTL level input Input Voltage Max. 5 VDC Output Type Isolated type (Digital isolator) Open collector type output (With 10 kΩ internal pull-up resistors) Output Voltage 5 VDC Output Current 25 mA max. (Per point) Operation Temperature 0 to 50 °C EGPC-40A M72 is -20 to 65 °C Operation Humidity 20 to 90% (Non-condensing) Storage Temperature -20 to 60 °C EGPC-40A M72 is -30 to 70 °C Dimensions 22.0 W × 128.0 H × 221.5 D mm Weight Approx. 170 g	uring,

Note: When using EDX-200A and DCS-101A for arithmetic operation, no CAN measurement is possible.

Standard Accessories

Connector plug for digital I/O ports GPS sensor (Cable length: 5 m) Shell case CANdb File Read Optional Software DCS-105A

Example

Conditioner-card slots for analog input

Option slot

Opt

Equipped on EDX-200A-4H



EDX-100A

Universal Recorder



Compact & lightweight, up to 256 channels measurement

- ●Compact & lightweight
- Available with 1, 2 and 4 slots
- LAN port for establishing multichannel network (Max. 256 channels)

Note:

For LAN connection, use straight cables and a LAN hub.



● Conditioner cards (See page 3-93.)

Strain/voltage measurement card
Dynamic strain amplifier card

Thermocouple card
F/V converter card
Charge amplifier card
CAN card
Strain/voltage measurement isolation card
Constant current amplifier card
Strain/voltage/acceleration measurement card
AD converter card

CDV-40B/40B-F DPM-42B-F DPM-42B-I DPM-42B-I DPM-42B-IF CTA-40A CFV-40A CCA-40A/40A-F CAN-41A CDV-44AS/46AS CDA-44AS/45AS CVM-41A AD-40AS/40AS-F

Note: If the CVM-41A is installed in the EDX-100A, and the Bridge Excitation is set to BV 10 V, or the Power Supply to Sensors is set to 10 VDC (± 5 V), then the number of settable channels of CVM-41A in EDX-100A is 3 times of units of CVM-41A.

Note: The EDX-100A limits the number of CFV-40A.

The number of CFV-40A is up to 1 for EDX-100A-1.

The number of CFV-40A is up to 2 for EDX-100A-2, EDX-100A-4.

Specifications

Models

Model name	Max. Channels	Card Slots	DCS-100A*1	DCS-101A*2	Remarks
EDX-100A-1			Yes		
EDX-100A-1-0	8	1			
EDX-100A-1-1			Yes	Yes	
EDX-100A-2			Yes		
EDX-100A-2-0	16	2			
EDX-100A-2-1			Yes	Yes	
EDX-100A-4			Yes		
EDX-100A-4-0	32	4			
EDX-100A-4-1			Yes	Yes	
EDX-100A-1H			Yes		
EDX-100A-1H-0	8	1			
EDX-100A-1H-1			Yes	Yes	
EDX-100A-2H			Yes		With
EDX-100A-2H-0	16	2			handle
EDX-100A-2H-1			Yes	Yes	grip
EDX-100A-4H			Yes		
EDX-100A-4H-0	32	4			
EDX-100A-4H-1			Yes	Yes	

Note: *1. Dynamic Data Acquisition Software

*2. Simultaneous Acquisition of Video and Numeric Data/ Arithmetic Operations/FFT Analysis Optional Software

	Arithm	etic Operations/FFT Analysis Optional Software
Channels		See table above.
Analog Inp	out	Optional conditioner cards
		Implement with DPM, CDV, CTA, CFV, CCA, CVM
		installed
		For details, see page 3-93.
CAN Data I	nput	Accepts one card of CAN-41A
Voice Men	no Input	1 channel.
		Record voice memos included with recordings
		alongside with measurement data (during manual
		measurements) using a dedicated remote control
		(optional accessory)
Sampling F	requenc	у
Sampling	Methods	s Synchronous sampling of all channels
Sampling	Frequen	cies
	1H:	z to 100kHz(1-2-5 series): for 1 channel measurement
	1H:	z to 10kHz(1-2-5 series): for 16 channel measurement
		z to 5kHz(1-2-5 series): for 32 channel measurement
	1H:	z to 1kHz(1-2-5 series): for CAN data measurement
Data Stora	ge CF	cards recommended by Kyowa
		8 MB to 8 GB; 45× speed or higher)
		line data transfer to computers is enabled after the
	rec	ording is complete
Setting Co		
		C via LAN or USB port
		from the CF card which has measuring conditions
		th the DCS-100A data acquisition software
Saving Con		mplifier setting conditions and measuring conditions
		re saved in the internal nonvolatile memory, enabling
	ir	nmediate setup with previous conditions upon power-on.
Measuring		
Manual		cording is manually started or stopped when
		ecorded to a preset number of measured data.
		mode allows recording of voice memo during data
	recordir	-
Trigger		cording is automatically started when the preset trigger
		on is satisfied.
		at any CAN data mustn't be used as a trigger condition
Interval		cording is periodically made at preset intervals.
Manual Sta		of Data Recording
		by using the PC or by pressing the switch on the
		nel or from the dedicated remote control unit
Balance Ac		
		put channels are balanced by pressing the BAL.
	switch o	on the front panel or from the dedicated remote

control unit or from the PC.

^{*}For the Data Analysis Software DAS-200A, see chapter 4.

Saved Data For	mat
	owa standard format KS2, which enables data analysis
	h the optional Data Analysis Software DAS-200A
	LAN or USB port enables online data transfer to the PC,
Conceing Data	while CF card enables offline data transfer.
TEDS Reads ser	nsor's information and sets to channel condition
automati	
	d conditioner cards: CDV-40B (-F), DPM-42B (-F),
	-I (-F), CCA-40A (-F), CDV-44AS, CDA-44AS/45AS, CVM-41A,
AD-40AS	
Synchronous O	peration
Synchronous	cable enables cascade connection of up to 8 units of the
EDX-100A. W	hile data is recorded as a separate file in the CF card
inserted into e	each unit, files of all cards are combined into a single
file after onlin	e or offline data transfer to the PC.
Analog Output	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
	Conditioner cards provide an analog output
	connector, enabling voltage monitoring (±5 VFS).
CF Card Slot	1 (For data recording and condition setting)
Interfaces	LAN and USB (For control and data transfer), switchable
LAN I/F	10BASE-T / 100BASE-TX Connector: RJ45 modular jack
USB I/F	Conforms to USB 2.0 (High speed).
	Connector: Series B receptacle
Operation Switch	nes REC/PAUSE: Starts/pauses data recording.
	STOP: Stops data recording.
	BAL.: Executes balance adjustment.
	READ: Reads and sets conditions.
	ID: Sets ID No. of EDX-100A.
Indicators Ope	LAN/USB: Switches communication port.
	eration status indicator LEDs: 7 annel status indicator LEDs: The number
	responds to the number of channels provided.
External Contro	<u> </u>
	CONT OUT (For remote control and synchronous operation)
	perature 0 to 50°C
	nidity 20 to 90% (Non-condensing)
	rature -20 to 60°C
Vibration Resist	
	±49.03 m/s² (5 G), 5 to 55 Hz (When not operating)
Impact Resistar	
Power Supply	10 to 18 VDC
	Connector: RM12BRD-4PH (Hirose)
	DC power supply or optional dedicated AC adapter
	is required.
Current Consur	nption
EDX-100A-1:	Approx. 1.2 A (When operated on 12 VDC with
	1 CDV-40B card mounted and full load applied)
EDX-100A-2:	Approx. 1.8 A (When operated on 12 VDC with
	2 CDV-40B cards mounted and full load applied)
EDX-100A-4:	Approx. 2.8 A (When operated on 12 VDC with
5	4 CDV-40B cards mounted and full load applied)
Dimensions	EDX-100A-1: 70.0 W × 132.5 H × 255 D mm
	EDX-100A-2: 92.5 W x 132.5 H x 255 D mm
	EDX-100A-4: 137.5 W × 132.5 H × 255 D mm
\\/aimbt	*Excluding protrusions
Weight	EDX-100A-1: 1.6 kg (1.7 kg with 1 CDV-40B card mounted)
	EDX-100A-2: 1.8 kg (2.0 kg with 2 CDV-40B cards mounted)

Standard Accessories DC power cable P-76

Ground wire P-72 USB cable N-38 CF card (1 GB)

DVD (Dynamic data acquisition software DCS-100A) *DCS-100A is optional for models with suffix "-0".

EDX-100A-4: 2.0 kg (2.6 kg with 4 CDV-40B cards mounted)

Optional Accessories USB cable N-39 (2 m)

Cable N-39 (2 III)
Synchronous cable N-128
Camera synchronous cable N-98, N-99, N-101
AC adapter UIA345-12 (For U.S.A.: UNI345-1238)
Cable fixture

Synchronous extension unit ESYN-30A Remote control unit RCU-41A

Battery unit for instantaneous power failure EDB-41B Monitor unit EMON-20A

Dummy panel EDX2000-DUMMY

DCS-100A software, specification for control of **EDX-100A**

i oi actalis oi	Des 100A, see chapter 4.
Units	Up to 8 units (up to 256 channels.)
Interfaces	LAN or USB
Saving Format	Saves the measured data in the EDX-100A CF card or
	PC folder in the KS2 format file.
Channel Conditions	Measuring ON/OFF, Measuring mode, Range,
	High-pass filter, Low-pass filter, Balance adjustment
	ON/OFF, CAL range, CAL ON/OFF, Calibr. const.,
	Offset, Unit, Channel name, Measuring range,
	Rated capacity, Rated output, Deci Digits,
	Internal sensitivity compensation ON/OFF,
	Offset ZERO ON/OFF
	(Display items can freely be selected.)
Loading TEDS Senso	r Information
Loads the TEDS info	rmation automatically and sets the channel conditions
Setting Parameter a	nd Loading Parameter
Loads and sets the E	DX-100A internal parameter.
Collecting Data File	PC collects the KS2 format file, saved in the EDX-100A
	CF card, via LAN/USB.
	To collect the KS2 format file, insert the CF card in the PC.
Deleting Data File	PC deletes the KS2 format file, saved in the EDX-100A
	CF card, via LAN/USB.
Setting Environment	t
Setting Hardware	3
Sets the number of	of units and device names.
	are configurations from the EDX-100A.
Communication Ch	neck Loads the EDX-100A version.
Setting IP Address	
	Saves the IP address setting file in the CF card.

	operating beep sound	
■When Saving the Measured Data in the EDX-100A CF Card		
Sampling Frequency	1 Hz to 100k Hz 1/2/5 system, 2n system, external	
	clock)*Limited by the number of channels.	
File Size	Up to 2 GB.	
	*The number of data varies with the number of	
	channels.	
Measure Mode	Manual, Manual (Set Record Data), Interval,	
	Analog Trigger, External Trigger, Complex Trigger	
Manual Measurement	Records data from REC to STOP or from REC to	
	the number of data, specified on the Manual	
	(Set Record Data).	
Interval Measurement	Records data automatically based on the pre-set	
	starting time and recording interval.	
Trigger Measurement	Starts/stops recording data based on the pre-set	

Device Confirmation LEDs, on the EDX-100A front panel, light up.

Others

Oscillator switching (internal/external),

	starting time and recording interval.	
Trigger Measurement	Starts/stops recording data based on the pre-set	
	trigger conditions.	
Common trigger conditions		
End Trigger	Settable	
Delay	Up to 262144 data for both start and end.	
	The delay time varies with the number of channels.	
Analog Trigger Conditions		
Trigger Channel	Any 1 channel of the master unit	
Trigger Level	Physical quantity	
Trigger Slope	Positive or Negative	

	The delay time varies with the number of that	
Analog Trigger Conditions		
Trigger Channel	Any 1 channel of the master unit	
Trigger Level	Physical quantity	
Trigger Slope	Positive or Negative	
External Trigger Conditions		
Trigger Slope	Positive or Negative	
Complex Trigger Conditions		

Complex Trigger Conditions				
Trigger Source	Select from the analog channels (any 2 channels			
	of the master unit) or external trigger.			
	Capable of judging the trigger source by using			
	the logical AND and OR operators.			
Trigger Level	Physical quantity			
Trigger Slope	Positive or Negative			
■When saving the measured data in the PC folder				
Sampling Frequency	1 Hz to 100k Hz (1/2/5 system, 2n system,			
	external clock)			
File Size	Up to the hard disk capacity.			
Measure Mode	Manual, Manual (Set Record Data), Interval,			

the number of data, specified on the Manual

Analog Trigger $\textbf{Manual Measurement} \ \text{Records data from REC to STOP or from REC to}$

(Set Record Data).



■Remote Control Unit RCU-41A



Control Functions	①"REC/PAUSE":	Starts/pauses data recording.	
	②"STOP":	Stops data recording.	
	③"BAL":	Executes balance adjustment.	
	4"VOICE MEMO": Records voice memo.		
Indicators	REC/PAUSE, BAL		
Cable Length	Approx. 1.5 m		
	(Used by connecting to the CONT IN connector of		
	the EDX-100A recorder unit)		
Dimensions	35 W × 110 H × 20 D mm		
	*Excluding protru	sions	
Weight	Approx.200 g		

■Synchronous Extension Unit ESYN-30A



Display	POWER LED	_		
	With EDX-3000B connected:	Lit green		
	With EDX-100A connected:	Lit orange		
Numbers of	Connected Recorder			
EDX-3000E	3 synchronous operation:	Max. 10		
EDX-100A	synchronous operation:	Max. 8		
EDX-3000B, EDX-100A mixed synchronous operation *1: Max. 8				
Total Synchronous Cable Length *2				
EDX-3000E	3 synchronous operation:	1000 m or less		
EDX-100A	synchronous operation:	50 m or less		
EDX-3000E	3, EDX-100A mixed synchronous operatio	on *1: 50 m or less		
Synchronous Cable Length between Devices				
EDX-3000E	3 synchronous operation:	100 m or less		
EDX-100A	synchronous operation:	50 m or less		
EDX-3000B, EDX-100A mixed synchronous operation *1:50 m or less				
Dimensions	$92 \text{ W} \times 24.6 \text{ H} \times 55 \text{ D} \text{ mm}$ (Excluding p	orotrusions)		
Weight	250 g or less			

*1 The ID number of EDX-100A must be higher than an ID number of EDX-3000B.


*2 Not including the synchronous cable length.

Note: When using ESYN-30A, do not use a remote control unit.

Optional Accessories EDX connection cables N-106, N-107 Terminators ESYN-1A (For slave), ESYN-2A (For master) Extension cables N-108, N-109, N-110, N-111


Dimensions

●1 Slot EDX-100A-1 EDX-100A-1H (With handle grip)








EDX-100A-4H
















EMON-20A

Monitor Unit



- Monitoring any 8-channel data
- Touching the panel to control the EDX-100A and EDX-200A
- Setting channel conditions (Measure ON/OFF, channel modes, measuring range, LPF, sampling frequencies,
- Confirming recorded data on the spot

Specifications

Applicable Recorders	EDX-100A and EDX-200A (Max. 3 units in sync)			
Display	LCD: 5.7" color TFT, 320 x 2	240		
	Touchscreen: Analog resist	tive film type		
	POWER LED : ON (Power ON)			
		k right is OFF, Updating)		
	OFF (Power 0			
Display Contents	Y-time graph: Max. 8 channels. It is not possible			
	to select some channels over several EDXs that is			
	in synchronous operation.			
	Numeric monitoring: Max. 8 channels. It is not			
	possible to select some channels over several EDXs			
	that is in synchronous operation.			
	Data confirmation: Max. 8 channels			
Control Items	Measuring items: Monitor start (MONITOR),			
Control Items	stop (STOP), record (REC), and balance (BAL)			
	Channel conditions: Measi			
	switching modes, LPF			
	Measuring conditions: San			
Other Functions	EMON-20A settings	inpling frequencies		
Other runetions		lish) background color		
	Language (Japanese/English), background color (black/white), operating beep (ON/OFF),			
	back light (lighting time), network settings,			
	preset values initialization			
	Measuring unit information			
	EDX model, the number of			
	EDX model, the number of			
	EDX subnet mask, conditi			
Coupling Cable	Dedicated cable within 5 m			
Power Supply	10 to 36 VDC or AC exclus			
Current Consumption	450 mA or less (12 VDC)	ive adapter		
Current Consumption	200 mA or less (24 VDC)			
Dimensions	166 W × 29 H × 128.5 D mr	n (Excluding protrusions		
Weight	Approx. 550 g	ir (Excidairig protrasioris		
Vibration Resistant	29.4 m/s ² (3 G), 5 to 200 H	l ₇		
Shock Resistance	147.0 m/s ² (15 G), 11 ms o			
Operating Temperatu		11 1033		
Operating Humidity	20 to 80% (Non-conder	nsina)		
Control Available Con		131119/		
	eration Measurement Card	CVM-41A		
Strain/Voltage/Accel		CDV-40B, CDV-40B-F		
Dynamic Strain Meas		DPM-42B, DPM-42B-F,		
Dynamic Strain Meas	ulernent Card	DPM-42B-I,		
		DPM-42B-I-F		
Thermocouple Card		CTA-40A		
F/V Converter Card		CFV-40A		
Charge Amplifier Card	d	CCA-40A, CCA-40A-F		
Charge Ampimer Can	urement Insulation Card	CDV-44AS		
Direct Rated Current		CDA-44AS, CDA-45AS		
A/D Converter Card	LAPATISION CAIU	AD-40AS, AD-40AS-F		
CAN Card*1		CAN-41A		
	nd recording data are availa			
*1 Monitoring data and recording data are available. Confirming with recorded data and changing CAN setting condition are				
	rueu uata anu changing CA	is setting condition are		
not available.				

Standard Accessories

Connection cable (Approx. 5 m)

Optional Accessories

AC adapter UIA345-12 (For U.S.A.: UNI345-1238)

DC power cable P-76

*For custom-designed products, contact us.
*Requires the EDX-100A/200A firmware version 02.00 or higher.

Dimensions

