

Significance of Use

Dissolved oxygen analysis measures the amount of gaseous oxygen (O₂) dissolved in an aqueous solution. Dissolved oxygen is one of the most important parameters in aquatic systems. This gas is required for metabolism by aerobic organisms and also influences inorganic chemical reactions. Therefore, knowledge of the solubility and dynamics of oxygen distribution is essential to interpreting both biological and chemical processes within water bodies. Oxygen gets into water by diffusion from the surrounding air by aeration (rapid movement) and as a product of photosynthesis. The amount of oxygen (or any gas) that can dissolve in pure water (saturation point) is inversely proportional to the temperature of the water; the warmer the water, the less dissolved oxygen is present.

Specifications H	196732 Oxygen,	Dissolved
------------------	----------------	-----------

Specifications	ni96/32 Oxygeii, Dissoived	
Range	0.0 to 10.0 mg/L (ppm)	
Resolution	0.1 mg/L	
Accuracy @ 25°C (77°F)	±0.4 mg/L ±3% of reading	
Light Source	light emitting diode	
Light Detector	silicon photocell with narrow band interference filter @ 466 nm	
Power Supply	9V battery	
Auto-off	after ten minutes of non-use in measurement mode; after one hour of non-use in calibration mode; with last reading reminder	
Environment	0 to 50°C (32 to 122°F); RH max 95% non-condensing	
Dimensions	193 x 104 x 69 mm (7.6 x 4.1 x 2.7")	
Weight	360 g (12.7 oz.)	
Method	Adaptation of Standard Methods for Examination of Water and Wastewater (18th edition) Azide modified Winkler method reaction causes a yellow tint in sample	
Ordering Information	HI96732 is supplied with sample cuvettes (2) with caps, 9V battery, instrument quality certificate and instruction manual CAL Check™ standards and testing reagents sold separately	
Reagents and Standards	HI96732-11 CAL Check™ standard cuvettes	
	HI93732-01 reagents for 100 tests	
	HI93732-03 reagents for 300 tests	

ติดต่อบริษัท นีโอนิคส์ จำกัด

Tel: 02-077-7602 หรือ 061-8268939

E-mail: sale@neonics.co.th หรือ sale@tools.in.th

HI96732

Dissolved Oxygen Portable Photometer

CAL Check

 Allows for performance verification and calibration of the meter using NIST traceable standards.

GIP

· Review of the last calibration date.

· Auto-shut off

 Automatic shut off after 10 minutes of non-use when the meter is in measurement mode. Prevents wastage of batteries in the event the meter is accidentally left on.

• Battery status indicator

 Indicates the amount of battery life left.

• Built-in timer

 Display of time remaining before a measurement is taken. Ensures that all readings are taken at the appropriate reaction intervals for the test being performed.

Error messages

 Messages on display alerting to problems including no cap, high zero, and standard too low.

• Cooling lamp indicator

 To maintain the desirable wavelength to be used for absorbance, it is necessary to ensure components are not overheated from the heat generated by the tungsten lamp. Each photometer is designed to allow a minimal amount of time for components to cool. The cooling lamp indicator is displayed prior to a reading being taken.

• Units of measure

 Appropriate unit of measure is displayed along with reading.

The HI96732 portable photometer is for the measurement of dissolved oxygen. Hanna's portable photometers feature an advanced optical system; the combination of a light emitting diode, a narrow band interference filter, and silicon photodetector ensure accurate photometric readings every time. The Hanna exclusive CAL Check™ feature utilizes ready-made, NIST traceable standards to verify both meter validation and calibration. The exclusive cuvette locking system ensures that the cuvette is inserted into the measurement cell in the same position every time to maintain a consistent path length.

