

### Safety Symbols

In the manual, the A symbol indicates particularly important information that the user should read before using the

device A The  $\Lambda$  symbol printed on the device indicates that the user should refer to a corresponding topic in the manual (marked with the A symbol) before using the relevant function.

#### Indicates DC (Direct Current). \_\_\_\_

The following symbols in this manual indicate the relative importance of cautions and warnings.

- MWARNING Indicates that incorrect operation presents a significant hazard that could result in serious injury or death to the user.
- CAUTION Indicates that incorrect operation presents a possibility of injury to the user or damage to the device.
  - Indicates advisory items related to performance or correct NOTE Indicates advisory ....

#### Symbols for Various Standards

This symbol indicates that the product conforms to safety CE regulations set out by the EC Directive.

WEEE marking: This symbol indicates that the electrical and electronic appliance is put on the EU market after August 13, 2005, and producers of the Member States are required to display it on the appliance under Article 11.2 of Directive 2002/96/EC (WEEE).

## Usage Notes

Before using the device for the first time, verify that it operates normally to ensure that no damage occurred during storage or shipping. If you find any damage, contact your dealer or Hioki representative.

### **AWARNING**

Before using the device, make sure that the insulation on the probes is undamaged and that no bare conductors are improperly exposed. Using the device in such conditions could cause an electric shock, so contact your dealer or Hioki representative for repair.

### **ACAUTION**

- Do not store or use the device where it could be exposed to direct sunlight, high temperature or humidity, or condensation. Under such conditions, the device may be damaged and insulation may deteriorate so that it no longer meets specifications.
- Do not use the device where it may be exposed to corrosive or combustible gases. The device may be damaged.
- Do not use it in an especially dusty environment, nor where it might be splashed with liquid. This may cause damage.
- shock when transporting and handling. Be especially careful to avoid physical shock from dropping.
- the probe is contaminated with an excess amount of water, oil, or dust.
- suring device to which this product is connected. Using a wrong probe may increase the measurement error.


### NOTE

For more information about how to use the instrument with which you are using the probe, refer to that instrument's instruction manual.

## **Specifications**

Rubber-sheathed alligator-clip-type
9500: DC to 1 MHz
9500-10: DC to 200 kHz
±40 V DC (42 Vpeak (Measurement signal +
bias voltage))
1 Apeak (Measurement signal + bias current)
Approx. 1000 mm (39.37") (not including connection terminal)
9500: Approx. 230 g (8.1 oz.)
9500-10: Approx. 140 g (4.9 oz.)
9500: 75 Ω coaxial cable
9500-10: 50 Ω coaxial cable
0 to 40°C (32 to 104°F), 80%RH or less.
(non-condensing)
-10 to 55°C (14 to 131°F), 80%RH or less.
(non-condensing)
Indoors, Pollution Degree 2
altitude up to 2000 m (6562 feet)
Instruction manual
EN61010

# **Names of Parts**



# **Connection Methods**

9500

side printed with the model number is on top, plug it into the instrument's measurement terminals and secure in place with the levers on the left and right.

## 9500-10

BNC plug of  $H_{cur}$ ,  $H_{pot}$ ,  $L_{cur}$  and L<sub>not</sub> connected properly to the measurement terminals of each of the instruments


# **Open and Short Correction**

When using the Model 3532-80 Chemical Impedance Meter and IM Series , perform open and short correction to increase measurement precision.

#### You will need: Two short bars

A short bar is a device that shorts the measurement cable's terminals. Use short bars with as low an impedance as possible. When using a metal wire or similar object as the short bar, use as thick and short a wire as possible.

#### Open correction



Short the probe's H<sub>cur</sub> and H<sub>pot</sub> terminals (red) with one short bar and its L<sub>cur</sub> and -not terminals (black) with the other, so that there is no connection between the high and low terminals. Perform open correction.

\*1: Leave the high and low terminals as far apart as they will be when connected to the measurement sample.

#### Short correction



Short the probe's H<sub>cur</sub>, H<sub>pot</sub>, L<sub>pot</sub>, and L<sub>cur</sub> terminals in this order, with a short bar and perform short correction.

### NOTE

- To perform zero adjustment with the Model RM3543 Resistance HiTester, follow the directions in the RM3543 instruction manual.
- · For more information about instrument operation, refer to the instrument's instruction manual.

#### **Measurement Procedures** $\wedge$

Attach the rubber-sheathed alligator clips at the end of the probe to the measurement sample and make measurements.

### NOTE

Contract.

ODD DD

- Exercise caution as dirt on the connection surfaces of electrodes or the measurement sample may prevent proper contact, making accurate measurement impossible.
- Open correction and measurement of high-impedance elements are susceptible to the effects of external induced noise and stray capacitance. It is recommended to use quarding. for example by making measurements on a metal plate that has been connected to the guard terminal. (For more information about guarding, refer to the instrument's instruction manual.)

# **Maintenance and Service**

- · To clean the device, wipe it gently with a soft cloth moistened with water or mild detergent. Never use solvents such as benzene, alcohol, acetone, ether, ketones, thinners or gasoline, as they can deform and discolor the case.
- · If the device seems to be malfunctioning, contact your dealer or Hioki representative. Pack the device so that it will not sustain damage during shipping, and include a description of existing damage. We do not take any responsibility for damage incurred during shipping.

#### WWW. Warrant Warranty formity w ings will of one (1 tor from warrantv

Introd

 $\cap$ Thank y 0 Termina П vice, ple referenc

#### Initial

tion


presentative.

When ye no dama it fails to dealer o

-The 950 connect O Model 3 Resistar B alligator measure Q Impedar Ö Saf J Follow tl the full t 9 ∕∆WAF -**T** 

Mishar В or deat you ur manua accide defects

O



ons occurring under conditions of normal use in con-

truction Manual and Product Precautionary Mark-

the date of purchase. Please contact the distribu-

purchased the product for further information on

Irchasing the HIOKI Model 9500, 9500-10 4-

To obtain maximum performance from the de-

e the device, inspect it carefully to ensure that

red during shipping. If damage is evident, or if

according to the specifications, contact your


this manual first, and keep it handy for future

d free of charge. This warranty is valid for a period

# nformation

autions to ensure safe operation and to obtain f the various functions.

is device during use could result in injury Il as damage to the device. Be certain that d the instructions and precautions in the use. We disclaim any responsibility for juries not resulting directly from device



- This device is not designed to be entirely water- or dust-proof.
- To avoid damage to the device, protect it from physical
- Stop use and contact your dealer or Hioki representative if
- · Which 4-terminal probe can be used depends on the mea-

Orienting the probe so that the

