
Instruction Manual

HI 9040 Portable Microprocessor Thermistor Thermometer



This Instrument is in Compliance with CE Directives

WARRANTY

www.hannainst.com

All Hanna Instruments **meters are warranted for two years** against defects in workmanship and materials when used for their intended purpose and maintained according to instructions. **Sensors and probes are warranted for a period of six months**.

This warranty is limited to repair or replacement free of charge. Damages due to accidents, misuse, tampering or lack of prescribed maintenance are not covered.

If service is required, contact the dealer from whom you purchased the instrument. If under warranty, report the model number, date of purchase, serial number and the nature of the failure.

First obtain a Returned Goods Authorization number from the Customer Service department, then return the instrument with the Authorization # included along with shipment costs prepaid. If the repair is not covered by the warranty, you will be notified of the charges.

When shipping any instrument, make sure it is properly packaged for complete protection.

All rights are reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner, Hanna Instruments Inc., Woonsocket, Rhode Island, 02895, USA.

Hanna Instruments reserves the right to modify the design, construction and appearance of its products without advance notice.

Dear Customer,

Thank you for choosing a Hanna product. This manual will provide you with the necessary information for correct operation. Please read it carefully before using the meter. If you need additional technical information, do not hesitate to email us at tech@hannainst.com.

This instrument is in compliance with the CC directives.

PRELIMINARY EXAMINATION

Remove the instrument from the packing material and examine it carefully to make sure that no damage has occurred during shipping. If there is any noticeable damage, notify your Dealer or the nearest Hanna Office.

Note: Save all packing materials until you are sure that the instrument functions correctly. Any defective item must be returned in the original packaging together with the supplied accessories.

GENERAL DESCRIPTION


HI 9040 is a hand-held microprocessor-based thermometer which allows fast and accurate temperature measurements, using a calibrated thermistor probe. The temperature probe is linearized by the microprocessor.

The meter is also provided with low battery detection and BEPS (Battery Error Preventing System), which turns the unit off when battery is discharged avoiding erroneous readings caused by low battery level.


HI 9040 features include a dual-level LCD for simultaneously displaying of maximum and minimum measured temperatures, $^\circ C\!/^\circ F$ selection button and HOLD function.

Each meter is supplied complete with a **HI 765BL** thermistor probe, a 9V battery and instruction manual.

FUNCTIONAL DESCRIPTION



Liquid Crystal Display
Measuring unit selection key
HI/LO values reset key
HOLD key
ON/OFF key




1) Current temperature value

- HOLD indicator
- 3) Low Battery indicator
- 4) Minimum temperature value
- 5) Maximum temperature value
- 6) Measuring unit, °C or °F

SPECIFICATIONS

Range	-50.0 to 150.0°C / -58.0 to 302.0°F
Resolution	0.1°C or 0.1°F
Accuracy	$\pm 0.4^{\circ}$ C / $\pm 0.8^{\circ}$ F
	excluding probe error
Typical EMC	$\pm 0.5^{\circ}$ C / $\pm 1^{\circ}$ F,
Deviation	with HI 765BL probe
Display	Dual-line LCD
Battery Type	1 x 9V (IEC 6LR61) battery
Life	approx. 700 hours of continuous use
Probe (included)	HI 765BL with 1 m (3.3') cable
Environment	-10 to 50°C (14 to 122°F);
	max. 95% RH non-condensing
Dimensions	180 x 83 x 40 mm (7.1x3.3x1.6")
Weight	226 g (8 oz.) meter only

CE DECLARATION OF CONFORMITY



OPERATIONAL GUIDE

INITIAL PREPARATION

Remove the battery cover on the back of the thermometer. Unwrap the supplied 9V battery, connect it to the clip and reattach the cover.

Connect the temperature probe to the connector on the top of the meter.

To switch ON, press the ON/OFF key on the front of the meter.

The thermometer will carry out a self diagnostic test routine. the LCD will show all seaments for a few seconds (or as long

as ON/OFF is held), followed by the percentage indication of the remaining battery life.

The thermometer then enters normal measurement mode.

If a temperature probe is plugged in, the meter displays the measured temperature.

If no probe is plugged in, or if reading is over-range, the display shows flashing dashes.

If a measurement is slightly over the range of the meter specifications, the display flashes the closest full-scale value. To switch the thermometer OFF, press the ON/OFF key.

MEASURING SCALE (°C/°F)

The instrument is factory set to the °C scale, but measurements can be performed in either the Celsius or Fahrenheit scale.

Press the $^{\circ}C/^{\circ}F$ button to select the desired scale

HOLD MODE

The HOLD function is activated by pressing the HOLD key.

The measured temperature is held on the display until HOLD is pressed again. The "H" tag blinks on the display to indicate the HOLD mode.

100 855

35

Note: Although the display is frozen, internally the meter continues measuring and updating Hi and Lo values.

HIGH/LOW TEMPERATURES

The maximum and minimum temperatures are continuously monitored and displayed in the lower portion of the LCD.



Note: When reading goes over-range, the Hi and Lo values display dashes until cleared.

CLEAR FUNCTION

ment.

Upon pressing the CLEAR key, the current reading is assigned to the highest and lowest temperature values. The High/Low values may be cleared at any time during measure-



BATTERY REPLACEMENT

The instrument is powered by a 9 V battery and is provided with the Battery Error Prevention System (BEPS), which turns the unit off when a low battery signal is detected.

When the remaining battery level is סיד הר less than 10%, a warning symbol Ìġ́-L 100 H 355 blinks on the display to indicate a low battery condition.

It is recommended to replace the battery as soon as the low battery condition is detected.



Remove the cover on the meter's back by applying pressure in the indicated direction. Unplug the rundown battery and replace it with a new one.

Battery replacement must only take place in a non-hazardous area using a 9V alkaline battery.

FACTORY RECALIBRATION

All Hanna thermometers have been accurately pre-calibrated at the factory.

It is recommended to have all thermometers recalibrated at least once a year. For an accurate annual recalibration, contact your nearest Hanna Service Center.

Hanna Accuracy Test Plugs provide a quick and easy way to test the meter's accuracy by simply connecting these Test Plugs to the probe connector of the meter. If the reading differs by more than $\pm 0.4^{\circ}$ C ($\pm 0.8^{\circ}$ F) from the Test Plug value, the meter is due for recalibration. Choose the Test Plug closest to your measurement range to best suit your needs:

HI 765-18C Calibration key, -18.0°C HI 765000C Calibration key, 0.0°C HI 765070C Calibration key. 70.0°C HI 765-004F Calibration kev. -0.4°F HI 765032F Calibration kev. 32.0°F HI 765158F Calibration kev. 158.0°F



Recommendations for Users

Before using these products, make sure that they are entirely suitable for the environment in which they are used.

Operation of these instruments in residential areas could cause unacceptable interference to radio and TV equipment, requiring the operator to take all necessary steps to correct interference. Any variation introduced by the user to the supplied equipment may degrade the instruments' EMC performance

To avoid electrical shock, do not use these instruments when voltage at the measurement surface exceeds 24VAC or 60VDC

To avoid damage or burns, do not perform any measurement in microwave ovens.

TEMPERATURE PROBES & ACCESSORIES

Hanna offers a wide range of probes to meet your needs with air, liquid, penetration and surface measurements.

All Hanna temperature probes are pre-calibrated at the factory and ready-to-use. These interchangeable probes make it possible to switch from one probe to another without requiring recalibration.

Hanna probes are also available in different handle colors to avoid cross contamination during testing.

PROBES WITH 1 m (3.3') CABLE

HI

HI

HI

HI

HI

HI

HI

HI

HI

765A	Air probe with white handle
765BL	General purpose liquid probe with black handle
765L	General purpose liquid probe with white handle
765PBL	General purpose penetration probe with blue
	handle
765PG	General purpose penetration probe with green
	handle
765PR	General purpose penetration probe with red
	handle
765PW	General purpose penetration probe with white
	handle
765PWL	Penetration probe with white handle
765W	Wire probe without handle for hard-to-reach
765PR 765PW 765PWL	handle General purpose penetration probe with red handle General purpose penetration probe with white handle Penetration probe with white handle

places

PROBES WITH 10 m (33') CABLE

HI 765A/10 Air probe with white handle

- HI 765L/10 General purpose liquid probe with white handle
- HI765PBL/10 General purpose penetration probe with **blue** handle
- HI 765PG/10 General purpose penetration probe with green handle
- HI765PR/10 General purpose penetration probe with red handle
- HI 765PW/10 General purpose penetration probe with white handle
- HI 765W/10 Wire probe without handle for hard-to-reach places

OTHER ACCESSORIES

HI 710002	Soft carrying case
HI 710009	Blue rubber boot
HI 710010	Orange rubber boot
HI 710031	Hard carrying case
HI 721310	9V Battery (10 pcs)